

# Electrical Safety Analyzer

GPT-10000 Series

---

**USER MANUAL**



ISO-9001 CERTIFIED MANUFACTURER

**GW INSTEK**

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance procedures at any time without notice.

**Good Will Instrument Co., Ltd.**  
**No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.**

---

# Table of Contents

<b>SAFETY INSTRUCTIONS .....</b>	<b>5</b>
<b>GETTING STARTED.....</b>	<b>9</b>
GPT-10000 Series Overview .....	10
Front Panel Overview .....	15
Rear Panel Overview .....	19
Set Up.....	22
<b>OPERATION .....</b>	<b>29</b>
Menu Tree.....	31
Test Lead Connection.....	36
Manual Tests .....	39
Special MANU Test Mode (000) .....	95
Sweep Function.....	97
Automatic Tests .....	100
System Settings .....	125
<b>EXTERNAL CONTROL .....</b>	<b>172</b>
External Control Overview.....	173
<b>REMOTE CONTROL.....</b>	<b>179</b>
Interface Configuration .....	180
Command Syntax .....	185
Command List .....	188
Error Messages.....	249
<b>FAQ.....</b>	<b>251</b>
<b>APPENDIX.....</b>	<b>254</b>
Fuse Replacement.....	254
Tester Errors .....	255

Factory Default Parameters .....	258
GPT-10000 Specifications .....	260
GPT-15001/15002/15003 Dimensions	268
GPT-15004 Dimensions.....	269
GPT-12001/12002/12003 Dimensions	270
GPT-12004 Dimensions.....	271
Declaration of Conformity .....	272
Declaration of Conformity .....	273
<b>INDEX.....</b>	<b>274</b>



# S SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow during operation and storage. Read the following before any operation to ensure your safety and to keep the instrument in the best possible condition.

## Safety Symbols

These safety symbols may appear in this manual or on the instrument.

---



WARNING

Warning: Identifies conditions or practices that could result in injury or loss of life.



CAUTION

Caution: Identifies conditions or practices that could result in damage to the instrument or to other properties.



DANGER High Voltage



Attention Refer to the Manual



Protective Conductor Terminal



Frame or Chassis Terminal



Earth (ground) Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

## Safety Guidelines

---

### General Guideline



#### CAUTION

- Do not place any heavy object on the instrument.
- Avoid severe impact or rough handling that leads to damaging the instrument.
- Do not discharge static electricity to the instrument.
- Use only mating connectors, not bare wires, for the terminals.
- Do not block the cooling fan opening.
- Do not disassemble the GPT-10000 unless you are qualified.

### Position Guideline



#### WARNING

- The rear position of the GPT-10000 should be placed in an area with easy accessible for power disconnection, that is, unplugging the power cord with ease.
- Keep away from the device under test which connects with the GPT-10000 when test is underway. In addition, while test is ongoing, never touch the device under test, the GPT-10000 as well as other relevant units.
- Any inappropriate manner that is unspecified by the manufacturer may result in irreversible harms or impaired protection by the GPT-10000.

(Measurement categories) EN 61010-1:2010 specifies the measurement categories and their requirements as follows. The GPT-10000 does not fall under category II, III or IV.

- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.

---

#### Power Supply



WARNING

- AC Input voltage range:  
AC 100V – 240V  $\pm$  10%
- Frequency: 50Hz/60Hz
- To avoid electrical shock connect the protective grounding conductor of the AC power cord to an earth ground.

---

#### Cleaning the GPT-10000

- Disconnect the power cord before cleaning.
- Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.
- Do not use chemicals containing harsh material such as benzene, toluene, xylene, and acetone.

---

#### Operation Environment

- Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)
- Relative Humidity:  $\leq$  70% (no condensation)
- Altitude: < 2000m
- Temperature: 0°C~40°C

(Pollution Degree) EN 61010-1:2010 specifies the pollution degrees and their requirements as follows. The GPT-10000 falls under degree 2.

Pollution refers to “addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity”.

- Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
- Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.
- Pollution degree 3: Conductive pollution occurs, or dry, non-conductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.

---

#### Storage environment

- Location: Indoor
- Temperature: -10°C to 70°C
- Relative Humidity:  $\leq 85\%$  (no condensation)

---

#### Disposal



Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.

# G E T T I N G   S T A R T E D

This chapter describes the safety analyzer in a nutshell, including its main features and front / rear panel introduction. After going through the overview, please read the safety considerations in the Set Up chapter.

---

<b>GPT-10000 Series Overview .....</b>	<b>10</b>
Series lineup .....	10
Lineup Overview .....	11
Main Features .....	11
Accessories .....	12
Package Contents .....	14
<b>Front Panel Overview .....</b>	<b>15</b>
GPT-12001/12002/12003/12004/15001/15002/15003/15004 .....	15
<b>Rear Panel Overview .....</b>	<b>19</b>
GPT-12001/12002/12003/12004/15001/15002/15003/15004 .....	19
<b>Set Up .....</b>	<b>22</b>
Tilting the Stand .....	22
Line Voltage Connection and Power Up .....	23
Installing the Optional LAN/GPIB Card .....	24
Workplace Precautions .....	25
Operating Precautions .....	26
Basic Safety Checks .....	28

## GPT-10000 Series Overview

### Series lineup

The GPT-10000 Series Safety Analyzers are AC/DC withstanding voltage, insulation resistance, ground bond and continuity safety analyzers.

By and large, GPT-10000 Series has 2 major categories, one is GPT-12XXX models, and the other is GPT-15XXX models. The subordinate models of 2 categories share the same test functions but with different specifications. We use the term “X” for the 2nd digit of model names described below to stand for both 2 categories in common.

The GPT-1X001 is AC withstanding voltage and continuity tester, the GPT-1X002 is AC/DC withstanding voltage and continuity tester and the GPT-1X003 is AC/DC withstanding voltage, insulation resistance and continuity tester. The GPT-1X004 includes all the test functions of the other models, plus the ground bond testing. See the following Lineup Overview for more details.

The GPT-10000 Series can store up to 100 manual tests, as well as run up to 10 manual tests sequentially as an automatic test, allowing the safety analyzers to accommodate any number of safety standards, including IEC, EN, UL, CSA, GB, JIS and others.

Note: Throughout this user manual, the terms ACW, DCW, IR, GB and CONT refer to AC Withstanding, DC Withstanding, Insulation Resistance, Ground Bond and Continuity testing, respectively.

## Lineup Overview

Model name	ACW	DCW	IR	GB	CONT
GPT-12001	✓				✓
GPT-12002	✓	✓			✓
GPT-12003	✓	✓	✓		✓
GPT-12004	✓	✓	✓	✓	✓
GPT-15001	✓*				✓
GPT-15002	✓*	✓			✓
GPT-15003	✓*	✓	✓		✓
GPT-15004	✓*	✓	✓	✓	✓

- Short Current > 200mA

## Main Features

- Performance
- ACW: 0.05kV~5kVAC
  - DCW: 0.05kV~6kVDC
  - IR: 50V~1200V (50V steps)\*
  - GB: 3A~32A
  - CONT: 100mA (fixed)

- Features
- Ramp up time control
  - Ramp down time control
  - Safety discharge
  - 100 test conditions (MANU mode)
  - 100 automatic tests (AUTO mode)
  - Over temperature, voltage and current protection
  - Pass, Fail, Test, High Voltage and Ready indicators
  - PWM output (90% efficiency, increased reliability)
  - Interlock (configurable)
  - Rear panel output

- Interface
- Remote control start/stop interface terminal
  - RS232/USB interface for programming
  - Optional GPIB interface for programming
  - Optional LAN interface for programming
  - Signal I/O port for pass/fail/test monitoring and start/stop control/interlock

### Accessories

Standard Accessories	Part number	Description
	GHT-115x1	Test lead
	Region dependent	Power cord
	GTL-215x1	GB test lead (GPT-12004/GPT-15004 only)
	GHT-119	Remote terminal cable
	N/A	Interlock key




Optional Accessories	Part number	Description
	GHT-205	High Voltage Test Probe
	GHT-113	High Voltage Test Pistol
	GTL-232	RS232C cable
	GTL-248	GPIOB cable
	GTL-246	USB cable (A to B type)
	GRA-440	Rack Adapter Panel (19", 4U) (GPT-12000/15000 only)
Options	Part number	Description
	GPT-10KG1	GPIOB card
	GPT-10KL1	LAN card

## Package Contents

Check the contents before using the GPT-10000 series.

### Opening the box



#### Contents (single unit)


- GPT-10000 unit
- Quick Start Guide
- User manual CD
- CTC (Calibration Traceable Certificate)
- Power cord x1 (region dependent)
- GHT-115 test leads x1
- GTL-215 GB test leads x1 (GPT-12004/GPT-15004 only)
- GHT-119 Remote terminal cable
- Interlock key




Keep the packaging, including the box, polystyrene foam and plastic envelopes should the need arise to return the unit to GW Instek.


## Front Panel Overview


GPT-12001/12002/12003/12004/15001/15002/15003/15004



Item	Description
1	STOP Button
2	START Button
3	POWER Switch
4	Test Function Keys (Green Zone)
5	Display
6	Mode Keys (AUTO, MANUAL, SYSTEM in Red Zone)
7	Soft Keys (Blue Zone)
8	USB A-Type Host Port
9	PASS/FAIL Indicators
0	REMOTE Terminal
A	Scroll Wheel
B	HIGH VOLTAGE Indicator
C	HIGH VOLTAGE Output Terminal
D	SENSE L & RETURN Terminal
E	SENSE H & Output Terminal
F	SOURCE L (GPT-12004/GPT-15004 only)
G	SOURCE H (GPT-12004/GPT-15004 only)


**STOP button**  The STOP button is used to stop/cancel tests. The STOP button will also put the safety analyzer in the READY status to begin testing.


**START button**  The START button is used to start tests. The START button can be used to start tests when the tester is in the READY status. Pressing the START button will put the tester in the TEST status.

**POWER switch**  Turns the power on. The safety analyzer will always start up with the last test setting from when the instrument was last powered down.

**Test Function Keys** The keys indicate the 5 testing functions including ACW, DCW, IR, GB and CONT. Pressing one of the keys enters the function settings.

**Display** 7" Color TFT LCD display in 800 X 480 resolution


**AUTO button**  Press to enter the AUTO test mode.

**MANUAL button**  Press to enter the MANUAL test mode.

**SYSTEM button**  Press to enter the SYSTEM mode.


**Soft Keys** The Soft keys correspond to the menu keys directly above on the main display.

USB Host Port



It can connect with USB flash drive for data and log import/export and for firmware update. Also, it is able to connect with USB disk for screenshot hardcopy and barcode scanner for convenient tests.

Pass/Fail indicators



The PASS and FAIL indicators light up upon a PASS or FAIL test result at the end of a manual test or automatic test.

REMOTE terminal



The REMOTE terminal is used to connect to a remote controller.

Scroll wheel




The scroll wheel is used to edit parameter values.

HIGH VOLTAGE indicator



The HIGH VOLTAGE indicator will light up red when an output terminal is active. Only after the test has finished or stopped will the indicator turn off.

HIGH VOLTAGE output terminal




The HIGH VOLTAGE terminal output is used for outputting the testing voltage in ACW, DCW and IR tests. The terminal is recessed for safety. This terminal is used in conjunction with the RETURN terminal.



**WARNING**


**USE EXTREME CAUTION.**  
Do not touch the **HIGH VOLTAGE** terminal during testing.

**RETURN terminal**



The RETURN terminal is used for ACW, DCW, IR and CONT tests.

**OUTPUT and RETURN terminals**




The OUTPUT terminal (red) and RETURN terminal (black) are used for CONT (Continuity) test.

**SENSE H/L and SOURCE H/L terminals**


GPT-12004,  
GPT-15004 only

The SENSE H, SENSE L, SOURCE H and SOURCE L, terminals are used for GB (Ground Bond) test.











## Rear Panel Overview

GPT-12001/12002/12003/12004/15001/15002/15003/15004



Item	Description
1	HIGH VOLTAGE Output Terminal
2	HIGH VOLTAGE Indicator
3	SENSE H & Output Terminal
4	SENSE L & RETURN Terminal
5	SOURCE H (GPT-12004/GPT-15004 only)
6	SOURCE L (GPT-12004/GPT-15004 only)
7	Fan
8	RS-232 Port
9	USB B-Type Interface Port
A	Signal I/O Port
B	GPIB Port/Ethernet LAN Port (Optional)
C	GND
D	AC Mains Input (Power Cord Socket)
E	HIGH VOLTAGE pilot lamp

- |                      |  |  |
|----------------------|--|--|
| SIGNAL I/O port      | <p>SIGNAL I/O</p>   | <p>The SIGNAL I/O port is used to monitor the tester status (PASS, FAIL, TEST) and input (START/STOP signals). It is also used with the Interlock key.</p>     |
| USB B-Type port      |   | <p>The USB B-Type port is used for remote control.</p>   |
| RS232 interface port | <p>RS232</p>    | <p>The RS-232 port is used for remote control.</p>   |
| Fan/Fan Vents        |   | <p>Exhaust fan. Allow enough room for the fan to vent. Do not block the fan openings.</p>  |
| GND                  | <p>GND</p>    | <p>Connect the GND (ground) terminal to the earth ground.</p>  |
| AC Mains Input       | <p>AC 100 - 240V ~<br/>50/60Hz 400VA MAX.</p>  <p>FUSE RATING<br/>T4A 250V</p> | <p>AC Mains Input for Power Cord Socket: 100 - 240 VAC ±10%.</p> <p>The fuse holder contains the AC mains fuse. For fuse replacement details, see page 45.</p> |
| Optional LAN port    | <p>LAN</p>    | <p>Optional LAN port for remote control.</p>   |
| Optional GPIB port   | <p>GPIB</p>   | <p>Optional GPIB interface for remote control.</p>   |




HIGH VOLTAGE output terminal



**CAUTION**  
HIGH VOLTAGE  
5.0 kVAC MAX.  
6.0 kVDC MAX.



The HIGH VOLTAGE terminal output is used for outputting the testing voltage in ACW, DCW and IR tests. The terminal is recessed for safety and used in conjunction with the RETURN terminal.



**WARNING**


USE EXTREME CAUTION. Do not touch the HIGH VOLTAGE terminal during testing.

HIGH VOLTAGE pilot lamp



The HIGH VOLTAGE pilot lamp will light up red when an output terminal is active. Only after the test has finished or stopped will the lamp turn off.


RETURN terminal



The RETURN terminal is used for ACW, DCW, IR and CONT tests.

OUTPUT and RETURN terminals


All models



The OUTPUT terminal (red) and RETURN terminal (black) are used for CONT (Continuity) test.

SENSE H/L and SOURCE H/L terminals

GPT-12004,  
GPT-15004 only



The SENSE H, SENSE L, SOURCE H and SOURCE L, terminals are used for GB (Ground Bond) test.


## Set Up

### Tilting the Stand

---


Horizontal position

Place the unit on a flat surface horizontally.



Tilt stand position

Gently pull the 2 stands out from the bottom and the unit will be placed in the tilt stand position.




## Line Voltage Connection and Power Up


**Background**                      The GPT-10000 accepts line voltages of 100 - 240V at 50Hz or 60Hz.

**Steps**

1. Connect the power cord to the AC Mains Input socket on the rear panel.




2. If the power cord does not have an earth ground, ensure the ground terminal is connected to an earth ground.




Ensure the power cord is connected to an earth ground. Failure could be harmful to the operator and instrument.

3. Press the Power button.



4. When the unit is powered up, the display will show the last time parameters in either MANU or AUTO test mode as shown below.




## Installing the Optional LAN/GPIB Card

**Background**                      The optional LAN/GPIB is a user-installable option. Follow the instructions below to install the GPIB card.




Before installing optional GPIB/LAN card ensure the GPT-10000 is turned off and disconnected from power.

- Steps**
1. Remove screws from the rear panel cover plate.




2. Insert the GPIB/LAN card into the opening of rear panel. Push the card gently until it is fully inserted followed by fastening the screws.

GPIB Card



LAN Card



## Workplace Precautions

---

**Background**                      The GPT-10000 is a high voltage instrument that outputs dangerous voltages. The following section describes precautions and procedures that must be followed to ensure a safe work environment.

---



### WARNING

The GPT-10000 generates voltages in excess of 5kVAC or 6kVDC. Follow all safety precautions, warnings and directions given in the following section when using the instrument.

---

1. Only technically qualified personnel should be allowed to operate the safety analyzer.
2. The operating workplace must be fully isolated, especially when the instrument is in operation. The instrument should be clearly labeled with appropriate warning signage.
3. The operator should not wear any conductive materials, jewelry, badges, or other items, such as wrist watches.
4. The operator should wear insulation gloves for high voltage protection.
5. Ensure the earth ground of the line voltage is properly grounded.
6. Ensure any devices that are adversely affected by magnetic fields are not placed near the tester.

## Operating Precautions

---

**Background**            The GPT-10000 is a high voltage instrument that outputs dangerous voltages. The following section describes precautions and procedures that must be followed to ensure that the tester is operated in a safe manner.

---



The GPT-10000 generates voltages of up to 5kVAC or 6kVDC. Follow all safety precautions, warnings and directions given in the following section when using the instrument.

---

1. Never touch the safety analyzer, lead wires, terminals, probes and other connected equipment when the tester is testing.
2. Do not turn the safety analyzer on and off quickly or repeatedly. When turning the power off, please allow a few moments before turning the power back on. This will allow the protection circuits to properly initialize.

Do not turn the power off when a test is running, unless in an emergency.

3. Only use those test leads supplied with the instrument. Leads with inappropriate gauges can be dangerous to both the operator and the instrument.  
For GB testing, never use the Sense leads on the SOURCE terminals.
4. Do not short the HIGH VOLTAGE terminal with ground. Doing so could charge the chassis to dangerously high voltages.

5. Ensure the earth ground of the line voltage is properly grounded.
6. Only connect the test leads to the HIGH VOLTAGE/SOURCE H/SENSE H terminals before the start of a test. Keep the test leads disconnected at all other times.
7. Always press the STOP button when pausing testing.
8. Do not leave the safety analyzer unattended. Always turn the power off when leaving the testing area.
9. When remotely controlling the safety analyzer, ensure adequate safety measures are in place to prevent:
  - Inadvertent output of the test voltage.
  - Accidental contact with the instrument during testing. Ensure that the instrument and DUT are fully isolated when the instrument is remotely controlled.
10. Ensure an adequate discharge time for the DUT.

When DCW or IR tests are performed, the DUT, test leads and probes become highly charged. The GPT-10000 has discharge circuitry to discharge the DUT after each test. The time required for a DUT to discharge depends on the DUT and test voltage.

Never disconnect the safety analyzer before a discharge is completed.

## Basic Safety Checks

---

Background                      The GPT-10000 is a high voltage device and as such, daily safety checks should be made to ensure safe operation.

---

1. Ensure all test leads are not broken and are free from defects such as cracks or splitting.
  2. Ensure the safety analyzer is always connected to an earth ground.
  3. Test the safety analyzer operation with a low voltage/current output:  
Ensure the safety analyzer generates a FAIL judgment when the HIGH VOLTAGE and RETURN terminals are shorted (using the lowest voltage/current as the testing parameters).
- 



Do not use high voltages/currents when the HIGH VOLTAGE and RETURN terminals are shorted. It may result in damage to the instrument.

---



# O PERATION

---

<b>Menu Tree</b> .....	<b>31</b>
Menu Tree Overview .....	32
<b>Test Lead Connection</b> .....	<b>36</b>
ACW, DCW, IR Connection.....	36
GB Connection.....	37
CONT Connection.....	38
<b>Manual Tests</b> .....	<b>39</b>
Setting the Test Function.....	41
Choose/Recall a Manual Test Number.....	42
Creating a MANU Test File Name.....	43
Setting the Upper and Lower Limits .....	44
Setting the Test Time .....	46
Setting the Ramp Up Time.....	48
Setting the Ramp Down Time .....	50
Setting the Test Voltage or Test Current .....	52
Setting the Test Frequency .....	54
Setting a Reference Value.....	55
Setting an Initial Voltage .....	56
Setting the Wait Time .....	58
Setting the ARC Function.....	60
Setting MAX HOLD.....	63
Setting PASS HOLD.....	64
Setting IR Mode .....	65
Setting GND OFFSET .....	67
Setting GB Contact .....	69
Zero Check for the Test Leads.....	71
Setting the Grounding Mode.....	74
Setting Contact Check.....	79
Setting IR Mode Filter.....	81


Screenshot Hardcopy.....	83
Running a MANU Test.....	85
PASS / FAIL MANU Test.....	90
<b>Special MANU Test Mode (000) .....</b>	<b>95</b>
<b>Sweep Function.....</b>	<b>97</b>
<b>Automatic Tests .....</b>	<b>100</b>
Choose/Recall an AUTO Test.....	101
Creating an AUTO Test File Name.....	102
Adding a Step to the AUTO Test .....	103
Continuous AUTO Tests .....	105
AUTO Test Page Editing .....	107
Running an Automatic Test.....	113
Automatic Test Results.....	119



## Menu Tree Overview

**MANU Mode**      MANU mode is used to create and/or execute a single test. Only under MANU mode can parameters be edited for each manual test.

MANU mode



**AUTO Mode**      AUTO mode indicates that the tester is automatic, which consists of a sequential AUTO test of up to 10 MANU steps. Also, several groups of AUTO tests can be further interconnected for an advanced AUTO test.

AUTO mode

AUTO: 001	AUTO_NAME				READY
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C
026	IR	0.050kV	49.99GΩ	001.0MΩ	P.C/F.C

The screenshot shows the AUTO mode interface with a table of test steps. On the right, there are four arrow keys (up, down, left, right) and a 'PAGE 1/3' indicator.

**SYSTEM Mode**

System mode covers the Display Set, Buzzer, Interface, Control, System Time, Data Initialize, Information, Statistics, USB Disk and CONTACT CHK settings. These settings are system-wide and applied to both MANU and AUTO tests.


**SYSTEM mode**




**READY Status (Yellow Color)**

When the tester is in READY status of MANU or AUTO test, it is ready to begin testing. Pressing the START button will begin testing and put the tester into TEST status. Pressing the AUTO key will change from MANU - READY status to AUTO - READY status and vice versa.

**READY status in MANU test**



**READY status in AUTO test**







## Test Lead Connection

This section describes how to connect the GPT-10000 to a DUT for withstanding, insulation resistance, ground bond as well as continuity testing.


### ACW, DCW, IR Connection

---

#### Background


ACW, DCW and IR tests use the HIGH VOLTAGE terminal and RETURN terminal with the GHT-115 test leads.

#### ACW, DCW, IR Connection



#### Steps

1. Turn the power off on the safety analyzer.
2. Connect the high voltage test lead (red) to the HIGH VOLTAGE terminal and screw firmly into place.
3. Connect the return test lead (white) into the RETURN terminal and screw the protector bar into place, as shown below.






## GB Connection

### Background


GB tests use the SENSE H/L and SOURCE H/L terminals with the GTL-215 test leads.

### GB Connection



### Steps

1. Turn the power off on the safety analyzer.
2. Connect the Sense H lead to the SENSE H terminal.
3. Connect the Sense L lead to the SENSE L terminal.
4. Connect the Source H lead to the SOURCE H terminal.
5. Connect the Source L lead to the SOURCE L terminal.




## CONT Connection

Background

CONT tests use the OUTPUT and RETURN terminals with the GTL-115 test leads.


CONT Connection




Steps

1. Turn the power off on the safety analyzer.
2. Connect the OUTPUT test lead (red) to the OUTPUT terminal.
3. Connect the RETURN test lead (black) into the RETURN terminal and screw the protector bar into place, as shown below.

OUTPUT Terminal



RETURN Terminal



## Manual Tests

This section describes how to create, edit and run a *single* ACW, DCW, IR, GB and CONT manual tests. Each Manual setting described in this chapter *only applies to the selected* manual test – *no other manual tests are affected*.


Each manual test can be stored/recalled to/from one of 100 memory locations. Each stored manual test can be used as a test step when creating an AUTO test (page 97).

- Setting the Test Function → from page 41.
- Choose/Recall a Manual Test Number → from page 42.
- Creating a MANU Test File Name → from page 43.
- Setting the Upper and Lower Limits → from page 44.
- Setting the Test Time → from page 46.
- Setting the Ramp Up Time → from page 48.
- Setting the Ramp Down Time → from page 50.
- Setting the Test Voltage or Test Current → from page 52.
- Setting the Test Frequency → from page 54.
- Setting a Reference Value → from page 55.
- Setting an Initial Voltage → from page 56.
- Setting the Wait Time → from page 58.
- Setting the ARC Function → from page 60.
- Setting MAX HOLD → from page 63.
- Setting PASS HOLD → from page 64.
- Setting IR Mode → from page 65.
- Setting GND OFFSET → from page 67.
- Setting GB Contact → from page 69.
- Zero Check for the Test Leads → from page 71.
- Setting the Grounding Mode → from page 74.
- Setting Contact Check → from page 79.
- Setting IRMode Filter → from page 81.
- Screenshot Hardcopy → from page 81.
- Running a MANU Test → from page 85.
- PASS / FAIL MANU Test → from page 90.
- Special MANU Test Mode (000) → from page 95.

- Sweep Function → from page 97.

## Setting the Test Function


**Background** There are five test functions, AC Withstand, DC Withstand, Insulation Resistance, Ground Bond and Continuity tests.

- Steps**
1. If the tester is in AUTO or SYSTEM mode, press the MANUAL key to put the tester into MANU mode. 
  2. To choose the test function, press the ACW, DCW, IR, GB or CONT key on the front panel.



3. The key of selected test function is lit, and the test function selected is shown on the upper-left corner of the display.


Selected Test Function



## Choose/Recall a Manual Test Number


**Background** ACW, DCW, IR, GB and CONT tests can only be created and edited in the MANU mode. MANU number 001 to 100 can be saved and thus be loaded when editing/creating a MANU test or AUTO test. MANU number 000 is a special mode. See page 95 for details on the special mode.

- Steps**
1. If the tester is in AUTO or SYSTEM mode, simply press the **MANUAL** key to switch to MANU mode.
  2. Use the scroll wheel to choose the MANU number.
- MANU # 001~100  
(MANU# 000 is a special mode)



 **Note**

Manual number can only be selected or recalled when the “READY” status shows on the screen. If the “FAIL” status appears, it is required to press STOP key first before selecting or recalling procedure.



## Creating a MANU Test File Name


**Background** Each manual test can have a user-defined name (default: MANU\_NAME) up to 10 characters long. See the available list of characters below.

### Character List

0	1	2	3	4	5	6	7	8	9	_
A	B	C	D	E	F	G	H	I	J	K
L	M	N	O	P	Q	R	S	T	U	V
W	X	Y	Z	a	b	c	d	e	f	g
h	i	j	k	l	m	n	o	p	q	r
s	t	u	v	w	x	y	z			

### Steps

1. Press the UP / DOWN arrow soft-keys to bring the cursor to the MANU\_NAME (default name) field. The characters table will appear in the right hand accordingly.





2. Use the scroll wheel to scroll through the available characters.
3. Press the LEFT / RIGHT arrow soft-keys to move the cursor to the next character.
4. The MANU test file name is set when the cursor is moved to another setting.




## Setting the Upper and Lower Limits

**Background** There is both a LOW and HI judgment setting. When the measured value is below the LOW SET setting, the test will be judged as FAIL. When the value exceeds the HI SET setting the test will be judged as FAIL. Any measurement between the LOW SET and HI SET setting is judged as PASS. The LOW SET limit cannot be made greater than the HI SET limit.

- Steps**
1. Press the UP / DOWN arrow soft-keys to bring the cursor to the HI SET setting. 




2. Use the scroll wheel to set the HI SET limit. 

ACW (HI)	001uA~42.00mA (GPT-12XXX)
	001uA~110.0mA (GPT-15XXX)
DCW (HI)	001uA~11.00mA (GPT-12XXX)
	001uA~21.00mA (GPT-15XXX)
IR (HI)	000.2MΩ~50.00GΩ, OFF
GB (HI)	000.1mΩ~650.0mΩ
CONT (HI)	00.01Ω~80.00Ω



- Press the UP / DOWN arrow soft-keys to bring the cursor to the LOW SET setting.



- Use the scroll wheel to set the LOW SET limit.



ACW (LOW)	000uA~41.99mA (GPT-12XXX)
	000uA~109.9mA (GPT-15XXX)
DCW (LOW)	000uA~10.99mA (GPT-12XXX)
	001uA~20.99mA (GPT-15XXX)
IR (LOW)	000.1MΩ~49.99GΩ
GB (LOW)	000.0mΩ~649.9mΩ
CONT (LOW)	00.00Ω~79.99Ω



\*Please note that the resolution of the measured value depends on the resolution of HI SET setting.



The LOW SET setting is limited by the HI SET setting. The LOW SET limit cannot be greater than the HI SET limit.

When setting the current, be aware that a maximum of 200VA can be set for ACW and 50W for DCW, respectively in terms of GPT-12XXX series.

As for GPT-15XXX series, a maximum of 500VA can be set for ACW and 100W for DCW, respectively.


## Setting the Test Time

### Background

This setting is used to set the test time for a test. The test time determines how long the test voltage or current is applied to the DUT. This test time does not include RAMP UP time or RAMP DOWN time (note: GB and CONT do not have RAMP UP or RAMP DOWN). The test time can be set from 0.3 seconds to 999.9 seconds for ACW, DCW, IR, GB and CONT, with a resolution of 0.1 seconds for all modes. Also, the test time can be turned off when using the ACW or DCW test functions.


Each test has a RAMP UP and RAMP DOWN time (except GB and CONT), respectively. Refer to page 48 & 50 for more details.

### Output Voltage Timing Chart (Resistive load)



### Steps

1. Press the UP / DOWN arrow soft-keys to bring the cursor to the TEST TIME setting.



- Use the scroll wheel to set the TEST TIMER value.



ACW	OFF, 000.3s~999.9s
DCW	OFF, 000.3s~999.9s
IR	000.3s~999.9s
GB	000.3s~999.9s
CONT	000.3s~999.9s




Note

With the ACW test function, when the test current is beyond 30mA, the Ramp Up Time + Test Time cannot exceed 240 seconds. At this current level, the tester also needs to pause after a test for a time equal to or greater than the output time.

Turn Off Test Time

When in either ACW or DCW test, the TEST TIME can be turned off, which means the test without test time will last infinitely until FAIL judgment occurs.

Identical with the regular setting for TEST TIME, turn off the timer by using the scroll wheel to set OFF for TEST TIME value.




## Setting the Ramp Up Time

### Background

The Ramp Up time is the total time taken for the tester to reach the test voltage level. The Ramp Up time can be set from 000.1 to 999.9 seconds. The Ramp Up time is only applicable for ACW, DCW and IR tests.

### Output Voltage Timing Chart (Resistive load)



### Steps

1. Press the UP / DOWN arrow soft-keys to bring the cursor to the RAMP TIME setting.



RAMP TIME cursor




2. Use the scroll wheel to set the RAMP TIME value.



ACW	000.1s~999.9s
DCW	000.1s~999.9s
IR	000.1s~999.9s

Ramp Time  
Duration  
Indicator

After pressing START to begin a test with set RAMP TIME, a section at the lower right corner of display shows the counting duration of RAMP TIME, which will run to the set value followed by the test time. See the screenshot shown below.




RAMP TIME duration indicator

## Setting the Ramp Down Time

### Background

The Ramp Down time is the time taken for the DUT to discharge the test voltage level. The Ramp Down time can be set from 000.0 to 999.9 seconds. The Ramp DOWN time is only applicable for ACW, DCW and IR tests.

### Output Voltage Timing Chart (Resistive load)



### Steps

1. Press the PAGE soft-key to move to the 2/3 page where RAMP DOWN setting appears for ACW and DCW.

**PAGE**  
2 / 3

As for IR test, the RAMP DOWN setting shows in the 2/2 page.

**PAGE**  
2 / 2

2. Press the UP / DOWN arrow soft-keys to bring the cursor to the RAMP DOWN setting.



RAMP DOWN cursor




- Use the scroll wheel to set the RAMP DOWN value.



ACW            000.0s~999.9s  
 DCW           000.0s~999.9s  
 IR             000.0s~999.9s

Ramp Down  
 Duration  
 Indicator


After the set TEST TIME is fully completed, a section at the lower right corner of display shows the counting duration of RAMP DOWN, which will run to the set value by user. See the screenshot shown below.





RAMP DOWN duration indicator

## Setting the Test Voltage or Test Current

**Background** The test voltage can be set from 0.050kV to 5.1kV for ACW, 0.050kV to 6.1kV for DCW and 0.050 to 1.2kV for IR (50V steps\*). For GB tests the test current can be set from 3A to 33A. As for CONT test, the test current is fixedly set at the default value of 100mA.

- Steps**
1. Press the UP / DOWN arrow soft-keys to bring the cursor to the voltage or ampere setting depending on selected test function. 



2. Use the scroll wheel to set the test voltage or ampere level. 

ACW	0.050kV ~ 5.1kV <sup>1</sup>
DCW	0.050kV ~ 6.1kV <sup>2</sup>
IR	0.05kV ~ 1.2kV (50V steps)
GB	3.00A ~ 33.00A
CONT	100mA <sup>3</sup>



<sup>1</sup> At least 0.3 seconds is needed to reach a set voltage of 50V/10mA.

<sup>2</sup> At least 0.3 seconds is needed to reach a set voltage of 50V/2mA.

<sup>3</sup> Test current for CONT is fixed at 100mA

---



Note


When setting the current, be aware that a maximum of 200VA can be set for ACW and 50W for DCW, respectively in terms of GPT-12XXX series.


As for GPT-15XXX series, a maximum of 500VA can be set for ACW and 100W for DCW, respectively.


The ground bond voltage (GBV) is calculated as the HI SET limit x Test Current.



## Setting the Test Frequency

**Background** A test frequency of 60Hz or 50Hz can be set, regardless of the input line voltage. The test frequency setting only applies to ACW and GB tests.


 **Note** The test frequency can only be set for ACW or GB tests.


**Steps** 1. Press the PAGE soft-key to move to the 2/3 page where **FREQ** setting appears for ACW. 

As for GB test, the **FREQ** setting shows in the 1/2 page directly. 

2. Press the UP / DOWN arrow soft-keys to bring the cursor to the **FREQ** setting.  

FREQ setting cursor




3. Use the scroll wheel to set the test frequency. 


ACW, GB 50Hz, 60Hz


## Setting a Reference Value


**Background**                      The REF VALUE acts as an offset. The REF VALUE is subtracted from the measured current (ACW, DCW) or measured resistance (IR, GB, CONT).


**Steps**


1. Press the PAGE soft-key to move to the 3/3 page where REF VALUE setting appears for ACW and DCW. 

As for IR and GB, the REF VALUE setting shows in the 2/2 page. 

The REF VALUE setting appears in the 1/1 page directly for CONT. 

2. Press the UP / DOWN arrow soft-keys to bring the cursor to the REF VALUE setting. 



3. Use the scroll wheel to set the REF value. 

ACW	000uA~ 41.99mA (GPT-12XXX) *HI SET + REF value ≤ 42.00mA 000uA~ 109.9mA (GPT-15XXX) *HI SET+REF value ≤ 110.0mA
DCW	000uA~ 10.99mA (GPT-12XXX) *HI SET + REF value ≤ 11.00mA 000uA~ 20.99mA (GPT-15XXX) *HI SET+REF value ≤ 21.00mA
IR	000.0MΩ~50.00GΩ
GB	000.0mΩ~650.0mΩ *ISET x (HI SET + REF value) is no greater than 7.2V
CONT	00.00Ω~80.00Ω *ISET(100mA) x (HI SET + REF value) is no greater than 8V



Note

For IR test, a reference value of tester can be automatically created via the GND OFFSET function. See page 67 for details.

For GB and CONT tests, a reference value of test lead can be automatically created via the ZERO CHECK function. See page 71 for details.

## Setting an Initial Voltage

### Background

In essence, the test voltage for both ACW and DCW will gradually and linearly rise up, from zero, to the target set voltage in accord with the set RAMP TIME ahead of the TEST TIME.

Nevertheless, under certain circumstances, user may have preferences on the percentage of starting test voltage. Therefore, the INIT VOLTAGE provides another alternative for different applications on user side.

It is easy to set a preferred percentage of the test voltage in the INIT VOLTAGE setting and the starting test voltage will commence from the value corresponding to the set percentage relative to the target test voltage.



Note

INIT VOLTAGE setting is only applicable to both ACW and DCW tests.

Steps

1. Press the PAGE soft-key to move to the 3/3 page where the INIT VOLTAGE setting appears for ACW and DCW.



2. Press the UP / DOWN arrow soft-keys to bring the cursor to the INIT VOLTAGE setting.



INIT VOLTAGE cursor

3. Use the scroll wheel to set the percentage of INIT VOLTAGE.



INIT VOLTAGE 000% ~ 099%

## Setting the Wait Time

### Background

The Wait Time refers to the pending time before FAIL judgment appears. By default, FAIL judgment appears when Test Time has reached 0.3 second at the earliest manner. However, when user sets 1.0 second for Wait Time on the tester with 0.5 second of Ramp Up time and 1.0 second of Test Time, the FAIL judgment will be shown when Test Time has reached 0.5 second. In short, Wait Time is the pending duration which dominates the priority over both Ramp UP time and Test Time in terms of timing of FAIL judgment.

The WAIT TIME is only applicable for ACW, DCW and IR tests.

### Steps

1. Press the PAGE soft-key to move to the 2/3 page where WAIT TIME setting appears for ACW and DCW.



As for IR test, the WAIT TIME setting shows in the 1/2 page.



2. Press the UP / DOWN arrow soft-keys to bring the cursor to the WAIT TIME setting.



WAIT TIME cursor




- Use the scroll wheel to set the WAIT TIME value.



ACW            000.0s~999.9s  
 DCW           000.0s~999.9s  
 IR             000.0s~999.9s

**Wait Time Indicator**

While the WAIT TIME is set, the indicator of WAIT TIME will be shown on the display in the set duration during a test progress for clear identification for user.



WAIT TIME indicator

 **Note**

During the Wait Time, if test voltage is beyond the set voltage by 1.1 times, test will be stopped immediately in case of overvoltage issue.

During the Wait Time, if test current is beyond the maximum currents of each unit as follows, test will be stopped immediately in case of overcurrent issue.

	GPT-12000	GPT-15000
ACW	40mA	100mA
DCW	10mA	20mA

## Setting the ARC Function

### Background

ARC detection, otherwise known as flashover detection, detects fast voltage or current transients that are not normally detected. Arcing is usually an indicator of poor withstanding insulation, electrode gaps or other insulating problems that cause temporary spikes in current or voltage during ACW and DCW testing.


There are three ARC detection settings: OFF, ON & CONT, ON & STOP.

The ON & CONT setting will detect arcs over the ARC current level and continue the test, the ON & STOP setting will stop the test when an arc is detected.

ARC mode settings only apply to both ACW and DCW tests.

### Steps

1. Press the UP / DOWN arrow soft-keys to bring the cursor to the ARC FUNC setting.




2. Use the scroll wheel to set the ARC modes setting.



ARC MODES: OFF, ON & CONT, ON & STOP



3. If the ARC MODE was set to either ON & CONT, or ON & STOP, the ARC current level can be edited. Press the DOWN arrow soft-key to bring the cursor to the ARC SET setting field.



4. Use the scroll wheel to edit the ARC SET level.



ACW	1.000mA~80.00mA (GPT-12XXX)
	1.000mA~200.0mA (GPT-15XXX)
DCW	1.000mA~20.00mA (GPT-12XXX)
	1.000mA~40.00mA (GPT-15XXX)




Note

The ARC SET level should be greater than or equal to the HI SET value.

5. If the ARC MODE was set to either ON & CONT, or ON & STOP, the ARC speed, which indicates the threshold for width of detected ARC, can be edited. Press the PAGE soft-key to move to the 2/3 page where ARC SPEED setting appears for ACW and DCW.



- Press the UP / DOWN arrow soft-keys to bring the cursor to the ARC SPEED setting field.



- Use the scroll wheel to select the ARC SPEED modes.



ARC SPEED	FAST	Threshold for the narrowest width of detected arc, which is the most sensitive manner.
	NORMAL	Threshold for the general width of detected arc.
	SLOW	Threshold for the widest width of detected arc, which is the manner of high tolerance.

## Setting MAX HOLD

### Background

The MAX HOLD setting will hold the maximum current measured in the ACW and DCW tests or the maximum resistance measured in the IR and GB tests.

For instance, when running an IR test with 120 seconds of test time and MAX HOLD enabled, the highest resistance measured in the 30 seconds of the test time will be retained on display until the next largest value. If there is no further maximum resistance occurred, the value measured in 30 seconds will be remained till the end of the test of 120 seconds.

### Steps

1. Press the PAGE soft-key to move to the 2/3 page where MAX HOLD setting appears for ACW and DCW.

PAGE  
2 / 3

As for IR and GB, the MAX HOLD setting shows in the 2/2 page.

PAGE  
2 / 2

2. Press the UP / DOWN arrow soft-keys to bring the cursor to the MAX HOLD setting.



MAX HOLD cursor



- Use the scroll wheel to set MAX HOLD.



MAX HOLD      OFF, ON

## Setting PASS HOLD

---

**Background**      The PASS HOLD setting refers to the holding duration after PASS judgment is shown on the display. When the PASS HOLD setting is set, a PASS judgment is held until the set duration is fully reached.

---



**Note**

The PASS HOLD setting only applies to MANU tests. This setting is ignored when running AUTO test.

---

### Steps

- Press the PAGE soft-key to move to the 3/3 page where PASS HOLD setting appears for ACW.



And it is the 2/3 page where PASS HOLD setting appears for DCW.



As for IR and GB, the PASS HOLD setting shows in the 2/2 page.




The PASS HOLD setting appears in the 1/1 page directly for CONT.



- Press the UP / DOWN arrow soft-keys to bring the cursor to the PASS HOLD setting.





- Use the scroll wheel to set PASS HOLD duration.



PASS HOLD 000.0s ~ 999.9s, ON



- The STOP key can be pressed at any time in the set duration of PASS HOLD to promptly halt the set PASS HOLD duration. In short, user can stop, if necessary, the duration of PASS HOLD any time.
- When ON is selected, the duration of PASS HOLD will remain indefinitely until the STOP key is further pressed.

## Setting IR Mode

### Background

The IR MODE setting, which contains three options, STOP ON FAIL, STOP ON PASS, TIMER, only applies to IR test.

When IR MODE is set to STOP ON FAIL, the tester will show the FAIL judgment, if available, in the 0.3 second of test time at the earliest manner, regardless of the set test time.

When set to PASS ON FAIL, the tester will show the PASS judgment, if available, in the 0.3

second of test time at the earliest manner, regardless of the set test time.

The TIMER mode will run a test in a full course completely in accordance with the set test time, whether the final judgment is PASS or FAIL.



Note


If the DUT is under the situation of abnormal measurement, e.g., short circuit, the FAIL judgment of SHORT warning, though TIMER is set, will appear in the early manner regardless of the set test time.

Steps

1. Press the PAGE soft-key to move to the 2/2 page where IR MODE setting appears for IR test.



2. Press the UP / DOWN arrow soft-keys to bring the cursor to the IR MODE setting.



IR MODE cursor

3. Use the scroll wheel to set the IR MODE.



IR MODE      STOP ON FAIL  
                  STOP ON PASS  
                  TIMER

## Setting GND OFFSET

**Background** The GND OFFSET is used to determine the offset resistance of the tester. When a GND OFFSET is performed, the reference is automatically set to the measured resistance.



**Note**

GND OFFSET setting is only applicable to IR test.

**Steps**

1. Press the PAGE soft-key to move to the 2/2 page where GND OFFSET setting appears for IR testing.

**PAGE**  
2 / 2

2. Press the UP / DOWN arrow soft-keys to bring the cursor to the GND OFFSET setting. When selecting ON, the ZERO CHECK indicator will be shown on the display.



GND OFFSET cursor

ZERO CHECK indicator

- Press the START button to perform the GND OFFSET. The resistance of the tester, after the GND OFFSET has finished, will be added into the REF VALUE field as the display shown below.

**START**



Resistance of the tester



## Setting GB Contact

**Background** Basically, GB test has no ramp up time and thus starts from the set test time by user directly. However, due to some cases where a buffer time before test time is in fact required for GB test, e.g., in conveyor where DUTs are tested for GB by batches and certain buffer duration needed for test leads or jigs connecting with DUTs, the GB CONTACT setting practically allows user to apply to customized scenarios when necessary occurs.




Note

GB CONTACT setting is only applicable to GB test.

Steps

1. Press the UP / DOWN arrow soft-keys to bring the cursor to the GB CONTACT setting.



GB CONTACT cursor


2. Use the scroll wheel to set the value of GB CONTACT



GB CONTACT 000.0 s ~ 999.9 s

**GB CONTACT**  
Duration  
Indicator

After every parameter including GB CONTACT is well set, press START to begin the GB test. A section at the lower right corner of display shows the counting duration of GB CONTACT, which will run to the set value followed by the test time. See the screenshot shown below.



GB CONTACT duration indicator

## Zero Check for the Test Leads

---

**Background** The Zeroing function is used to determine the resistance of the test leads for GB and CONT tests. When a ZERO CHECK is performed, the reference is automatically set to the measured resistance of the test leads.

---




**Note**

ZERO CHECK setting is only applicable to both GB and CONT tests.

---

**Steps**

1. Short the positive and negative alligator clips as shown below.



2. Press the PAGE soft-key to move to the 2/2 page where ZERO CHECK setting appears for GB testing.


PAGE  
2 / 2

As for CONT, ZERO CHECK setting shows in the 1/1 page directly.

PAGE  
1 / 1



3. Press the UP / DOWN arrow soft-keys to bring the cursor to the ZERO CHECK setting. When selecting ON, the ZERO CHECK indicator will be shown on the display.





ZERO CHECK cursor      ZERO CHECK indicator

4. Press the START button to perform the zero check. The resistance of the test leads, after the ZERO CHECK has finished, will be added into the REF VALUE field as the display shown below.



Resistance of the test leads




Note

Remember to replace the test leads to the proper position on the DUT before testing.

**FAIL – GBI LOW**


If SOURCE H/L terminals are open or poorly connected, the FAIL – GBI LOW status will appear on the screen. Please re-check the connection of SOURCE H/L terminals again.



FAIL – GBI LOW status

**REF VALUE = 0**

Press STOP button to exit and the resistance of test leads were not properly added into the REF VALUE, which shows 000.0 mΩ as shown below. Re-check the connection of SOURCE H/L terminals and press START button again to proceed to the ZERO CHECK procedure.



REF VALUE = 0


## Setting the Grounding Mode

### Background


When GROUND MODE is set to ON, the GPT-10000 grounds the return terminal to the ground. This mode is best for DUTs that are grounded to an earth ground by their chassis, fixtures or operation environment. This mode measures the potential of the HIGH VOLTAGE terminal with respect to earth ground. This means that additional noise which leaks to earth ground will also be measured. This is the safest testing mode, though potentially not as accurate.

When GROUND MODE is set to OFF, the return terminal is floating with respect to the earth ground. This mode is for DUTs that are floating and not directly connected to an earth ground. This is more accurate than when GROUND MODE is set to ON as less noise will be measured. For this reason, this testing mode is able to measure with better stability.

ACW/DCW, GROUND MODE ON, DUT grounded




ACW/DCW, GROUND MODE OFF, DUT floating




Note

If the current value, which results from comparison between I1 and I2 current, is above 3mA, once user unexpectedly touches the DUT, the GFCI, Ground Fault Circuit Interrupter, function activates and output will be stopped immediately so that protection mechanism will be well triggered at once.


IR, GROUND MODE ON, DUT grounded




IR, GROUND MODE OFF, DUT floating



GB, GROUND MODE ON, DUT grounded




GB, GROUND MODE OFF, DUT floating





Cont., GROUND MODE ON, DUT grounded



Note

In terms of Continuity test, it is compulsory to ground the DUT and thus GROUND MODE is ON.



Warning

When GROUND MODE is set to OFF, the DUT, fixtures or connected instrumentation cannot be grounded. This will short circuit the internal circuitry during a test.

For ACW and DCW tests, if it is not known whether the DUT test setup is grounded or not, always set GROUND MODE to ON.

Only set GROUND MODE to OFF when the DUT is floating electrically.

Steps

1. Press the PAGE soft-key to move to the 2/3 page where GROUND MODE setting appears for ACW and DCW.




As for IR and GB, the GROUND MODE setting shows in the 1/2 page.



2. Press the UP / DOWN arrow soft-keys to bring the cursor to the GROUND MODE setting.






- Use the scroll wheel to set the GROUND MODE.




GROUND MODE      OFF, ON

- The GROUND MODE icon on the display changes accordingly.



GROUND MODE ON



GROUND MODE OFF



Under the IR test mode, when GROUND MODE is ON but test time is  $t < 0.5s$ , the error message “TEST TIMR<0.5s” will be shown, by which user is not able to start the IR test mode unless the test time is reset to  $> 0.5s$ . Refer to page 46 for how to set the test time manually.



## Setting Contact Check

**Background** The CONTACT CHK function is used to determine if open circuit or short circuit occurs between the test leads and DUT under the ACW, DCW and IR tests. Before activating this function, it is first required to define a reference value along with relevant thresholds, for which refer to page 169.




Note

CONTACT CHK setting is only applicable to ACW, DCW and IR test modes.

Step


1. Press the PAGE soft-key to move to the 3/3 page where CONTACT CHK setting appears for ACW, DCW and IR tests.
2. Press the UP / DOWN arrow soft-keys to bring the cursor to the CONTACT CHK and turn it ON.

PAGE  
3 / 3




CONTACT CHK ON

- After pressing the START button, the GPT-10000 unit will perform the CONTACT CHK before running a MANU test. If the measured current is lower than the reference value by user-defined percentage, the "OPEN" status appears on the screen. While the measured current is higher than the reference value by user-defined percentage, the "SHORT" status appears instead.




OPEN  
Status



OPEN Status detected

SHORT  
Status



SHORT Status detected







Note

The CONTACT CHK will be invalid when reference value is defined less than 30uA, even though CONTACT CHK is turned ON. Refer to page 170 for details of reference value learning.

## Setting IR Mode Filter

**Background**                      The filter function is used to test if unstable resistance issue occurs when capacitive load test is performed.

 **Note**                                      Filter setting is only applicable to IR mode.

- Steps**
1. Press the PAGE soft-key to move to the 3/3 page where FILTER setting appears for IR test. 
  2. Press the UP / DOWN arrow soft-keys to bring the cursor to the FILTER setting. 
  3. Use the scroll wheel to select options of FILTER setting. 
- FILTER                      OFF, LEVEL 1, LEVEL 2



FILTER Setting OFF





## Screenshot Hardcopy

---

**Background** When connecting a USB disk to the USB host port on the front panel, it is available to execute hardcopy function, which allows user to capture screenshots from unit. The saved filename to USB disk will be in .bmp format with serial number from 01 ~ 99 (LCDGET01.bmp ~ LCDGET99.bmp) within the directory GPT1X000/SCREEN.

---

- Steps**
1. Press and hold the SYSTEM key for 2 seconds, and the prompt message will be shown in the upper side describing hardcopy is ongoing.  for 2 seconds




Note

When unit is under test, the hardcopy function will be unavailable in that high voltage output will be influenced if hardcopy is underway.

---


Upper Limit of  
Filename

When the filename upper limit LCDGET99.bmp is reached while doing hardcopy action, an error message will be shown on the display.



No USB Disk

When no USB disk is connected with unit while doing hardcopy action, an error message will be shown on the display as follows.





## Running a MANU Test

---

Background                      A test can be run when the tester is in READY status.

---



Note

The tester cannot start to run a test under the following conditions:

- A protection setting has been tripped; when a protection setting has been tripped the corresponding error message is displayed on the screen. See page 249 for a comprehensive list of the all the setting errors.
  - The INTERLOCK function is ON and the Interlock key is not inserted in the signal I/O port (page 136).
  - The STOP signal has been received remotely.
  - If Double Action is ON, ensure the START button is pressed immediately after the STOP button (<0.5s).
- 



Note

When a test is running the voltage output cannot be changed, unless the test is under the special manual mode. See page 95 for details.


---

Steps                              1. Ensure the tester is in READY                      Page 33  
status for the test to come.


READY status



2. Press the START button when the tester is in the READY status. The manual test starts accordingly and the tester goes into the TEST status.




TEST status




3. The test will start by showing the ongoing ramp up time followed by the ongoing test time and the ongoing ramp down time. The test will continue until the test is finished or stopped.

## RAMP UP TIME




Ongoing RAMP UP TIME

## TEST TIME



Ongoing TEST TIME

## RAMP DOWN TIME




Ongoing RAMP DOWN TIME




Note

RAMP DOWN time only appears when user has activated it. See page 50 for details.


ACW Example




DCW Example




IR Example



GB Example




CONT Example



Stop the Test

- To stop the test at any time when it is running, press the STOP button. The test will stop immediately. When the STOP button is pressed, a judgment is not made and the tester will restore to READY status.



 Note

Do not touch any terminals, test leads or any other connections when the test is on.

## PASS / FAIL MANU Test

**Background** If the test is allowed to run to completion (the test is not stopped or a protection setting is not tripped) then the tester will judge the test as either PASS or FAIL.



**Note**


The test will be judged PASS when:

- The HI SET and LO SET limits have not been tripped during the test time.


The test will be judged FAIL when:

- Either the HI SET or LO SET limit has been tripped during the test time.
- A protection setting has been tripped during the test time. See page 249 for a list of error messages.

**PASS Judgment** 1. When the test is judged as PASS, PASS will be displayed on screen, the buzzer will sound and the PASS indicator will be lit green.




PASS Judgment



2. The tester will immediately restore back to the READY status after PASS judgment. However, if the PASS HOLD is activated, PASS judgment will persist until the set duration of PASS HOLD is fully met. Refer to page 64 for details.

In addition, pressing the STOP button during the set duration of PASS HOLD can return to READY status immediately.




Note

The START button is disabled when the buzzer is beeping.


**PASS Timing Diagrams**

The timing diagrams below show the ACW, DCW, IR, GB and CONT timing for the START status, TEST status and PASS judgment.


**ACW PASS Timing**




**DCW PASS Timing**




**IR PASS Timing**



**GB PASS Timing**




**CONT PASS Timing**



**FAIL Judgment**


1. When the test is judged as FAIL, FAIL will be displayed on screen, the buzzer will sound and the FAIL indicator will be lit red.




As soon as a test is judged FAIL, power is cut from the terminals.



FAIL Judgment




- The FAIL judgment will be held on the display until the STOP button is pressed. Pressing the STOP button will return the tester back to the READY status.




FAIL Timing Diagrams

The timing diagrams below show the ACW, DCW, IR, GB and CONT timing for the START status, TEST status and FAIL judgment.


ACW FAIL Timing




**DCW FAIL Timing**




**IR FAIL Timing**



**GB FAIL Timing**



**CONT FAIL Timing**



## Special MANU Test Mode (000)

### Special Test Mode Overview

When MANU number 000 is selected, the special test mode is activated. Under the special test mode, the voltage can be changed during a test in real time (ACW, DCW only). The test function can also be changed when in READY status, unlike under normal operation.

Separate settings can be saved under the special test mode for each of the testing functions: ACW, DCW, IR, GB and CONT. This means different test setups for ACW, DCW, IR, GB and CONT can be saved within the MANU number 000 concurrently.

### Steps

1. Choose MANU number 000 to enter the special test mode.

Page 42

2. The settings of a previous test can be loaded by pressing the corresponding soft-keys on the front panel.


For example, if you are currently in DCW mode, pressing the ACW key will load the ACW settings that were previously stored in the special manual mode.



- Set all the necessary parameters for Pages 43 ~ 74 a test and save.

Note: A different test setup can be saved for each test function (ACW, DCW, IR, GB and CONT). Below is an example of ACW function in special manual mode.

Special MANU Number 000



**Running the Test**

- In special test mode (000), tests are started and stopped in the same way as for the normal manual test mode. See page 79 for details.
- If required, the scroll wheel can be used to set the voltage level in real-time as the test is running under either ACW or DCW mode.



ACW	0.050kV ~ 5kV
DCW	0.050kV ~ 6kV

**Results**

Test judgments are the same as those for the normal manual tests. Please see the PASS/FAIL MANU Test section for details.


Page 90

## Sweep Function

### Sweep Function Overview

The GPT-10000 Series has access to the sweep mode function, which creates a graph of one of the ACW, DCW, IR, GB or CONT tests in either Manual test or the special MANU mode. The graph will plot the output voltage, current or resistance versus time. After the test has been completed, the test current, voltage or resistance at any point in time can be fetched and viewed in the graph.

Below is an example of the resultant sweep plot of a DCW test where a DC voltage is ramped up to a user-defined level until the HI SET current level has been tripped or the test time runs out.




The test items that are plotted on the sweep graph depend on the type of test that is performed.

TEST	Graph Test Items
ACW	Measured voltage, measured current (V, I)
DCW	Measured voltage, measured current (V, I)
IR	Measured voltage, measured resistance (V, R)
GB	Measured current, measured resistance (I, R)
CONT	Measured current, measured resistance (I, R)


Steps of View Sweep Graph

1. When a test has finished, press the corresponding button, e.g., DCW button for DCW test, to view the result of the sweep in an intuitive graph.



Graph Test Items:		
TEST	GREEN	BLUE
ACW	Measured voltage	Measured current
DCW	Measured voltage	Measured current
IR	Measured voltage	Measured resistance
GB	Measured current	Measured resistance
CONT	Measured current	Measured resistance

DCW Sweep Graph Example



The values of point by cursor

- Use the scroll wheel to move the cursor on the time axis (red highlight in x-axis). The measured values on the green and blue lines at that particular point in time are shown within the table below (orange highlight). Also, the test function along with the test number is clearly shown within the table. The HI in y-axis (yellow highlight) along with the dotted line in red indicates the HI SET value and the point of tripped time.



Turn Pages

- The resultant graph will be over 1 page when test time is beyond 650 steps (the interval of each step is 0.1s). In this case, press PAGE soft-key to switch among each page for full graphs.

**PAGE**  
01/02

**PAGE**  
02/02

Fast-forward


- Press the MOVE soft-key before moving the cursor to fast-forward steps by 10 times (x 10), which is practical when steps are many. Press the MOVE soft-key again to return back to the normal "x 1" speed.

**MOVE**  
x 1

**MOVE**  
x 10

Exit the Results Graph

To exit the sweep graph, press the corresponding button again to return back to Manual test.



## Automatic Tests

This section describes how to create, edit and run automatic tests. Automatic tests allow you to link up to 10 different MANU tests and run them sequentially within a single AUTO test. Each stored MANU test is used as a test step when creating an AUTO test. In addition, up to 5 groups of AUTO test can be interconnected together to present an ever-advanced AUTO tests.

- Choose/Recall an AUTO Test → from page 101
- Creating an AUTO Test File Name → from page 102
- Adding a Step to the AUTO Test → from page 103
- Continuous AUTO Tests → from page 105
- AUTO Test Page Editing → from page 107
- Running an Automatic Test → from page 113
- Automatic Test Results → from page 119

Before operating the GPT-10000 please read the safety precautions as outlined in the Set Up chapter on page 22.



## Choose/Recall an AUTO Test

**Background**                      The tester must first be put into AUTO mode to create or run automatic tests.

Up to 100 automatic tests can be saved or recalled.

**Steps**

1. If the tester is in MANU or SYSTEM mode, press the AUTO key on the front panel. This will put the tester into Auto mode.



2. After entering the AUTO mode, first use the scroll wheel to choose the AUTO number.




AUTO #    001~100

AUTO number cursor      READY status

AUTO-001		AUTO_NAME				READY	↑
MANU STEP	TEST MODE	V/I SETTING	H/I SETTING	LOW SETTING	STEP HOLD	↓	
							←
							→

**Note**

The AUTO number can only be chosen in READY status. If the status is either PASS or FAIL, press the STOP button to restore back to the READY status.



## Creating an AUTO Test File Name

### Background

Each automatic test can have a user-defined test file name (Default: AUTO\_NAME) up to 10 characters long. See the character list below for the allowed characters.

### Character List

0	1	2	3	4	5	6	7	8	9	
A	B	C	D	E	F	G	H	I	J	K
L	M	N	O	P	Q	R	S	T	U	V
W	X	Y	Z	a	b	c	d	e	f	g
h	i	j	k	l	m	n	o	p	q	r
s	t	u	v	w	x	y	z			

### Steps

1. Use the LEFT/RIGHT arrow soft-keys to move the cursor to the AUTO\_NAME (default name) field. The characters table will appear in the right hand accordingly.



AUTO name cursor      Character Table

AUTO-001	AUTO_NAME	READY	
MANU	TEST	0 1 2 3 4 5 6 7 8 9 A B C D E F G H I J	STEP
STEP	MODE	K L M N O P Q R S T U V W X Y Z a b c d	HOLD
		e f g h i j k l m n o p q r s t u v w x	
		y z	
			↑
			↓
			←
			→

2. Use the scroll wheel to scroll through the available characters.
3. Press the LEFT / RIGHT arrow soft-keys to move the cursor to the next character.





- Further press the DOWN arrow key followed by using the scroll wheel to choose another MANU STEP number to add to the automatic test.



MANU STEP number cursor (2nd)

AUTO-001		AUTO_NAME				READY
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C	↑
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C	↓
						SKIP
						DEL.
						STEP HOLD

- Repeat the previous steps for any other MANU tests that you wish to add to the automatic test.

## Continuous AUTO Tests

**Background** As mentioned previously, up to 10 MANU steps can be grouped to form an AUTO test and user can designate each step from MANU step number 1 to 100 for an AUTO test. However, it is available to interconnect different AUTO tests together to present a series of AUTO tests.

- Steps**
1. Follow the steps of “Adding a Step to the AUTO Test” in page 103 first. See the example below where 5 MANU steps have been added into the AUTO-001 group.

AUTO-001		AUTO_NAME				READY	↑
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD	↓	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.H		
002	ACW	0.100kV	1.000mA	000 uA	P.H/F.C		
005	IR	0.050kV	066.8MΩ	000.1MΩ	P.C/F.S		
010	ACW	0.200kV	2.000mA	000 uA	P.C/F.C	SKIP	
006	DCW	0.500kV	1.500mA	000 uA	P.H/F.S		
						DEL.	
						STEP HOLD	

2. Press the DOWN arrow key to bring the cursor to the next MANU STEP field followed by using the scroll wheel to choose CON from the MANU STEP options.



AUTO-001		AUTO_NAME				READY	↑
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD	↓	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.H		
002	ACW	0.100kV	1.000mA	000 uA	P.H/F.C		
005	IR	0.050kV	066.8MΩ	000.1MΩ	P.C/F.S		
010	ACW	0.200kV	2.000mA	000 uA	P.C/F.C	SKIP	
006	DCW	0.500kV	1.500mA	000 uA	P.H/F.S		
CON						DEL.	
						STEP HOLD	


CON is chosen from MENU STEP

- Repeat the step 1 to form another group of AUTO-002 test as the following display shown.

AUTO-002 comprising 3 MANU steps

AUTO-002		AUTO_NAME				READY	↑
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD	↓	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.H		
002	ACW	0.100kV	1.000mA	000 uA	P.H/F.C		
026	IR	0.150kV	069.8MΩ	000.6MΩ	P.C/F.S		
							SKIP
							DEL.
							STEP HOLD

- After the previous steps, return to the AUTO-001 test page followed by pressing START button for automatic test. The AUTO-002 test will ensue from the end of AUTO-001 test. The continuous AUTO tests are thus established perfectly.



 Note

- Up to 5 groups of AUTO tests can be interconnected. The former 4 groups of AUTO tests, due to CON occupation, owns up to 9 MANU steps, respectively, whereas the last group can own up to 10 MANU steps. Thus, it is 46 MANU steps at the maximum for a continuously interconnected AUTO test.
- The interconnected groups of AUTO test are limited in serial numbers. That is to say, when initializing from AUTO-005, for example, the next group will be definitely AUTO-006 followed by AUTO-007, if available, and so forth up to 5 groups.

## AUTO Test Page Editing

**Background** The AUTO test page contains each added MANU step (up to 10 steps) in order on the list along with the corresponding settings including Test Mode, Test V/I Setting, HI & LOW Settings as well as Step Hold action, respectively. Each step can be skipped, deleted or edited for its Step Hold actions.

**Skip a MANU STEP**

1. Press the UP / DOWN arrow soft-keys to bring the cursor to the target MANU STEP on list.



Target MANU STEP cursor

AUTO-001		AUTO_NAME				READY
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C	
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C	
						SKIP
						DEL.
						STEP HOLD

2. Press the SKIP soft-key.
3. The designated MANU STEP will be grayed out in color of setting.



The gray-out MANU STEP

AUTO-001		AUTO_NAME				READY	↑
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD	↓	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C		
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C		
							SKIP
							DEL.
							STEP HOLD



Note

When the AUTO test is run next time, the grayed-out steps will be simply skipped.

Delete a MANU STEP

1. Press the UP / DOWN arrow soft-keys to bring the cursor to the target MANU STEP on list.



Target MANU STEP cursor

AUTO-001		AUTO_NAME				READY	↑
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD	↓	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C		
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C		
							SKIP
							DEL.
							STEP HOLD

2. Press the DEL. soft-key.
3. The designated MANU STEP will be deleted from the list.









STEP HOLD cursor

AUTO-001		AUTO_NAME				READY	
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD		
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C		↑
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C		↓
							SKIP
							DEL.
							STEP HOLD



- Use the scroll wheel to choose the options from STEP HOLD setting as listed below.



- P.H/F.H** Step which is judged PASS will be held until START button pressed by user for next step. Step which is judged FAIL will be held until START button pressed by user for next step.
- P.H/F.S** Step which is judged PASS will be held until START button pressed by user for next step. The AUTO test will be immediately stopped when Step is judged FAIL.
- P.H/F.C** Step which is judged PASS will be held until START button pressed by user for next step. The AUTO test will automatically continue although the step is judged FAIL.
- P.C/F.H** The AUTO test will automatically continue when the step is judged PASS. Step which is judged FAIL will be held until START button pressed by user for next step.

- P.C/F.S The AUTO test will automatically continue when the step is judged PASS. The AUTO test will be immediately stopped when step is judged FAIL.
- P.C/F.C The AUTO test will automatically continue when the step is judged PASS. The AUTO test will automatically continue although the step is judged FAIL.
- 0.1 ~ 999.9 s The step will be held for specified seconds (0.1 ~ 999.9s) until the next step, regardless of PASS or FAIL judgment.
- P.C/F.C  Literally it works identically with the P.C/F.C setting above. However, this setting works on the basis of PREVOLTAGE framework. Refer to the section below on page 112 for details of PREVOLTAGE.
- P.C/F.S  Literally it works identically with the P.C/F.S setting above. However, this setting works on the basis of PREVOLTAGE framework. Refer to the section below on page 112 for details of PREVOLTAGE.

## PREVOLTAGE

It indicates that MANU steps set with the options (P.C/F.C , P.C/F.S ) within an AUTO test will be executed in a continuous manner without voltage zeroing. See the conditions below:

1. The PREVOLTAGE of P.C/F.C and P.C/F.S options apply to ACW, DCW and IR test modes only. And only the same mode in continuous MANU steps can constitute the PREVOLTAGE test. For example, the step 1 is IR mode and the step 2 is IR mode as well.
2. When applying INIT VOLTAGE function to several MANU steps within an AUTO test, only the 1st MANU step will be executed.
3. The contact status should be identical among each MANU step. When CONTACT CHK is ON for several MANU steps within an AUTO test, only the 1st MANU step will be executed.
4. The set voltage of following MANU step should be greater than or equal to the previous MANU step. If not, the set voltage of next MANU step will only start after zeroing.
5. The frequency setting should be identical among each MANU step within an AUTO test.
6. When applying RAMP DOWN function to several MANU steps within an AUTO test, only the last MANU step will be executed.
7. When applying CON function to a MANU step within an AUTO test, it is available to interconnect with next AUTO test page for test based on PREVOLTAGE. However, if the 1st MANU step is selected CON in the next AUTO test, the PREVOLTAGE setting will be invalid.
8. If a MANU step is set SKIP within an AUTO test, the following MANU step will not be executed under PREVOLTAGE setting. For example, when MANU step 2 is set SKIP, the AUTO test will start from MANU step 1 under PREVOLTAGE followed by MANU step 3 without PREVOLTAGE setting.

## Running an Automatic Test

**Background** An automatic test can be run when the tester is in READY status.



**Note**

The tester cannot start to run an AUTO test under the following conditions:

- Any protection modes have been tripped.
- The INTERLOCK function is ON and the Interlock key is not inserted in the signal I/O port (page 177).
- The STOP signal has been received remotely.

If Double Action is ON, ensure the START button is pressed immediately after the STOP button (<0.5s).



**Warning**


Do not touch any terminals, test leads or the DUT when a test is running.

**Steps** 1. Ensure the tester is in READY status for the AUTO test to come. Page 101

READY status indicator

AUTO-001		AUTO_NAME				READY	STEP HOLD	↑	↓
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING					
001	DCW	0.100kV	1.000mA	000 uA					
002	ACW	0.100kV	1.000mA	000 uA					
005	IR	0.050kV	066.8MΩ	000.1MΩ					
010	ACW	0.200kV	2.000mA	000 uA					SKIP
006	DCW	0.500kV	1.500mA	000 uA					
									DEL.
									STEP HOLD

2. Press the START button when the tester is in the READY status. The AUTO test starts automatically and the display changes to each MANU TEST in sequence.



3. Each test will start by showing the ongoing ramp up time followed by the ongoing test time and the ongoing ramp down time. Each test will be tested in sequence until the last test has finished or the test is stopped.




Note

RAMP DOWN time only appears when user has activated it. See page 50 for details.

**PASS & FAIL HOLD**

1. If P.H (Pass Hold) or F.H (Fail Hold) is set for a MANU STEP, then the tester will “hold” the testing when a PASS or FAIL judgment for that particular MANU STEP occurs. See page 110 for more details.

PASS HOLD Indicator



PASS HOLD indicator

FAIL HOLD Indicator




FAIL HOLD indicator


2. The PASS or FAIL indicator on the front panel will also be lit and the buzzer will sound accordingly.



3. To continue to the next MANU STEP after HOLD is displayed on-screen, press the START button.



4. To stop the whole AUTO test when HOLD is displayed on-screen, press the STOP button.





Note

When in HOLD status, only the START and STOP buttons can be pressed, all other keys are disabled.

**FAIL STOP**

1. If F.S (Fail Stop) is set for a MANU STEP, then the tester will “Stop” the whole AUTO test immediately when a FAIL judgment for that particular MANU STEP occurs. See page 111 for more details.

**FAIL STOP Setting**

AUTO-001	AUTO_NAME					REP/ADV	
MANU STEP	TEST MODE	V/I SETTING	HI SETTING	LOW SETTING	STEP HOLD		
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C		↑
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C		↓
026	IR	0.150kV	069.8MΩ	000.6MΩ	P.C/F.S		
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C		SKIP
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C		
							DEL.
							STEP HOLD

FAIL STOP setting

**FAIL HOLD Result Indicator**

AUTO test stops in FAIL status


AUTO-001	AUTO_NAME				FAIL	
MANU STEP	TEST MODE	READ DATA1	READ DATA2	TEST TIME	TEST RESULT	
001	DCW	0.099kV	000 uA	T000.3s	PASS	
002	ACW	0.099kV	000 uA	T000.3s	PASS	
026	IR	0.049kV	60.00GΩ	T000.3s	FAIL	
001	DCW	0.000kV	000 uA	I000.0s		
002	ACW	0.100kV	000 uA	I000.0s		
						PAGE 1 / 1

FAIL STOP indicator on exact MANU STEP

2. The FAIL indicator on the front panel will also be lit and the buzzer will sound accordingly.



3. When FAIL is displayed on-screen, press the STOP button twice to return to the READY status.





Return to  
READY  
status

Restore to READY status

AUTO.001		AUTO NAME				READY
MANU	TEST	V/I	HI	LOW	STEP	↑
STEP	MODE	SETTING	SETTING	SETTING	HOLD	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C	↓
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C	
026	IR	0.150kV	069.8MΩ	000.6MΩ	P.C/F.S	SKIP
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C	
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C	DEL.
						STEP HOLD




Note

When in FAIL status, only the STOP button can be pressed, all other keys are disabled.

Stop a  
Running Test

1. To stop the AUTO test at any time when it is running, press the STOP button. The AUTO test will stop immediately. When the STOP button is pressed, a judgment is not made on the current test and any remaining tests are aborted.



All panel keys except the STOP and START buttons are disabled when the tester has been stopped. All the results up until when the AUTO test was stopped are shown on-screen. See page 119 for more details on automatic test results.

Below is example of an automatic test that has been stopped in the midway. The remaining MANU STEPs are aborted without test results.



## Automatic Test Results

### Background

If all the test steps are allowed to run to completion (the AUTO test is not stopped or a protection setting is not tripped) then the tester will judge each step as either PASS or FAIL. This is shown as a table after the automatic test has finished running. If the test has been stopped, then any remaining tests will not be run and thus the AUTO test will not finish running.

### Overview

AUTO TEST result indicator

AUTO-001		AUTO_NAME				TEST RESULT
MANU STEP	TEST MODE	READ DATA1	READ DATA2	TEST TIME	TEST RESULT	
001	DCW	0.099kV	000 uA	T000.3s	PASS	
002	ACW	0.099kV	000 uA	T000.3s	PASS	
001	DCW	0.000kV	000 uA	T000.0s	SKIP	
001	DCW	0.099kV	000 uA	T000.3s	PASS	
002	ACW	0.099kV	000 uA	T000.3s	PASS	
026	IR	0.049kV	60.00GΩ	T000.3s	FAIL	
001	DCW	0.097kV	000 uA	T000.1s	STOP	
002	ACW	0.000kV	000 uA	T000.3s		

PAGE 1 / 1

MANU STEP results indicators



Note

The PASS/FAIL/STOP result shown on the top-right corner for an AUTO TEST as a whole depends on the results of all the steps (MANU STEPs) that compose an AUTO TEST:

If Interlock function is enabled but without interlock inserted into Signal I/O port, the Interlock Open message will be shown on top-right corner and AUTO test will be unable to start. Refer to page 149 for details.



**STOP Result**

Once a MANU STEP is stopped, the AUTO TEST will be presented STOP in its result. In other words, if a MANU STEP is stopped, the entire AUTO TEST is in STOP result, neither PASS nor FAIL judgment. And the remaining MANU STEP(s) will be ignored with blank in test result field.

AUTO TEST STOP result

AUTO-001		AUTO_NAME				STOP
MANU STEP	TEST MODE	READ DATA1	READ DATA2	TEST TIME	TEST RESULT	
001	DCW	0.099kV	000 uA	T000.3s	PASS	
002	ACW	0.099kV	000 uA	T000.3s	PASS	
001	DCW	0.000kV	000 uA	T000.0s	SKIP	
001	DCW	0.099kV	000 uA	T000.3s	PASS	
002	ACW	0.099kV	000 uA	T000.3s	PASS	
026	IR	0.049kV	60.00GΩ	T000.3s	FAIL	
001	DCW	0.097kV	000 uA	T000.1s	STOP	
002	ACW	0.000kV	000 uA	T000.3s		
						PAGE 1 / 1

One of the MANU STEPS was stopped









## System Settings



The System settings are system-wide settings that apply to both MANU tests and AUTO tests.

The System menu includes the following settings:


- Display Set settings → from page 126.
- Buzzer Settings → from page 128.
- Interface Settings → from page 130.
- Control settings → from page 136.
- Time Setting settings → from page 150.
- Data Initialize settings → from page 155.
- Information section → from page 158.
- Statistics settings → from page 159.
- USB Disk settings → from page 161.
- Contact Check settings → from page 169.

## Display Set Setting

**Description**                      The Display Set page includes both brightness level and language settings.

- Steps**
1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test. 
  2. The SYSTEM page will be shown where DISPLAY SET is on top of the left-side list. Press the ENTER soft-key to enter the setting page. 



3. Use the scroll wheel to set the Brightness level. 



LCD Brightness    1 bar (low) ~ 10 bars (high)

4. Press the UP/DOWN arrow soft-keys to move the cursor to the Language setting followed by using the scroll wheel to set the options of Language setting.



Language options      English  
    繁體中文 (Traditional Chinese)  
    简体中文 (Simplified Chinese)

5. Press the EXIT soft-key to exit from the DISPLAY SET page.



**EXIT**






- The changes in DISPLAY SET are saved instantly.
- The AUTO or MANUAL button can be pressed at any time to jump to its belonging page, individually. Alternatively, it is available to promptly return back to the previous page with settings, whether it's AUTO or MANUAL mode, by simply pressing SYSTEM button.


## Buzzer Settings

**Description** The Buzzer settings allow you to set the volume of buzzer sound for PASS/FAIL judgments. Also, it is available to set Key Sound for buttons being pressed.

- Steps**
1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test. 
  2. The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the BUZZER setting. 





3. Press the ENTER soft-key to enter the Volume setting followed by using the scroll wheel to set the Volume level.   




Buzzer Volume 1 bar (low) ~ 3 bars (high)

4. Press the UP/DOWN arrow soft-keys to move the cursor to the Key Sound setting followed by using the scroll wheel to set the Key Sound setting.



Key Sound ON, OFF

5. Press the EXIT soft-key to exit from the BUZZER page.

**EXIT**



Note

When in the AUTO test, the Buzzer sound only applies to the overall judgment of an AUTO test. There will no Buzzer sound for judgment of each test step within a group of an AUTO test.



Note


The changes in BUZZER setting are saved instantly.

## Interface Settings


**Description** The interface settings allows user to choose the remote interface configuration. USB, RS232, LAN (optional) and GPIB (optional) can be selected.

**Steps**


1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test.



2. The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the INTERFACE setting.





3. Press the ENTER soft-key to enter the Interface setting followed by using the scroll wheel to select the Interface options.



Interface Options



RS-232, USB, GPIB, LAN

- When RS-232 is selected, press the UP/DOWN arrow soft-keys to move the cursor to the Baud Rate setting followed by using the scroll wheel to set the Baud Rate setting.




Baud Rate Setting      9600, 19200, 38400,  
for RS-232                57600, 115200,

- When GPIB is selected, press the UP/DOWN arrow soft-keys to move the cursor to the Address setting followed by using the scroll wheel to set the Address setting.




Address Setting for GPIB      00~31

- When LAN is selected, press the UP/DOWN arrow soft-keys to move the cursor to the DHCP setting, which assigns IP address related settings automatically, followed by using the scroll wheel to turn on or off the setting.












- IP Address Setting            0-255, 0-255, 0-255, 0-255
- Subnet Mask Setting        0-255, 0-255, 0-255, 0-255
- Gateway Setting            0-255, 0-255, 0-255, 0-255


Press the UP/DOWN arrow soft-keys to move the cursor back to the Interface setting followed by pressing the SET soft-key to confirm setting.



When pressing the SCAN soft-key, the unit will scan the LAN card setting thoroughly. In fact, the unit automatically scans at once every time when Interface is changed to LAN setting.



If LAN card with network setting is scanned properly, the “LAN LINK” icon appears. If not, however, the icon doesn’t appear.



When LAN setting is scanned properly and Interface is set as LAN, the “LAN LINK” icon shows as the following figures.


LAN LINK icon in MANU



LAN LINK icon

LAN LINK icon in AUTO

LAN LINK icon



When LAN setting is Not scanned properly and Interface is set as LAN, the “LAN OPEN” icon shows as the following figures.


LAN  
OPEN  
icon in  
MANU



LAN OPEN icon

LAN  
OPEN  
icon in  
AUTO

LAN OPEN icon



- Press the EXIT soft-key to exit from the INTERFACE page.



 Note

Ensure the baud rate settings or GPIB address matches the host machine.

 Note

The changes in INTERFACE setting are saved instantly.

## Control Settings

---

Description	<p>The Control settings include 7 options: Control By, Double Action, Key Lock, Interlock, Start Click For 1 Second, Power GND Check and Barcode Function Setting.</p> <ul style="list-style-type: none"><li data-bbox="370 443 934 569">• Control By is used to determine how a test is started. Tests can be started via the front panel (START/STOP buttons), from a remote controller or via the SIGNAL I/O port.</li><li data-bbox="370 592 925 847">• The Double Action function is a safety feature used to prevent accidentally starting a test. Normally to start a test, the START button is pressed when the tester is in the READY status. To start a test when Double Action is ON, the STOP button must first be pressed, followed by the START button within 500ms.</li><li data-bbox="370 869 934 1098">• Key Lock disables the front panel keys from changing the test number, mode or testing parameters. Only the START &amp; STOP buttons required for testing are not disabled. Also, the SYSTEM button remains functional for user to return back to the system setting.</li><li data-bbox="370 1120 925 1313">• The Interlock function is a safety feature. The interlock function prevents a test from running, unless the interlock pins on the signal I/O port connector are shorted. The included interlock key can be used for this purpose. See page 178 for details.</li><li data-bbox="370 1335 934 1458">• The Start Click For 1 Second indicates another safety feature that requires the START button being pressed for 1 second so that a test, whether MANU or AUTO, can be started.</li></ul>
-------------	--


- The Power GND Check detects if the ground terminal from power cord of instrument connects to earth ground properly.
- Barcode Function Setting is a feature which facilitates fast yet convenient MANU and AUTO tests for, in particular, assembly line application. It enables GPT-10000 series, with additional barcode scanner plugged in, to scan barcodes and edit into a list for prompt utilization in diversified tests.

**Steps**

1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test.




2. The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the CONTROL setting.



3. Press the ENTER soft-key to enter the Control By setting followed by using the scroll wheel to select the following options.






Control By settings      Front Panel  
    Remote  
    SIGNAL IO


When SIGNAL IO is selected, press the PIN SET soft-key to enter the specific setting page.

**PIN SET**




The setting page is divided into 2 sections; the upper is for output pins settings, whilst the lower part indicates the methods of Signal IO selections under AUTO test mode. Refer to the figure below.

SIGNAL IO Output PINs (green zone)




SIGNAL IO Selection for AUTO Test (blue zone)

Press the UP/DOWN arrow soft-keys to move the cursor to target PINs (1~5) followed by using the scroll wheel to select the following 6 options for each pin.




PINs                      READY, TEST, PASS, FAIL,  
Settings                  FAIL\_H, FAIL\_L

Further press the UP/DOWN arrow soft-keys to move the cursor to the TEST PIN STATUS followed by using the scroll wheel to select the following 2 options for TEST PIN under AUTO test mode.




1 signal for all steps      It means one signal output of TEST  
for all                      PIN will be delivered to all steps all  
steps                        the way till the end of an AUTO test.




1 signal for each step  
 for each step  
 It means one signal output of TEST PIN will be delivered to each step with continuous counters within each interval between each step, which is particularly practical for certain applications.



Further press the UP/DOWN arrow soft-keys to move the cursor to the PASS & FAIL PIN STATUS followed by using the scroll wheel to select the following 2 options for PASS & FAIL PINs under AUTO test mode.




Pass & Fail judgment in final step  
 Regardless of judgments of each step in an AUTO test, a PASS or FAIL will be given after the whole steps are completed. However, an AUTO test will be stopped in the mid way when F.S is activated. Refer to page 110 for details.



Pass & Fail judgment for each step  
 Pass or Fail judgment will be given for each step within an AUTO test. By doing so, the judgments of each step can be concretely recognized, individually for user.





Press the UP/DOWN arrow soft-keys to move the cursor to the Double Action setting followed by using the scroll wheel to set the Double Action setting.



DISPLAY SET:	Control By: Front Panel	↑
BUZZER:	Double Action: OFF	
INTERFACE:	Key Lock: ON	↓
CONTROL:	Interlock: OFF	
SYSTEM TIME:	Start Click For 1 Second: OFF	
DATA INIT:	Power GND check: ON	
INFORMATION:	Barcode Function Setting:	
STATISTICS:		
USB DISK:		
CONTACT CHK:		EXIT

Double Action settings      ON, OFF


Press the UP/DOWN arrow soft-keys to move the cursor to the Key Lock setting followed by using the scroll wheel to set the Key Lock setting.



DISPLAY SET:	Control By: Front Panel	↑
BUZZER:	Double Action: OFF	
INTERFACE:	Key Lock: ON	↓
CONTROL:	Interlock: OFF	
SYSTEM TIME:	Start Click For 1 Second: OFF	
DATA INIT:	Power GND check: ON	
INFORMATION:	Barcode Function Setting:	
STATISTICS:		
USB DISK:		
CONTACT CHK:		EXIT


Key Lock settings      ON, OFF

4. Press the UP/DOWN arrow soft-keys to move the cursor to the Interlock setting followed by using the scroll wheel to set the Interlock setting.



Interlock settings      ON, OFF

5. Press the UP/DOWN arrow soft-keys to move the cursor to the Start Click For 1 Second setting followed by using the scroll wheel to set the Start Click For 1 Second setting.



Start Click For 1 Second settings      ON, OFF

6. Press the UP/DOWN arrow soft-keys to move the cursor to the Power GND Check setting followed by using the scroll wheel to set the Power GND Check setting.



DISPLAY SET:	Control By: Front Panel	↑
BUZZER:	Double Action: OFF	
INTERFACE:	Key Lock: ON	↓
CONTROL:	Interlock: OFF	
SYSTEM TIME:	Start Click For 1 Second: OFF	
DATA INIT:	Power GND check: ON	
INFORMATION:	Barcode Function Setting:	
STATISTICS:		
USB DISK		
CONTACT CHK:		
		EXIT

Power GND Check settings      ON, OFF

When Power GND Check setting is ON but the instrument doesn't connect to earth ground, the prompt message will appear in either MANU or AUTO mode as the figures below shown.

MANU  
MODE

ACW	0. 100 kV mA <b>READY</b> POWER GND FAIL	↑ ↓ ← → PAGE 1 / 3
MANU: 001		
MANU_NAME		
IR SET: 1.000 mA		
LOW SET: 000 uA		
TEST TIME: 001.0 s		
RAMP TIME: 000.5 s		
ARC FUNC: OFF		
ARC SET: 1.001 mA		

POWER GND FAIL Message

AUTO  
MODE

GND FAIL Message

AUTO-001	AUTO_NAME	IR	LOW	STEP	READY
STEP	TEST MODE	SETTING	SETTING	SETTING	MODE
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C
026	IR	0.150kV	069.8MΩ	000.6MΩ	P.C/F.S
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C

- Press the UP/DOWN arrow soft-keys to move the cursor to the Barcode Function Setting followed by pressing the SET soft-key to enter the specific setting page.



DISPLAY SET:	Control By: Front Panel	↑
BUZZER:	Double Action: OFF	
INTERFACE:	Key Lock: ON	↓
CONTROL:	Interlock: OFF	
SYSTEM TIME:	Start Click For 1 Second: OFF	SET
DATA INIT:	Power GND check: ON	
INFORMATION:	Barcode Function Setting:	EXIT
STASTISTICS:		
USB DISK		
CONTACT CHK:		

The barcode setting page is composed of a table with several columns and rows. First use the scroll wheel to choose PAGE number.



PAGE # 001~010

BAR PAGE number cursor    BAR setting indicator

PAGE:001	BAR				↓
BARCODE	TEST MODE	TEST NUM	AUTO TEST	MANU/AUTO NAME	
					EXIT

Press the DOWN arrow key to bring the cursor to the PAGE table. Use a connected barcode scanner to scan a target barcode and the scanned barcode information will be written in the 1st row of the PAGE table.



The scanned barcode

PAGE:001	BAR				↑
BARCODE	TEST MODE	TEST NUM	AUTO TEST	MANU/AUTO NAME	
4710123134556			OFF		EXIT



Note

- Use an USB virtual com port-compatible barcode scanner, which plugs into the USB Host Port on the front panel of GPT-10000 series, for ideal function result.
- The length limit of barcode to be scanned is within 15 characters, which means up to 15 characters is displayed in BARCODE column for each barcode.


When a compatible barcode scanner connects to the GTP-10000 series, the corresponding icon will be shown on either MANU or AUTO display.

Barcode icon in MANU



Barcode scanner connected

Barcode icon in AUTO




Barcode scanner connected

Use the LEFT/RIGHT arrow soft-keys to move the cursor to the TEST MODE followed by using the scroll wheel to select desired mode.




TEST MODE      AUTO, MANU

Use the LEFT/RIGHT arrow soft-keys to move the cursor to the TEST NUM followed by using the scroll wheel to determine the number of selected test mode. Refer to page 42 & 101 for test number creation.



TEST NUM      001 - 100

Further use the LEFT/RIGHT arrow soft-keys to move the cursor to the AUTO TEST followed by using the scroll wheel to turn on or off the auto test function, which indicates the test will start automatically when the matched barcode is scanned later.



AUTO TEST      ON, OFF

The MANU/AUTO NAME column automatically reflects file name corresponding to the existed file name from the selected test number in either mode. Refer to page 43 & 102 for test name creation.

Example of a scanned barcode with complete settings

The scanned barcode is set with AUTO-001 with AUTO TEST ON

PAGE-001		BAR				↑
BARCODE	TEST MODE	TEST NUM	AUTO TEST	MANU/AUTO NAME	↓	
4710123134556	AUTO	001	ON	AUTO NAME	←	
					→	
					EXIT	

Repeat the above steps to scan more barcodes and edit the ensuing settings if necessary.














## Time Setting

**Description**                      The date and time for tester system can be edited under this section. The button cell battery used for system date & time has the lifecycle of approximate 2 years in general. Hence, it is suggested to replace with new battery of the type of CR-2032 every 2 years.

Also, this section provides alert relevant setting, which is specific for calibration.

- Steps**
1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test. 
  2. The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the SYSTEM TIME SETTING. 




3. Press the ENTER soft-key to enter the Year setting followed by using the scroll wheel to select the Year setting for system. Also, repeat the actions for the rest month, date, hour, minute and second settings.   





When Cal Alert is turned on and the system time is beyond either Cal Date or Cal Due setting, the display will be shown as follows.



MANU  
Display



AUTO  
Display



- Press the UP/DOWN arrow soft-keys to move the cursor to the Cal Date setting followed by using the scroll wheel to set the Cal Date setting, which indicates the date for calibration.



Cal Date            2000 ~ 2099  
                       01 ~ 12  
                       01 ~ 31

- Press the UP/DOWN arrow soft-keys to move the cursor to the Cal Due setting followed by using the scroll wheel to set the Cal Due setting, which indicates next due date for calibration.



DISPLAY SET:	SYSTEM TIME SETTING:	↑
BUZZER:	2021/05/14 16:53:05	
INTERFACE:		↓
CONTROL:	Calibration Alert	
TIME SETTING:	Cal Alert: ON	→
DATA INIT:	Cal Date: 2020/05/03	
INFORMATION:	Cal Due: 2021/05/03	←
STATISTICS:	Alert Date: 2021/04/01	
USB DISK:	Cal Protection: OFF	EXIT
CONTACT CHK:		

Cal Due                    2000 ~ 2099  
                                   01 ~ 12  
                                   01 ~ 31


- Press the UP/DOWN arrow soft-keys to move the cursor to the Alert Date setting followed by using the scroll wheel to set the Alert Date setting, which indicates the pre-alert function for due date of calibration.



DISPLAY SET:	SYSTEM TIME SETTING:	↑
BUZZER:	2021/05/14 16:53:11	
INTERFACE:		↓
CONTROL:	Calibration Alert	
TIME SETTING:	Cal Alert: ON	→
DATA INIT:	Cal Date: 2020/05/03	
INFORMATION:	Cal Due: 2021/05/03	←
STATISTICS:	Alert Date: 2021/04/01	
USB DISK:	Cal Protection: OFF	EXIT
CONTACT CHK:		

Alert Date                2000 ~ 2099  
                                   01 ~ 12  
                                   01 ~ 31

- Press the UP/DOWN arrow soft-keys to move the cursor to the Cal Protection setting followed by using the scroll wheel to set the Cal Protection setting, which indicates if the output protection setting is turned on of off when due date of calibration expires.



Cal Protection                      ON, OFF

When Cal Protection is turned on and the system time is beyond either Cal Due or Alert Date setting, the display will be shown as follows in which calibration output protection is effectively activated.

MANU  
Display



- Press the EXIT soft-key to exit from the SYSTEM TIME page.



The changes in Time Setting setting are saved instantly.

## Data Initialize Settings


**Description** The settings of AUTO test, MANU test and SYSTEM saved by user can be initialized within this section.

**Steps**

1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test.




2. The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the DATA INIT setting.





3. Press the ENTER soft-key to enter the Manu Data Init setting followed by pressing the right arrow soft-key for consecutive 3 times to initialize the Manu Data settings.





The status bar of Manu Data Init consists of 3 bars, which indicate the initializing action will not be implemented until 3 bars are fully achieved. After the initializing, the “OK” message appears.



4. Press the UP/DOWN arrow soft-keys to move the cursor to the Auto Data Init setting followed by pressing the right arrow soft-key for consecutive 3 times to initialize the Auto Data settings.



The status bar of Auto Data Init consists of 3 bars, which indicate the initializing action will not be implemented until 3 bars are fully achieved. After the initializing, the “OK” message appears.



5. Press the UP/DOWN arrow soft-keys to move the cursor to the System Data Init setting followed by pressing the right arrow soft-key for consecutive 3 times to initialize the System Data settings.



6. Press the EXIT soft-key to exit from the DATA INIT page.




The status bar of System Data Init consists of 3 bars, which indicate the initializing action will not be implemented until 3 bars are fully achieved. After the initializing, the “OK” message appears.

## Information Section

**Description**                      The Information section here discloses some basic information including model name, firmware version and the available functions.

**Steps**

1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test.





2. The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the INFORMATION section.



3. The basic information of the tester will be clearly exposed on the screen.

## Statistics Settings

**Description** This section allows user to have a comprehensive overview of not only total test counts including PASS and FAIL amounts, individually, but also the respective counts of each test mode. More than that, user is able to view those data from an intuitive histogram.

- Steps**
1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test. 
  2. The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the STATISTICS setting where PASS and FAIL amounts and TOTAL amounts to date are shown in the green highlight below. Also, the detailed distributions of PASS and FAIL amounts from each test functions are well disclosed for viewing in the blue highlight below. 

PASS, FAIL amounts & TOTAL amounts

DISPLAY SET:	TOTAL AMOUNT = 00032		↑	
BUZZER:	PASS AMOUNT = 00023			
INTERFACE:	FAIL AMOUNT = 00009			
CONTROL:	FUNCTION	PASS	FAIL	↓
SYSTEM TIME:	ACW	00003	00002	
DATA INIT:	DCW	00003	00002	
INFORMATION:	IR	00002	00003	
STATISTICS:	GB	00003	00002	
USB DISK	CONT	00012	00000	
CONTACT CHK:				ENTER

PASS & FAIL amounts distributions in each test function

3. Press the ENTER soft-key to enter the statistics table. It is available to press the DATA INIT soft-key to initialize the accumulated statistics.

**ENTER**

**DATA  
INIT**

DISPLAY SET:	TOTAL AMOUNT = 00032			↑
BUZZER:	PASS AMOUNT = 00023			
INTERFACE:	FAIL AMOUNT = 00009			
CONTROL:	FUNCTION	PASS	FAIL	↓
SYSTEM TIME:	ACW	00003	00002	
DATA INIT:	DCW	00003	00002	DATA INIT
INFORMATION:	IR	00002	00003	
STATISTICS:	GB	00003	00002	EXIT
USB DISK	CONT	00012	00000	
CONTACT CHK:				

DATA INIT soft-key



Note

After pressing the DATA INIT soft-key, all the statistics shown on this page will be initialized to 0 and the future tests will be re-accumulated from zero.

4. Press the UP/DOWN arrow soft-keys to move the cursor to the table below. Place the cursor in target test function followed by pressing ANALY soft-key to enter the specific analysis page.




**ANALY**

ANALY soft-key

DISPLAY SET:	TOTAL AMOUNT = 00032			↑
BUZZER:	PASS AMOUNT = 00023			
INTERFACE:	FAIL AMOUNT = 00009			
CONTROL:	FUNCTION	PASS	FAIL	↓
SYSTEM TIME:	ACW	00003	00002	
DATA INIT:	DCW	00003	00002	ANALY
INFORMATION:	IR	00002	00003	
STATISTICS:	GB	00003	00002	EXIT
USB DISK	CONT	00012	00000	
CONTACT CHK:				

Selected target test function

5. The distributions of PASS and FAIL statistics are well illustrated in the histogram with table display in which the upper side reads the individual PASS and FAIL amounts for test function. The mid and lower side depicts FAIL amounts in the far-right red strip with number below, whilst the PASS amounts are described in strips of different colors with numbers below indicating the percentage of varied measured values in relation to the set HI & LOW range.



6. Press the EXIT soft-key to exit from the STATISTICS page.

**EXIT**

## USB Disk Settings

### Description


The measurements data can be stored in the connected USB disk. In this section user can determine a user-defined name for data to be saved into the inserted USB disk. It is noted that only USB1.1 or 2.0, FAT16 or FAT32, capacity  $\leq$  32GB can support this function. Refer to page 15 for details on USB port in the front panel.

### Steps


1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test.

**SYSTEM**

- The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the USB DISK setting.



- Press the ENTER soft-key to enter the USB Disk Auto Data Save setting followed by using the scroll wheel to turn on or off the setting, which automatically saves the test data into the inserted USB disk when enabled.



USB Disk Auto Data Save setting ON, OFF

- Press the UP/DOWN arrow soft-keys to move the cursor to the File Name filed, which sets file name for USB Disk Auto Data Save. The characters table will appear beneath accordingly.






Use the scroll wheel to scroll through the available characters.



Press the LEFT / RIGHT arrow soft-keys to move the cursor to the next character and finish the naming.



5. Press the UP/DOWN arrow soft-keys to move the cursor to the Internal Memory SAVE setting followed by using the scroll wheel to turn on or off the setting, which automatically saves the test data into the internal memory of GPT-10000 series when enabled.



Internal Memory SAVE setting ON, OFF

6. Press the UP/DOWN arrow soft-keys to move the cursor to the Internal Memory Amount setting, which displays the total amount of test data.



DISPLAY SET:	USB Disk Auto Data Save: ON	↑
BUZZER:	File Name: LogFile	
INTERFACE:	Internal Memory SAVE: ON	↓
CONTROL:	Internal Memory Amount: 00012	
SYSTEM TIME:	Setting Data Save: ALL	SAVE USB
DATA INIT:	Setting Data Load: MANU	
INFORMATION:		CLEAR DATA
STATISTICS:		
USB DISK		EXIT
CONTACT CHK:		



Note

Only when “Internal Memory SAVE” is enabled can test data be stored into the internal memory amount.

Press the SAVE USB soft-key to save test data into the inserted USB disk. The saved data will be named xxxxxxxx.txt within the directory GPT1X000/MEASURE.

**SAVE  
USB**

### NO USB DISK Warning


If USB disk is Not properly inserted into GPT-10000 series, prompt message “NO USB DISK” pops up.

DISPLAY SET:	USB Disk Auto Data Save: ON	↑
BUZZER:	File Name: LogFile	
INTERFACE:	Internal Memory SAVE: ON	↓
CONTROL:	Internal Memory Amount: 00012	
SYSTEM TIME:	Setting Data Save: ALL	SAVE USB
DATA INIT:	Setting Data Load: MANU	
INFORMATION:	<b>NO USB DISK</b>	CLEAR DATA
STATISTICS:		
USB DISK		EXIT
CONTACT CHK:		

### NO TEST DATA Warning



If there is no test data available in internal memory (Amount: 00000), even though USB disk is inserted, prompt message “NO TEST DATA” pops up.




Press the CLEAR DATA soft-key to clear the internal memory amount.



**NO TEST DATA Warning**


If there is no test data available (Amount: 00000), prompt message “NO TEST DATA” pops up.



Note

Due to the 30,000 counts capacity limitation on internal memory amount, the warning message is shown on either MANU or AUTO mode when the maximum limitation is reached.

DATA FULL  
in  
MANU  
Test



Data Full Message

DATA  
FULL  
in  
AUTO  
Test

Data Full Message

AUTO-001	AUTO NAME		USB	DATA FULL	READY	
MANU	TEST	V/I	HI	LOW	STEP	↑
STEP	MODE	SETTING	SETTING	SETTING	HOLD	↓
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C	
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C	
026	IR	0.150kV	069.8MΩ	000.6MΩ	P.C/F.S	
001	DCW	0.100kV	1.000mA	000 uA	P.C/F.C	SKIP
002	ACW	0.100kV	1.000mA	000 uA	P.C/F.C	
						DEL.
						STEP HOLD

- Press the UP/DOWN arrow soft-keys to move the cursor to the Setting Data Save setting, which allows user to save individual data including MANUDATA, AUTODATA and SYSDATA or All data into the USB disk.



Setting Data Save setting

All, MANU,  
AUTO, SYSTEM


DISPLAY SET:	USB Disk Auto Data Save: ON	↑
BUZZER:	File Name: LogFile	
INTERFACE:	Internal Memory SAVE: ON	↓
CONTROL:	Internal Memory Amount: 00012	
SYSTEM TIME:	Setting Data Save: ALL	
DATA INIT:	Setting Data Load: ALL	SAVE
INFORMATION:		USB
STATISTICS:		
USB DISK		
CONTACT CHK:		EXIT

Press the SAVE USB soft-key to save selected data into USB disk. The saved data will be named AUTODATA.txt, MANUDATA.txt & SYSDATA.txt respectively within the directory GPT1X000/SET\_DATA.



**NO USB DISK Warning**

If USB disk is Not properly inserted into GPT-10000 series, prompt message “NO USB DISK” pops up.




8. Press the UP/DOWN arrow soft-keys to move the cursor to the Setting Data Load setting, which allows user to load individual data including MANUDATA, AUTODATA and SYSDATA or All data from the USB disk.



Setting Data Load setting

All, MANU,  
AUTO, SYSTEM




Press the USB LOAD soft-key to load the selected data from the USB disk.



**OPEN DATA ERROR Warning**

If there is no desired data in the USB disk, the prompt message “OPEN XXXXDATA.TXT ERROR” pops up.



9. Press the EXIT soft-key to exit from the USB DISK page.




Note

- The changes in USB DISK setting are saved instantly.
- The System Data Init function under DATA INIT section is Not able to clear Internal Memory Amount. Instead, only CLEAR DATA soft-key can clear internal memory amount completely.

Make sure an USB disk is plugged into GTP-10000 unit before saving measurement data into the disk. Once an USB disk is well inserted, the USB icon, in either MANU or AUTO mode, appears accordingly.


USB icon in MANU



USB Disk Plugged in

USB icon in AUTO

USB Disk Plugged in



## Contact Check Settings

---

**Background**                      The CONTACT CHK function is used to determine if open circuit or short circuit occurs between the test leads and DUT under the ACW, DCW and IR tests. The section here allows user to define a reference value via learning process and also to assign Hi limit and Low limit for Short and Open status check, respectively.


---

### Steps

1. Press the SYSTEM button on the front panel when the tester is under READY status in either MANU or AUTO test.




2. The SYSTEM page will be shown. Press the UP/DOWN arrow soft-keys to move the cursor to the CONTACT CHK setting.





3. Press the ENTER soft-key to enter the Hi Limit setting followed by using scroll wheel to determine an exact scale of Hi Limit threshold that triggers the SHORT status warning.






Hi Limit settings      OFF, 110% ~ 500%


4. Press the UP/DOWN arrow soft-keys to move the cursor to the Low Limit setting followed by using scroll wheel to determine an exact scale of Low Limit threshold that triggers the OPEN status warning.



Low Limit settings      10% ~ 90%


5. Press the UP/DOWN arrow soft-keys to move the cursor to the Learning setting followed by pressing the RUN soft-key to obtain the current reference value.






Note

- Prior to RUN the Learning process, be sure to well set up test leads connection between the GPT-10000 unit and the DUT.
- When reference value, for example, is defined as 40uA, and Hi and Low limits are set 400% and 40%, respectively, the OPEN status will be triggered when measured value is less than 16uA. The SHORT status, by contrast, will be triggered while measured value is above 160uA.
- When the reference value is learned below 30uA, the warning message will be shown as following and the CONTACT CHK function will be invalid even though CONTACT CHK is turned ON in MANU mode. Refer to page 79 for details of CONTACT CHK setting.



6. Press the EXIT soft-key to exit from the CONTACT CHK page.



Note

The changes in CONTACT CHK setting are saved instantly.

# E EXTERNAL CONTROL

The External Control chapter covers the  
REMOTE terminal and the SIGNAL I/O port.

---

<b>External Control Overview .....</b>	<b>173</b>
Remote Terminal Overview .....	173
Remote Controller Operation .....	174
SIGNAL I/O Overview .....	175
Using the SIGNAL I/O to Start/Stop Tests .....	177
Using the Interlock Key .....	178




## External Control Overview


The External Control section describes the front panel REMOTE terminal connection and the rear panel SIGNAL I/O port.

### Remote Terminal Overview

**Overview** The REMOTE terminal connector is a standard 5-pin DIN terminal suitable for a remote controller.

 **WARNING** Keep any cables that are connected to the REMOTE terminal away from the HIGH VOLTAGE and RETURN terminals.

### Pin Assignment and Connection



Pin	Pin name	Description
1	RMT_STOP	Remote Stop signal
2	COM	Common line
3	COM	Common line
4	RMT_START	Remote Start signal
5	+5V	+5V Output

Signal Properties	
High level input voltage	3.3V~5.0V
Low level input voltage	0~0.8V
Input period	minimum of 1ms

## Remote Controller Operation

---


**Description**                      The GPT-10000 accepts external remote controllers with a START and STOP button. To use the REMOTE terminal, the GPT-10000 must first be configured to accept a remote controller.

Operating a remote controller is the same as operating the START and STOP buttons on the front panel.

---

**Steps**

1. Insert the lead of remote controller into the REMOTE terminal.



2. Configure the CONTROL option to Page 136 REMOTE in the SYSTEM mode.
  3. The tester will now only be able to start a test using a remote controller.
- 



Even if the GPT-10000 is configured to use the REMOTE option, the STOP button on the front panel can still be used to stop a test.

---

4. To return the operation control to the front panel, configure the CONTROL option to Front Panel. [Page 136](#)


## SIGNAL I/O Overview

**Overview**                      The SIGNAL I/O port can be used to remotely start/stop tests and monitor the test status of the instrument.

The SIGNAL I/O port is also used for the interlock function. Refer to page 178 for details.


The SIGNAL I/O port basically uses a DB-15 pin female connector.

### Pin Assignment




Pin name	Pin	Description
INTERLOCK1	1	When INTERLOCK is ON, a test is only allowed
INTERLOCK2	2	to start when both INTERLOCK pins are shorted.
INPUT_START	3	Start signal input
INPUT_STOP	4	Stop signal input
INPUT_COM	5	Common input line
NC	6	NC
OUTPUT_1	7	OUTPUT1 SIGNAL
OUTPUT_2	8	OUTPUT2 SIGNAL
OUTPUT_3	9	OUTPUT3 SIGNAL
OUTPUT_4	10	OUTPUT4 SIGNAL
OUTPUT_5	11	OUTPUT5 SIGNAL
NC	12	NC
NC	13	NC
NC	14	NC
OUTPUT_COM	15	Common output line


**Interlock connection**



**Input Connection**




**Output Connection**




**Signal Properties**

Input Signals	
High level input voltage	5V ~ 32V
Low level input voltage	0V ~ 1V
Low level input current	Maximum of -5mA
Input period	Minimum of 1ms
Output Signals	
Output Type	Relay form A
Output Rated Voltage	30VDC
Maximum output current	0.5A

**Input Stop and Input Start Timing**



**Output Timing**



**Note**

Output is able to be deployed by programming.

## Using the SIGNAL I/O to Start/Stop Tests

---

Background                      To use the SIGNAL I/O port the CONTROL settings have to be set to SIGNAL IO in the SYSTEM mode.

---

- Panel operation                      1. Set the CONTROL option to SIGNAL IO in the SYSTEM mode.                      Page 135
2. Connect the Input/Output signals to the SIGNAL I/O port.
  3. To start the testing, short the INPUT\_STOP and INPUT\_COM line for a minimum of 1ms to put the tester into READY status.
  4. To start the testing, short the INPUT\_START and INPUT\_COM lines for a minimum of 1ms.
  5. To stop the testing, temporarily short the INPUT\_STOP and INPUT\_COM line again.
- 



Even if the GPT-10000 is configured to use the SIGNAL I/O interface, the STOP button on the front panel can still be used to stop a test.

---


## Using the Interlock Key

---

**Background** When the INTERLOCK function is set to ON, tests are only allowed to start when both Interlock pins on the signal I/O port are shorted. Using the Interlock key will short the INTERLOCK1 and INTERLOCK2 pins on the signal I/O port. See page 175 for the Signal I/O pin assignment.

---

**Panel operation** 1. Insert the Interlock key into the SIGNAL I/O port on the rear panel.



2. Set the Interlock option to ON in the SYSTEM mode. [Page 136](#)

---



Note

With INTERLOCK set to ON, the tester can now only start a test when the Interlock key is connected. Please note that removing the interlock key after starting a test leads to interruption of test.

Set Interlock to OFF to disable this feature.

---

# RREMOTE CONTROL

This chapter describes basic configuration of IEEE488.2 based remote control. The remote interface supports USB, RS232 and GPIB.

---


Interface Configuration .....	180
Command Syntax .....	185
Command List .....	188
Error Messages .....	249

## Interface Configuration

### USB Remote Interface

USB Configuration	PC side	Type A, host connector
	GPT-10000 side	Rear panel Type B connector
	USB Class	CDC (communications device class) (VCP, Virtual Com Port)

- Panel operation
1. Connect the USB cable to the rear panel USB B-Type port.



2. Set the Interface to USB from the SYSTEM mode. Page 130



When USB is used for remote control, an RS232 port is simulated. Check the Windows Device Manager for the baud rate and other RS232 settings. Check the RS232 configuration below for more details.

Note the baud rate is fixed to 115200 baud when using the USB interface.

### RS232 Remote Interface


RS232 Configuration	Connection	Null modem cable
	Baud rate	9600, 19200, 38400, 57600, 115200
	Parity	None
	Data bits	8



Stop bit 1

Flow control None

**Pin Assignment**




- 1: No connection
- 2: RxD (Receive Data)
- 3: TxD (Transmit Data)
- 4: No connection
- 5: GND
- 6-9: No connection

Connection	PC		Tester	
	DB9 Pin	Signal	Signal	DB9Pin
	2	RxD	TxD	3
	3	TxD	RxD	2
	5	GND	GND	5

**Panel operation**

1. Connect the Null modem cable to the rear panel RS232 port.



2. Set the Interface to RS-232 from the Page 130 SYSTEM mode.

**LAN Remote Interface**

LAN Configuration	Connection	RJ-45 cable
	DHCP	ON, OFF
	Socket Port	00000 – 65000
	IP Address	0-255, 0-255, 0-255, 0-255
	Subnet Mask	0-255, 0-255, 0-255, 0-255
	Gateway	0-255, 0-255, 0-255, 0-255
	MAC	XX:XX:XX:XX:XX:XX: (it varies by LAN card)

Panel operation 1. Connect the RJ-45 cable to the rear panel LAN port.



2. Set the Interface to LAN from the SYSTEM mode. Page 130

## GPIB Remote Interface

GPIB Configuration	Address	0-31
--------------------	---------	------

Panel operation 1. Connect the GPIB cable to the rear panel GPIB port.



2. Set the Interface to GPIB and set the GPIB address from the SYSTEM mode. Page 130

## USB/RS232/LAN/GPIB Remote Control Function Check

Functionality  
check

Invoke a terminal application such as RealTerm.

To check COM port number and other settings, see the Device Manager in PC. For WinXP; Control panel → System → Hardware tab.

Run this query command via the terminal after the instrument has been configured for USB, RS-232 or GPIB remote control.

\*idn?

This should return Model number, Serial number and Firmware version in the format below:

```
GPT-12004 ,GPT12000 ,V1.00
```

Model number : GPT-12004

Serial number :8 characters serial number

Firmware version : V1.00

CR, LF, CR+LF can be used as the terminal character when entering queries/commands from a terminal application. Refer to page 187 for details.

RMT Display

When the panel is being remotely controlled via the USB, RS232, LAN or GPIB interfaces, the RMT indicator will be displayed on the screen.



RMT indicator

## Err Display

When an incorrect command is sent to the tester, the Err indicator will be displayed on the screen indicating there is an error in command.



Err indicator

## Return to Panel Control

## Background

When the instrument is remotely controlled all panel keys except the STOP button are disabled. Receive a stop signal from either mode of Control By (Front Panel, Remote, SIGNAL IO), while the RMT indicator is displayed, or simply send a RMTOFF command (page 248) to return the instrument back to the READY status.



## Note

To put the tester back to the RMT, simply issue another remote control command.

## Command Syntax

---


Compatible Standard	IEEE488.2	Partial compatibility
	SCPI, 1999	Partial compatibility

---

**Command Structure**

SCPI commands follow a tree-like structure, organized into nodes. Each level of the command tree is a node. Each keyword in an SCPI command represents each node in the command tree. Each keyword (node) of an SCPI command is separated by a colon (:).

For example, the diagram below shows an SCPI sub-structure and a command example.



**Command types**

There are a number of different instrument commands and queries. A command sends instructions or data to the unit and a query receives data or status information from the unit.

Command types

---

**Setting**                      A single or compound command with/without a parameter

**Example**                      MANU:STEP 1

---

**Query**                      A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned.

**Example**                      MANU:ACW:VOLTage?

**Command Forms**            Commands and queries have two different forms, long and short. The command syntax is written with the short form of the command in capitals and the remainder (long form) in lower case.


The commands can be written in capitals or lower-case, just so long as the short or long forms are complete. An incomplete command will not be recognized.

Below are examples of correctly written commands.

**Long form**                      SYSTem:BUZZer:KEYSound  
 SYSTEM:BUZZER:KEYSOUND  
 system:buzzer:keysound

**Short form**                      SYST:BUZZ:KEYS  
 syst:buzz:keys

**Command Format**



**Parameters**

Type	Description	Example
<Boolean>	Boolean logic	0, 1
<NR1>	integers	0, 1, 2, 3
<NR2>	decimal numbers	0.1, 3.14, 8.5

---

<NR3>	floating point	4.5e-1, 8.25e+1
<NRf>	any of NR1, 2, 3	1, 1.5, 4.5e-1

---

<string>	ASCII text string	TEST_NAME
----------	----------------------	-----------

---

Message Terminator	CR, LF, CR+LF	Carriage Return, Line feed code, Carriage Return + Line feed code
--------------------	------------------	--

---

**Note**

There is an interval, which is 100ms at least, between each command communication. It is normal to see the interval occurred when promptly sending commands in the continuous way.

---

## Command List

---

### System Commands

SYSTem:LCD:BRIGhtness .....	192
SYSTem:BUZZer:VOLUME .....	193
SYSTem:BUZZer:KEYSoud .....	193
SYSTem:TIME .....	193
SYSTem:STATistics .....	194
SYSTem:ANALysis .....	194
SYSTem:USBDisk:AUTOSAVE .....	195
SYSTem:USBDisk:AMOUNT .....	195
SYSTem:USBDisk:FILENAME .....	195
SYSTem:INTERNAL:SAVE .....	196
SYSTem:CONtAct:HILIMIT .....	196
SYSTem:CONtAct:LOWLIMIT .....	197
SYSTem:CONtAct:LEARNING .....	197
SYSTem:ERRor .....	197
SYSTem:CONTRol:INTERlock .....	199
SYSTem:CAL:ALERT .....	199
SYSTem:CAL:DATE .....	199
SYSTem:CAL:DUE .....	200
SYSTem:ALERT:DATE .....	200
SYSTem:CAL:PROTection .....	200
SYSTem:INTERNAL:MEMORY .....	201

### Function Commands

FUNction:TEST .....	202
MEASure<x> .....	203
MAIN:FUNction .....	204
TESTok:RETURN .....	204

### Manual Commands

MANU:STEP .....	207
-----------------	-----



MANU:INITial.....	207
MANU:NAME.....	208
MANU:RTIME .....	208
MANU:EDIT:MODE.....	209
MANU:ACW:VOLTag.....	209
MANU:ACW:CHISet.....	210
MANU:ACW:CLOSet.....	210
MANU:ACW:TTIME.....	211
MANU:ACW:ARCFunction .....	212
MANU:ACW:ARCCurrent .....	213
MANU:ACW:ARCSpeed .....	213
MANU:ACW:FREQuency .....	213
MANU:ACW:WAITtime.....	214
MANU:ACW:RAMPadown .....	214
MANU:ACW:GROUNDMODE.....	215
MANU:ACW:MAXHold .....	215
MANU:ACW:PASShold .....	215
MANU:ACW:REF .....	216
MANU:ACW:INITvoltage .....	216
MANU:ACW:CONTACT .....	217
MANU:DCW:VOLTag.....	217
MANU:DCW:CHISet.....	218
MANU:DCW:CLOSet.....	218
MANU:DCW:TTIME.....	219
MANU:DCW:ARCFunction .....	220
MANU:DCW:ARCCurrent .....	220
MANU:DCW:ARCSpeed .....	220
MANU:DCW:WAITtime.....	221
MANU:DCW:RAMPadown .....	221
MANU:DCW:GROUNDMODE.....	222
MANU:DCW:MAXHold .....	222
MANU:DCW:PASShold .....	222
MANU:DCW:REF .....	223
MANU:DCW:INITvoltage .....	223
MANU:DCW:CONTACT .....	224
MANU:IR:VOLTag .....	224
MANU:IR:RHISet.....	225
MANU:IR:RLOSet.....	225
MANU:IR:TTIME .....	225
MANU:IR:WAITtime.....	226

---

MANU:IR:RAMPdown .....	226
MANU:IR:GROUNDMODE.....	227
MANU:IR:MAXHold .....	227
MANU:IR:PASShold .....	228
MANU:IR:REF .....	228
MANU:IR:MODE .....	229
MANU:IR:CONTACT .....	229
MANU:IR:FILTer .....	230
MANU:IR:GNDOFFSET .....	230
MANU:GB:CURRent .....	230
MANU:GB:RHISet .....	231
MANU:GB:RLOSet .....	232
MANU:GB:TTIME.....	232
MANU:GB:FREQuency .....	232
MANU:GB:CONtact .....	233
MANU:GB:GROUNDMODE .....	233
MANU:GB:MAXHold .....	233
MANU:GB:PASShold .....	234
MANU:GB:REF .....	234
MANU:GB:ZEROCHECK.....	235
MANU:CONTInuity:RHISet .....	235
MANU:CONTInuity:RLOSet.....	236
MANU:CONTInuity:TTIME .....	236
MANU:CONTInuity:PASShold .....	237
MANU:CONTInuity:REF .....	237
MANU:CONTInuity:ZEROCHECK .....	238

## Auto Commands

AUTO:STEP .....	239
AUTO:NAME .....	240
AUTO:EDIT:ADD .....	241
AUTO<x>:EDIT:HOLD.....	242
AUTO<x>:EDIT:SKIP .....	242
AUTO:EDIT:DEL .....	243
AUTO:TEST:RETURN .....	243
AUTO:EDIT:SHOW .....	244

## Sweep Commands

SWEEP:DATA:STATus .....	245
SWEEP:DATA:SHOW .....	245
SWEEP:GRAPh:SHOW .....	246

## Common Commands


*CLS.....	247
*IDN .....	247
*SRE.....	248

## Remote Commands

*RMTOFF.....	248
--------------	-----

## System Commands

SYSTem:LCD:BRIGhtness .....	192
SYSTem:BUZZer:VOLUME .....	193
SYSTem:BUZZer:KEYSound .....	193
SYSTem:TIME .....	193
SYSTem:STATistics .....	194
SYSTem:ANALysis .....	194
SYSTem:USBDisk:AUTOSAVE .....	195
SYSTem:USBDisk:AMOUNT .....	195
SYSTem:USBDisk:FILENAME .....	195
SYSTem:INTERNAL:SAVE .....	196
SYSTem:CONtact:HILIMIT .....	196
SYSTem:CONtact:LOWLIMIT .....	197
SYSTem:CONtact:LEARNING .....	197
SYSTem:ERRor .....	197
SYSTem:CONtrol:INTERlock.....	199
SYSTem:CAL:ALERT .....	199
SYSTem:CAL:DATE .....	199
SYSTem:CAL:DUE.....	200
SYSTem:ALERT:DATE.....	200
SYSTem:CAL:PROtECTION .....	200
SYSTem:INTERNAL:MEMORY .....	201



### SYSTem:LCD:BRIGhtness

Description	Sets the brightness of the LCD display from 1(dark) to 10(bright).
Syntax	SYSTem:LCD:BRIGhtness <NR1>
Query Syntax	SYSTem:LCD:BRIGhtness?
Parameter/ Return parameter	<NR1> 1 (dark) ~ 10 (bright)
Example	SYST:LCD:BRIG 10 Sets the display brightness to the brightest 10.

**SYSTem:BUZZer:VOLUME** 


Description	Sets buzzer volume from 1(low) to 3(high).
Syntax	SYSTem:BUZZer:VOLUME <NR1>
Query Syntax	SYSTem:BUZZer:VOLUME
Parameter/ Return parameter	<NR1> 1 (low) ~ 3 (high)
Example	SYST:BUZZ:VOLUME 3 Sets the buzzer volume to the highest 3.

**SYSTem:BUZZer:KEYSound** 


Description	Turns the buzzer on or off for key sound.
Syntax	SYSTem:BUZZer:KEYSound {ON OFF}
Query Syntax	SYSTem:BUZZer:KEYSound?
Parameter/ Return parameter	ON Buzzer Key Sound on. OFF Buzzer Key Sound off.
Example	SYST:BUZZ:KEYS ON Turns the buzzer on for key sound.

**SYSTem:TIME** 


Description	Sets or Queries the system time.
Syntax	SYSTem:TIME {TYY_MM_DD_hh:mm:ss}
Query Syntax	SYSTem:TIME?
Parameter/ Return parameter	TYY_MM_D Year (YY)_Month (MM)_Day D_hh:mm:ss (DD)_Hour (hh)_Minute (mm)_Second (ss)
	<string> Returns the system date & time as a string
Example	SYST:TIME T19_12_05_17_10_20 Sets the system time as 2019-12-05 17:10:20

## SYSTem:STATistics

→ Query


Description	Queries the latest statistics of PASS and FAIL.	
Query Syntax	SYSTem:STATistics?	
Return parameter	<string>	Returns the latest statistics of all the function tests with counts of PASS and FAIL judgments respectively.
Query Example	<pre> SYST:STAT? &gt;TOTAL AMOUNT=00071 &gt;PASS AMOUNT=00059 &gt;FAIL AMOUNT=00012 &gt;FUNC,PASS ,FAIL , &gt;ACW ,00026,00009, &gt;DCW ,00000,00000, &gt;IR ,00017,00003, &gt;GB ,00000,00000, &gt;CONT,00016,00000,                     </pre>	

## SYSTem:ANALysis

→ Query


Description	Queries the latest analysis of each test function.	
Query Syntax	SYSTem:ANALysis {ACW   DCW IR GB CONT}	
Return parameter	<string>	Returns the latest analysis of the select test with PASS and FAIL judgments and distributions.
Query Example	<pre> SYST:ANAL IR &gt;IR,PASS=00017,FAIL=00003 &gt;000~025%=00003 &gt;026~050%=00000 &gt;051~075%=00000 &gt;076~100%=00014 &gt;FAIL=00003                     </pre>	

**SYSTem:USBDisk:AUTOSAVE**




Description	Sets or returns the USB disk auto data save on or off.	
Syntax	SYSTem:USBDisk:AUTOSAVE {ON  OFF}	
Query Syntax	SYSTem:USBDisk:AUTOSAVE?	
Parameter	ON	Turns the USB disk auto save on.
	OFF	Turns the USB disk auto save off.
Return parameter	ON	USB disk auto save on.
	OFF	USB disk auto save off.
Example	SYST:USB:AUTOSAVE ON Turns USB disk auto save on.	

**SYSTem:USBDisk:AMOUNT**




Description	Saves, clears or returns the amount of tests. When saving, there are 2 results as follows. If no USB disk is inserted, the message “NO USB DISK” shows. If USB disk is inserted properly, the message “SAVE OK” is shown.	
Syntax	SYSTem:USBDisk:AMOUNT {SAVE   CLEAR}	
Query Syntax	SYSTem:USBDisk:AMOUNT?	
Parameter	SAVE	Saves the amount of tests into USB disk.
	CLEAR	Clears the amount of tests from internal memory.
Return parameter	<value>	Returns the amount of tests from internal memory.
Example	SYST:USB:AMOUNT SAVE Saves the amount of tests into USB disk.	

**SYSTem:USBDisk:FILENAME**




Description	Sets or returns the data file name to be saved into the inserted USB disk. Note only alphanumeric characters (A-Z, a-z, 0-9) and the “_” underscore character can be used to set the file name.
Syntax	SYSTem:USBDisk:FILENAME <”string”>
Query Syntax	SYSTem:USBDisk:FILENAME?
Parameter/ Return parameter	<”String”> 8 character string.
Example	SYST:USBD:FILENAME “File1” Sets the data file name to “File1”.



**SYSTem:INTERNAL:SAVE**

Description	Sets or returns the internal data save on or off.
Syntax	SYSTem:INTERNAL:SAVE {ON  OFF}
Query Syntax	SYSTem:INTERNAL:SAVE?
Parameter	ON Turns the internal data save on. OFF Turns the internal data save off.
Return parameter	ON Internal data save on. OFF Internal data save off.
Example	SYST:INTERNAL:SAVE ON Turns internal data save on.



**SYSTem:CONtact:HILIMIT**

Description	Sets or returns the threshold of Hi Limit scale for contact check function.
Syntax	SYSTem:CONtact:HILIMIT {value   OFF}
Query Syntax	SYSTem:CONtact:HILIMIT?
Parameter	<value> 110% ~ 500% OFF Disables the threshold of Hi Limit scale.
Return parameter	<value> 110% ~ 500% OFF The threshold of Hi Limit scale is disabled.



Example            SYST:CONT:HILIMIT 200%

                     Sets the threshold of Hi Limit scale as 200% to the reference value.

Set →

### SYSTem:CONtact:LOWLIMIT

→ Query

Description       Sets or returns the threshold of Low Limit scale for contact check function.

Syntax            SYSTem:CONtact:LOWLIMIT {value}

Query Syntax     SYSTem:CONtact:LOWLIMIT?

Parameter        <value>        10% ~ 90%

Return parameter <value>        10% ~ 90%

Example            SYST:CONT:LOWLIMIT 80%

                     Sets the threshold of Low Limit scale as 80% to the reference value.

Set →

### SYSTem:CONtact:LEARNING

→ Query

Description       Sets or returns the current reference value for contact check function.

Syntax            SYSTem:CONtact:LEARNING RUN

Query Syntax     SYSTem:CONtact:LEARNING?

Parameter        RUN             Sets the current reference value.

Return parameter <value>        Returns the current reference value.

Example            SYST:CONT:LEARNING RUN

                     The current reference value for contact check is set.

### SYSTem:ERRor

→ Query

Description       Returns error code of the previous error. See the error code table below for details.

Query Syntax     SYSTem:ERRor ?

Return parameter	<string>	Returns an error string that includes an error code and an error description.
------------------	----------	---

**Error Code Table**

Error code, Error description

- 0, No Error
- 20, Command Error
- 21, Value Error
- 22, String Error
- 23, Query Error
- 24, Mode Error
- 25, TIME OVER 240s
- 26, DC Over 50W [GPT-12XXX]
- 26, DC Over 100W [GPT-15XXX]
- 27, GBV > 7.2V
- 28, ARC <= HI Set
- 29, HI Set => ARC
- 30, Voltage Setting Error
- 31, Current Setting Error
- 32, Current HI SET Error
- 33, Current LO SET Error
- 34, Resistance HI SET Error
- 35, Resistance LO SET Error
- 36, REF Setting Error
- 37, Frequency Setting Error
- 38, ARC Setting Error
- 39, RAMP Time Setting Error
- 40, TEST Time Setting Error
- 41, WAIT Time Setting Error
- 42, RAMP Down Setting Error
- 43, PASS Hold Setting Error
- 44, GB Contact Setting Error
- 45, Setting Over 200W
- 46, CONT Setting Over 8V
- 47, Auto Step Add Full
- 48, This Is The Last Step
- 49, Learning less than 30uA
- 50, USB DISK BUSY
- 70, Read Buffer Error
- 71, Send Buffer Error

Example            SYST:ERR ?  
                      >0, No Error  
                      Returns "0, No Error" as the error message.

**SYSTEM:CONTROL:INTERlock** → Query

---

Description       Returns the status of interlock setting.

---

Query Syntax      SYSTEM:CONTROL:INTERlock?

---

Return parameter 

On	Interlock setting is set On.
Off	Interlock setting is set Off.

---

Example            SYSTEM:CONTROL:INTERlock?  
                      > On  
                      Returns the interlock setting is set On.

Set →

**SYSTEM:CAL:ALERT** → Query

---

Description       Sets or returns the calibration alert function.

---

Syntax             SYSTEM:CAL:ALERT {ON |OFF}

---

Query Syntax      SYSTEM:CAL:ALERT?

---

Parameter         

ON	Turns the calibration alert on.
OFF	Turns the calibration alert off.

---

Return parameter 

ON	Calibration alert on.
OFF	Calibration alert off.

---

Example            SYST:CAL:ALERT ON  
                      Sets the calibration alert function ON.

Set →

**SYSTEM:CAL:DATE** → Query

---

Description       Sets or returns the calibration date.

---

Syntax             SYSTEM:CAL:DATE {TYY\_MM\_DD}

---

Query Syntax      SYSTEM:CAL:DATE?

---

Parameter/  
Return parameter 

TYY_MM_DD	Year (YY)_Month (MM)_Day (DD)
<string>	Returns the calibration date as a string

Example            SYST:CAL:DATE T21\_06\_01  
                      Sets the calibration date as 2021-06-01.

Set →

**SYSTEM:CAL:DUE**

→ Query

Description       Sets or returns the next calibration due date.

Syntax            SYSTem:CAL:DUE {TYY\_MM\_DD}

Query Syntax     SYSTem:CAL:DUE?

Parameter/ Return parameter	TYY_MM_DD <string>	Year (YY)_Month (MM)_Day (DD) Returns the next calibration due date as a string
--------------------------------	-----------------------	--

Example            SYST:CAL:DUE T21\_06\_01  
                      Sets the next calibration due date as 2021-06-01.

Set →

**SYSTEM:ALERT:DATE**

→ Query

Description       Sets or returns the pre-alert date for calibration due date.

Syntax            SYSTem:ALERT:DATE {TYY\_MM\_DD}

Query Syntax     SYSTem:ALERT:DATE?

Parameter/ Return parameter	TYY_MM_DD <string>	Year (YY)_Month (MM)_Day (DD) Returns the pre-alert date for calibration due date as a string
--------------------------------	-----------------------	--

Example            SYST:ALERT:DATE T21\_06\_01  
                      Sets the pre-alert date as 2021-06-01.

Set →

**SYSTEM:CAL:PROTECTION**

→ Query

Description       Sets or returns the calibration output protection for calibration due date.

Syntax            SYSTem:CAL:PROTECTION {ON |OFF}

Query Syntax     SYSTem:CAL:PROTECTION?

Parameter	ON	Turns the calibration protection on.
	OFF	Turns the calibration protection off.
Return parameter	ON	Calibration protection on.
	OFF	Calibration protection off.
Example	SYST:CAL:PROT ON Sets the calibration protection function ON.	

## SYSTEM:INTERNAL:MEMORY


→ Query

Description	Returns the test result from internal memory of unit.	
Query Syntax	SYSTEM:INTERNAL:MEMORY?	
Return parameter	<string>	Returns the test result from internal memory as a string.
Example	SYST:INTERNAL:MEMORY? > Date/Time ,Stp,MOD,Judge, V/A , Reading , Timer ,MA_S,Barcode , 2021-02-24 13:52:08,001,IR ,PASS ,0.049kV, >10Gohm,T=000.3s,A002, ,	

## Function Commands

FUNcTion:TEST.....	202
MEASure<x> .....	203
MAIN:FUNcTion.....	204
TESTok:RETURN .....	204

### FUNcTion:TEST




**Description** Turns the currently selected test (output) on or off.

When HOLD is displayed on the screen during AUTO tests, use the FUNcTion:TEST command to move on to the next step.

Setting the FUNcTion:TEST command to OFF at the end of a test will also temporarily turn the PASS/FAIL buzzer sound off.

<b>Syntax</b>	FUNcTion:TEST {ON OFF}	
<b>Query Syntax</b>	FUNcTion:TEST?	
<b>Parameter</b>	ON	Turns the test on.
	OFF	Turns the test off.
<b>Return parameter</b>	TEST ON	Test is on.
	TEST OFF	Test is off.
<b>Example</b>	FUNC:TEST ON Turns the output on.	

**MEASure<x>**



**Description** Returns the test parameters & results of the tester in either MANU or AUTO mode.

MANU mode: Returns the test parameters & results of a MANU test.

AUTO mode: Returns the test parameters & results of the selected step (1-50) of the AUTO test.

Return parameters: function, judgment/status, test voltage, test current/resistance, test time (time of completed test) or ramp time (elapsed time of test that has not been completed).

<b>Query Syntax</b>	MEASure<x>?	
<b>Parameter (MANU mode)</b>		No parameter needed for MANU mode.
<b>Parameter (AUTO mode)</b>	<x>	<NR1>1~50. MANU Step number.
<b>Return parameter</b>	<string>	Returns the test status of the test in the following format: function, judgment or status, test voltage, test current or resistance, test time or ramp time

<b>Function</b>	ACW, DCW, IR, GB, CON
<b>Judgment /Status</b>	PASS, FAIL VIEW
<b>Test voltage</b>	voltage+unit
<b>Test current /Test resistance</b>	current+unit resistance+unit
<b>Test time /Ramp time</b>	T=time+s R=time+s

**Example (in MANU mode)** MEAS?  
> CON,FAIL ,100.0mA,99.99 ohm,T=000.1s  
Returns the test result of the current MANU test.

Example                    MEAS21?  
 (in AUTO mode)        > DCW,FAIL ,0.004kV, 000.0 uA ,T=000.3s  
                              Returns the step 21 of the current AUTO test result.

Set →

**MAIN:FUNCTION**

→ Query

Description	Changes the mode between AUTO and MANU.
Syntax	MAIN:FUNCTION {MANU AUTO}
Query Syntax	MAIN:FUNCTION ?
Parameter/ Return parameter	MANU    Puts the tester mode to MANU. AUTO    Puts the tester mode to AUTO.
Example	MAIN:FUNC MANU Sets the tester to MANU mode.

Set →

**TESTok:RETURN**

→ Query

Description	Turns on or off the "OK" message for test result, which is shown when a test finishes.
Syntax	TESTok:RETURN {ON OFF}
Query Syntax	TESTok:RETURN ?
Parameter/ Return parameter	ON        Turns on the "OK" message for test result. OFF       Turns off the "OK" message for test result.
Example	TEST:RETURN ON Turns of the OK message return function.




## Manual Commands

---

MANU:STEP .....	207
MANU:INITial.....	207
MANU:NAME.....	208
MANU:RTIME .....	208
MANU:EDIT:MODE.....	209
MANU:ACW:VOLTage.....	209
MANU:ACW:CHISet.....	210
MANU:ACW:CLOSet.....	210
MANU:ACW:TTIME.....	211
MANU:ACW:ARCFUNCTION .....	212
MANU:ACW:ARCCURRENT .....	213
MANU:ACW:ARCSpeed .....	213
MANU:ACW:FREQUENCY .....	213
MANU:ACW:WAITtime.....	214
MANU:ACW:RAMPDOWN .....	214
MANU:ACW:GROUNDMODE.....	215
MANU:ACW:MAXHold .....	215
MANU:ACW:PASShold.....	215
MANU:ACW:REF .....	216
MANU:ACW:INITvoltage.....	216
MANU:ACW:CONTACT .....	217
MANU:DCW:VOLTage.....	217
MANU:DCW:CHISet.....	218
MANU:DCW:CLOSet.....	218
MANU:DCW:TTIME.....	219
MANU:DCW:ARCFUNCTION .....	220
MANU:DCW:ARCCURRENT .....	220
MANU:DCW:ARCSpeed .....	220
MANU:DCW:WAITtime.....	221
MANU:DCW:RAMPDOWN .....	221
MANU:DCW:GROUNDMODE.....	222
MANU:DCW:MAXHold .....	222
MANU:DCW:PASShold.....	222
MANU:DCW:REF .....	223
MANU:DCW:INITvoltage.....	223
MANU:DCW:CONTACT .....	224


MANU:IR:VOLTage .....	224
MANU:IR:RHISet .....	225
MANU:IR:RLOSet .....	225
MANU:IR:TTIME .....	225
MANU:IR:WAITtime .....	226
MANU:IR:RAMPdown .....	226
MANU:IR:GROUNDMODE .....	227
MANU:IR:MAXHold .....	227
MANU:IR:PASShold .....	228
MANU:IR:REF .....	228
MANU:IR:MODE .....	229
MANU:IR:CONTACT .....	229
MANU:IR:FILTer .....	230
MANU:IR:GNDOFFSET .....	230
MANU:GB:CURRent .....	230
MANU:GB:RHISet .....	231
MANU:GB:RLOSet .....	232
MANU:GB:TTIME .....	232
MANU:GB:FREQuency .....	232
MANU:GB:CONtact .....	233
MANU:GB:GROUNDMODE .....	233
MANU:GB:MAXHold .....	233
MANU:GB:PASShold .....	234
MANU:GB:REF .....	234
MANU:GB:ZEROCHECK .....	235
MANU:CONTInuity:RHISet .....	235
MANU:CONTInuity:RLOSet .....	236
MANU:CONTInuity:TTIME .....	236
MANU:CONTInuity:PASShold .....	237
MANU:CONTInuity:REF .....	237
MANU:CONTInuity:ZEROCHECK .....	238

**MANU:STEP**



Description	Sets the MANU test number.
Syntax	MANU:STEP <NR1>
Query Syntax	MANU:STEP?
Parameter/ Return parameter	<NR1> 0~100
Example	MANU:STEP 100 Sets the manual test number to 100.

**MANU:INITial**



Description Loads the initial (default) settings for the selected MANU test number. The initial settings that are loaded depend on the test function (ACW, DCW, IR, GB or CONT).

Syntax	MANU:INITial					
Initial Settings		Function				
	Parameter	ACW	DCW	IR	GB	CONT
	REF#	000uA	000uA	000.0M Ω	000.0m Ω	00.00 Ω
	FREQ	60Hz	X	X	60Hz	X
	HI SET	1.000mA	1.000mA	OFF	100.0m Ω	01.00 Ω
	LOW SET	000uA	000uA	000.1M Ω	000.0m Ω	00.00 Ω
	I or V	V=0.100 kV	V=0.100 kV	V=0.050 kV	03.00A	100mA
	TEST TIME	000.3s	000.3s	000.3s	000.3s	000.3s
	RAMP TIME	000.1s	000.1s	000.1s	X	X

Example MANU:INITial  
Loads the initial settings for the selected MANU number.

Set →

→ Query

**MANU:NAME**

**Description** Sets or returns the test name for the selected manual test. The test must be in MANU mode before this command can be used.  
 Note only alphanumeric characters (A-Z, a-z, 0-9) and the “\_” underscore character can be used to set the MANU test name.

**Syntax** MANU:NAME <”string”>

**Query Syntax** MANU:NAME?

**Parameter/Return parameter** <”string”> 10 character string.

**Example** MANU:NAME “test1”  
 Sets the manual test name to “test1”.

Set →

→ Query

**MANU:RTIME**

**Description** Sets or returns the Ramp Up time for ACW, DCW and IR tests in seconds.

Note: An “Err” message will be shown on display if the Ramp Time + Test Time is > 240 seconds when the HI SET limit + REF is ≥ 30mA for GPT-12XXX or HI SET limit + REF is ≥ 80mA for GPT-15XXX. This applies to the ACW function only. An “TIME OVER 240s” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

Note: When tester is in GB or CONT mode, due to without RAMP TIME setting, only an “Err” message will be shown if issuing this remote command.

**Syntax** MANU:RTIME <NR2>

**Query Syntax** MANU:RTIME?

**Parameter/Return parameter** <NR2> 0.1~999.9 seconds

Example            MANU:RTIM 0.5  
                          Sets the ramp time to half a second.

Set →

**MANU:EDIT:MODE**

→ Query

Description       Sets or returns the mode (ACW, DCW, IR, GB, CONT) of the selected manual test.

Syntax            MANU:EDIT:MODE {ACW|DCW|IR|GB|CONT}

Query Syntax     MANU:EDIT:MODE?

Parameter/	ACW	AC Withstand mode
Return parameter	DCW	DC Withstand mode
	IR	Insulation Resistance mode
	GB	Ground Bond mode
	CONT	Continuity mode

Example            MANU:EDIT:MODE ACW  
                          Sets the mode to ACW.

Set →

**MANU:ACW:VOLTage**

→ Query

Description       Sets or returns the ACW voltage in kV. The test must first be in ACW mode before this command can be used.

Syntax            MANU:ACW:VOLTage <NR2>

Query Syntax     MANU:ACW:VOLTage?

Parameter/	<NR2>	0.050 ~ 5.100 (kV)
Return parameter		

Example            MANU:ACW:VOLT 1  
                          Sets the ACW voltage to 1 kV.

**MANU:ACW:CHISet**

Set →

→ Query

**Description**            Sets or returns the ACW HI SET current value in milliamps. The test must first be in ACW mode before this command can be used.

Note: An “Err” message will be shown on display if the Ramp Time + Test Time is > 240 seconds when the HI SET limit + REF is ≥ 30mA for GPT-12XXX or HI SET limit + REF is ≥ 80mA for GPT-15XXX. This applies to the ACW function only. An “TIME OVER 240s” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

**Syntax**                    MANU:ACW:CHISet <NR2>

**Query Syntax**            MANU:ACW:CHISet?

<b>Parameter/</b>	<NR2>	0.001 ~ 42.00 (mA) [GPT-12XXX]
<b>Return parameter</b>		0.001 ~ 110.00 (mA) [GPT-15XXX]

**Example**                    MANU:ACW:CHIS 30.0

                                  Sets the ACW HI SET current to 30 mA.

Set →

→ Query

**MANU:ACW:CLOSet**

**Description** Sets or returns the ACW LOW SET current value in milliamps. The LOW SET value must be less than the HI SET value. The test must first be in ACW mode before this command can be used.

The LOW SET range must use the HI SET range. If all the digits in the LOW SET range are outside the HI SET range, an Err message will be produced. All digits outside the HI SET range are ignored and will not be used.

For example:

HI SET value: 30.00

LOW SET value: 30.01 → error

**Syntax** MANU:ACW:CLOSet <NR2>

**Query Syntax** MANU:ACW:CLOSet?

**Parameter/** <NR2> 0.000 ~ 41.99 (mA) [GPT-12XXX]

**Return parameter** 0.000 ~ 110.9 (mA) [GPT-15XXX]

**Example** MANU:ACW:CLOS 20.0

Sets the ACW LO SET current to 20 mA.

Set →

→ Query

### MANU:ACW:TTIME

**Description** Sets or returns the ACW test time in seconds. The test must first be in ACW mode before this command can be used.

Note: An “Err” message will be shown on display if the Ramp Time + Test Time is > 240 seconds when the HI SET limit + REF is ≥ 30mA for GPT-12XXX or HI SET limit + REF is ≥ 80mA for GPT-15XXX. This applies to the ACW function only. An “TIME OVER 240s” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

Syntax	MANU:ACW:TTIME {<NR2> OFF}	
Query Syntax	MANU:ACW:TTIME?	
Parameter	<NR2>	0.3 ~ 999.9 seconds
	OFF	TIMER OFF
Return parameter	<NR2>	0.3 ~ 999.9 seconds
	TIME OFF	TIMER is OFF
Example	MANU:ACW:TTIM 1 Sets the ACW test time to 1 second.	

Set →

**MANU:ACW:ARCFUNCTION**

→ Query

Description	Sets or returns the ACW ARC function. The test must first be in ACW mode before this command can be used. Note that this command is only workable when ARC SET>HI SET.	
Syntax	MANU:ACW:ARCFUNCTION	
Query Syntax	{OFF ON_CONT ON_STOP} MANU:ACW:ARCFUNCTION?	
Parameter/ Return parameter	OFF	ARC function off
	ON_CONT	ARC function ON & CONT
	ON_STOP	ARC function ON & STOP
Example	MANU:ACW:ARCF OFF Sets the ACW ARC function off.	



**MANU:ACW:ARCCurrent**

Set →

→ Query

**Description** Sets or returns the ACW ARC current value in mA. ARC must be enabled before the ARC current can be set. The test must first be in ACW mode before this command can be used.

**Syntax** MANU:ACW:ARCCurrent <NR2>

**Query Syntax** MANU:ACW:ARCCurrent?

<b>Parameter/ Return parameter</b>	<NR2>	1.000 ~ 80.00mA [GPT-12XXX]
		1.000 ~ 200.0mA [GPT-15XXX]

**Example** MANU:ACW:ARCC 1.233  
Sets the ACW ARC value to 1.233 mA.

Set →

→ Query

**MANU:ACW:ARCSpeed**

**Description** Sets or returns the ACW ARC speed. ARC must be enabled before the ARC speed can be set. The test must first be in ACW mode before this command can be used.

**Syntax** MANU:ACW:ARCSpeed {FAST|NORMAL|SLOW}

**Query Syntax** MANU:ACW:ARCSpeed?

<b>Parameter/ Return parameter</b>	FAST	ARC speed fast
	NORMAL	ARC speed normal
	SLOW	ARC speed slow

**Example** MANU:ACW:ARCS SLOW  
Sets the ACW ARC speed slow.

Set →

→ Query

**MANU:ACW:FREQuency**

**Description** Sets or returns the ACW test frequency in Hz. The test must first be in ACW mode before this command can be used.

Syntax	MANU:ACW:FREQuency {50 60}	
Query Syntax	MANU:ACW:FREQuency?	
Parameter/	50	50 Hz
Return parameter	60	60 Hz
Example	MANU:ACW:FREQ 50 Sets the ACW test frequency to 50Hz.	

Set →

### MANU:ACW:WAITtime

→ Query

Description	Sets or returns the ACW wait time in seconds. The test must first be in ACW mode before this command can be used.	
Syntax	MANU:ACW:WAITtime <NR2>	
Query Syntax	MANU:ACW:WAITtime?	
Parameter/	<NR2>	0 ~ 999.9 seconds
Return parameter		
Example	MANU:ACW:WAIT 10.1 Sets the ACW wait time to 10.1 s.	

Set →

### MANU:ACW:RAMPdown

→ Query

Description	Sets or returns the ACW Ramp Down Time in seconds. The test must first be in ACW mode before this command can be used.	
Syntax	MANU:ACW:RAMPdown <NR2>	
Query Syntax	MANU:ACW:RAMPdown?	
Parameter/	<NR2>	0 ~ 999.9 seconds
Return parameter		
Example	MANU:ACW:RAMP 999.9 Sets the ramp down time to 999.9 seconds.	

**MANU:ACW:GROUNDMODE**

Set →

→ Query

**Description** Sets or returns the ACW Ground Mode. The test must first be in ACW mode before this command can be used.

**Syntax** MANU:ACW:GROUNDMODE {ON|OFF}

**Query Syntax** MANU:ACW:GROUNDMODE?

**Parameter/** ON ACW Ground Mode ON

**Return parameter** OFF ACW Ground Mode OFF

**Example** MANU:ACW:GROUNDMODE OFF

Sets the ACW Ground Mode off.

Set →

→ Query

**MANU:ACW:MAXHold**

**Description** Sets or returns the ACW MAX Hold. The test must first be in ACW mode before this command can be used.

**Syntax** MANU:ACW:MAXHold {ON|OFF}

**Query Syntax** MANU:ACW:MAXHold?

**Parameter/** ON ACW MAX Hold ON

**Return parameter** OFF ACW MAX Hold OFF

**Example** MANU:ACW:MAXH OFF

Sets the ACW MAX Hold off.

Set →

→ Query

**MANU:ACW:PASShold**

**Description** Sets or returns the duration of ACW PASS Hold in seconds. The test must first be in ACW mode before this command can be used.

**Syntax** MANU:ACW:PASShold {<NR2>|ON}

**Query Syntax** MANU:ACW:PASShold?

**Parameter/** <NR2> 0 ~ 999.9 seconds

**Return parameter** ON Indefinite duration

**Example**                    `MANU:ACW:PASS 999.9`  
 Sets the ACW PASS Hold time to 999.9 seconds.

**MANU:ACW:REF**

Set →

→ Query

**Description**                    Sets or returns the ACW reference value in uA or mA. The test must first be in ACW mode before this command can be used.

The ACW reference value shares the identical limit of HI SET value, which is 42mA at the maximum. For instance, when HI SET value is set 10mA, the reference value can therefore be set up to 32mA.

Note: An “Err” message will be shown on display if the Ramp Time + Test Time is > 240 seconds when the HI SET limit + REF is ≥ 30mA for GPT-12XXX or HI SET limit + REF is ≥ 80mA for GPT-15XXX. This applies to the ACW function only. An “TIME OVER 240s” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

<b>Syntax</b>	<code>MANU:ACW:REF &lt;NR2&gt;</code>
<b>Query Syntax</b>	<code>MANU:ACW:REF?</code>
<b>Parameter/</b>	<code>&lt;NR2&gt;</code> 0.000 ~ 41.99 (mA) [GPT-12XXX]
<b>Return parameter</b>	0.000 ~ 109.9 (mA) [GPT-15XXX]

**Example**                    `MANU:ACW:REF 40`  
 Sets the ACW reference to 40 mA.

Set →

→ Query

**MANU:ACW:INITvoltage**

**Description**                    Sets or returns the ACW percentage of initial voltage. The test must first be in ACW mode before this command can be used.

**Syntax**                         `MANU:ACW:INITvoltage <NR1>`

**Query Syntax**                `MANU:ACW:INITvoltage?`

Parameter/ Return parameter	<code>&lt;NR1&gt;</code>	0 ~ 99%
--------------------------------	--------------------------	---------

Example            `MANU:ACW:INIT 87`  
                      Sets the ACW Initial Voltage to 87%.

(Set) →

**MANU:ACW:CONTACT**

→ (Query)

Description        Sets or returns the CONTACT CHK function on or off.  
                      Note: An “Err” message will be shown on display if the learned reference value is less than 30uA. An “LEARNING < 30uA” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

Syntax              `MANU:ACW:CONTACT {ON|OFF}`

Query Syntax        `MANU:ACW:CONTACT?`

Parameter/ Return parameter	ON	CONTACT CHK in ACW test ON
	OFF	CONTACT CHK in ACW test OFF

Example            `MANU:ACW:CONTACT OFF`  
                      Sets the CONTACT CHK off in ACW test.

(Set) →

**MANU:DCW:VOLTage**

→ (Query)

Description        Sets or returns the DCW voltage in kV. The test must first be in DCW mode before this command can be used.  
                      Note: An “Err” message will be shown on display if the DCW Voltage X (HI SET value + REF) is > 80 watts for GPT-12XXX or the DCW Voltage X HI SET value + REF is > 100 watts for GPT-15XXX. An “DC Over 50W” or “DC Over 100W” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

Syntax              `MANU:DCW:VOLTage <NR2>`

Query Syntax        `MANU:DCW:VOLTage?`

Parameter/ Return parameter	<NR2>	0.050 ~ 6.100 (kV)
--------------------------------	-------	--------------------

Example            MANU:DCW:VOLT 6  
                          Sets the DCW voltage to 6 kV.

(Set) →

**MANU:DCW:CHISet**

→ (Query)

Description       Sets or returns the DCW HI SET current value in milliamps. The test must first be in DCW mode before this command can be used.

Note: An “Err” message will be shown on display if the DCW Voltage X (HI SET value + REF) is > 50 watts for GPT-12XXX or the DCW Voltage X HI SET value + REF is > 100 watts for GPT-15XXX. An “DC Over 50W” or “DC Over 100W” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

Syntax             MANU:DCW:CHISet <NR2>

Query Syntax      MANU:DCW:CHISet?

Parameter/ Return parameter	<NR2>	0.001 ~ 11.00 (mA) [GPT-12XXX] 0.001 ~ 21.00 (mA) [GPT-15XXX]
--------------------------------	-------	--

Example            MANU:DCW:CHIS 5  
                          Sets the DCW HI SET current to 5mA.

(Set) →

**MANU:DCW:CLOSet**

→ (Query)

Description       Sets or returns the DCW LOW SET current value in milliamps. The LOW SET value must be less than the HI SET value. The test must first be in DCW mode before this command can be used.

The LOW SET range must use the HI SET range. If all the digits in the LOW SET range are outside the HI SET range, an Err will be produced. All digits outside the HI SET range are ignored and will not be used.

For example:

HI SET value: 10.99

LOW SET value: 11.00 → error

Syntax	MANU:DCW:CLOSet<NR2>	
Query Syntax	MANU:DCW:CLOSet?	
Parameter/	<NR2>	0.000 ~ 10.99 (mA) [GPT-12XXX]
Return parameter		0.000 ~ 20.99 (mA) [GPT-15XXX]
Example	MANU:DCW:CLOS 2.00 Sets the DCW LO SET current to 2mA.	

(Set) →

→ (Query)

### MANU:DCW:TTIME

Description	Sets or returns the DCW test time in seconds. The test must first be in DCW mode before this command can be used.	
Syntax	MANU:DCW:TTIME {<NR2> OFF}	
Query Syntax	MANU:DCW:TTIME?	
Parameter	<NR2>	0.3 ~ 999.9 seconds
	OFF	TIMER OFF
Return parameter	<NR2>	0.3 ~ 999.9 seconds
	TIME OFF	TIMER is OFF
Example	MANU:DCW:TTIM 1 Sets the DCW test time to 1 second.	

**MANU:DCW:ARCFUNCTION**

Set →

→ Query

Description	Sets or returns the DCW ARC function. The test must first be in DCW mode before this command can be used. Note that this command is only workable when ARC SET>HI SET.	
Syntax	MANU:DCW:ARCFUNCTION	
Query Syntax	{OFF ON_CONT ON_STOP}	
	MANU:DCW:ARCFUNCTION?	
Parameter/ Return parameter	OFF	ARC function off
	ON_CONT	ARC function ON & CONT
	ON_STOP	ARC function ON & STOP
Example	MANU:DCW:ARCF OFF Sets the DCW ARC function off.	

Set →

**MANU:DCW:ARCCURRENT**

→ Query

Description	Sets or returns the DCW ARC current value in mA. ARC must be enabled to set the ARC current. The test must first be in DCW mode before this command can be used.	
Syntax	MANU:DCW:ARCCURRENT <NR2>	
Query Syntax	MANU:DCW:ARCCURRENT?	
Parameter/ Return parameter	<NR2>	1.000 ~ 20.00 (mA) [GPT-12XXX]
		1.000 ~ 40.00 (mA) [GPT-15XXX]
Example	MANU:DCW:ARCC 10 Sets the DCW ARC value to 10mA.	

Set →

**MANU:DCW:ARCSPEED**

→ Query

Description	Sets or returns the DCW ARC speed. ARC must be enabled before the ARC speed can be set. The test must first be in DCW mode before this command can be used.	
-------------	---	--



Syntax	MANU:DCW:ARCSpeed {FAST NORMAL SLOW}	
Query Syntax	MANU:DCW:ARCSpeed?	
Parameter/ Return parameter	FAST	ARC speed fast
	NORMAL	ARC speed normal
	SLOW	ARC speed slow
Example	MANU:DCW:ARCS SLOW Sets the DCW ARC speed slow.	

Set →

→ Query

### MANU:DCW:WAITtime

Description	Sets or returns the DCW wait time in seconds. The test must first be in DCW mode before this command can be used.	
Syntax	MANU:DCW:WAITtime <NR2>	
Query Syntax	MANU:DCW:WAITtime?	
Parameter/ Return parameter	<NR2>	0 ~ 999.9 seconds
Example	MANU:DCW:WAIT 10.1 Sets the DCW wait time to 10.1 s.	

Set →

→ Query

### MANU:DCW:RAMPdown

Description	Sets or returns the DCW Ramp Down Time in seconds. The test must first be in DCW mode before this command can be used.	
Syntax	MANU:DCW:RAMPdown <NR2>	
Query Syntax	MANU:DCW:RAMPdown?	
Parameter/ Return parameter	<NR2>	0 ~ 999.9 seconds
Example	MANU:DCW:RAMP 999.9 Sets the DCW ramp down time to 999.9 seconds.	

**MANU:DCW:GROUNDMODE** (Set) →  
→ (Query)

Description	Sets or returns the DCW Ground Mode. The test must first be in DCW mode before this command can be used.	
Syntax	MANU:DCW:GROUNDMODE {ON OFF}	
Query Syntax	MANU:DCW:GROUNDMODE?	
Parameter/ Return parameter	ON	DCW Ground Mode ON
	OFF	DCW Ground Mode OFF
Example	MANU:DCW:GROUNDMODE OFF Sets the DCW Ground Mode off.	

**MANU:DCW:MAXHold** (Set) →  
→ (Query)


Description	Sets or returns the DCW MAX Hold. The test must first be in DCW mode before this command can be used.	
Syntax	MANU:DCW:MAXHold {ON OFF}	
Query Syntax	MANU:DCW:MAXHold?	
Parameter/ Return parameter	ON	DCW MAX Hold ON
	OFF	DCW MAX Hold OFF
Example	MANU:DCW:MAXH OFF Sets the DCW MAX Hold off.	

**MANU:DCW:PASShold** (Set) →  
→ (Query)

Description	Sets or returns the duration of DCW PASS Hold. The test must first be in DCW mode before this command can be used.	
Syntax	MANU:DCW:PASShold {<NR2> ON}	
Query Syntax	MANU:DCW:PASShold?	
Parameter/ Return parameter	<NR2>	0 ~ 999.9 seconds
	ON	Indefinite duration

Example            MANU:DCW:PASS 999.9  
                      Sets the DCW PASS Hold time to 999.9 seconds.

**MANU:DCW:REF**



Description       Sets or returns the DCW reference value in uA or mA. The test must first be in DCW mode before this command can be used.


The DCW reference value shares the identical limit of HI SET value, which is 11mA at the maximum. For instance, when HI SET value is set 5mA, the reference value can therefore be set up to 6mA.

Note: An “Err” message will be shown on display if the DCW Voltage X (HI SET value + REF) is > 50 watts for GPT-12XXX or the DCW Voltage X HI SET value + REF is > 100 watts for GPT-15XXX. An “DC Over 50W” or “DC Over 100W” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

Syntax	MANU:DCW:REF <NR2>	
Query Syntax	MANU:DCW:REF?	
Parameter/ Return parameter	<NR2>	0.000 ~ 10.99 (mA) [GPT-12XXX] 0.000 ~ 20.99 (mA) [GPT-15XXX]

Example            MANU:DCW:REF 10  
                      Sets the DCW reference to 10 mA.

**MANU:DCW:INITvoltage**



Description       Sets or returns the DCW percentage of initial voltage. The test must first be in DCW mode before this command can be used.

Syntax	MANU:DCW:INITvoltage <NR1>	
Query Syntax	MANU:DCW:INITvoltage?	
Parameter/ Return parameter	<NR1>	0 ~ 99%

Example            MANU:DCW:INIT 87  
                      Sets the DCW Initial Voltage to 87%.

Set →

**MANU:DCW:CONTACT**

→ Query

Description       Sets or returns the CONTACT CHK function on or off.  
                      Note: An “Err” message will be shown on display if the learned reference value is less than 30uA. An “LEARNING < 30uA” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

Syntax             MANU:DCW:CONTACT {ON|OFF}

Query Syntax      MANU:DCW:CONTACT?

Parameter/	ON	CONTACT CHK in DCW test ON
Return parameter	OFF	CONTACT CHK in DCW test OFF

Example            MANU:DCW:CONTACT OFF  
                      Sets the CONTACT CHK off in DCW test.

Set →

**MANU:IR:VOLTage**

→ Query

Description       Sets or returns the IR voltage in kV. The test must first be in IR mode before this command can be used.

Syntax             MANU:IR:VOLTage <NR2>

Query Syntax      MANU:IR:VOLTage?

Parameter/	<NR2>	0.05 ~ 1.2 (0.05kV to 1.2kV: steps of .05)
Return parameter		

Example            MANU:IR:VOLT 1  
                      Sets the IR voltage to 1 kV.

Set →

→ Query

**MANU:IR:RHISet**

**Description** Sets or returns the IR HI SET resistance value in MΩ or GΩ. The test must first be in IR mode before this command can be used.

**Syntax** MANU:IR:RHISet <NR2>|NULL

**Query Syntax** MANU:IR:RHISet?

<b>Parameter/ Return parameter</b>	<NR2>	000.2M ~ 999.9M (Ω) 1.000G ~ 9.999G (Ω) 10.00G ~ 50.00G (Ω)
	NULL	Sets the HI SET value to OFF.

**Example** MANU:IR:RHIS 10M  
Sets the IR HI SET resistance to 10 MΩ.

Set →

→ Query

**MANU:IR:RLOSet**

**Description** Sets or returns the IR LO SET resistance value in MΩ or GΩ. The LO SET value must be less than the HI SET value. The test must first be in IR mode before this command can be used.

**Syntax** MANU:IR:RLOSet<NR2>

**Query Syntax** MANU:IR:RLOSet?

<b>Parameter/ Return parameter</b>	<NR1>	000.1M ~ 999.9M (Ω) 1.000G ~ 9.999G (Ω) 10.00G ~ 50.00G (Ω)
--	-------	---

**Example** MANU:IR:RLOS 10M  
Sets the IR LO SET resistance to 10MΩ.


Set →

→ Query

**MANU:IR:TTIME**


**Description** Sets or returns the IR test time in seconds. The test must first be in IR mode before this command can be used.

Syntax	MANU:IR:TTIMe <NR2>
Query Syntax	MANU:IR:TTIMe?
Parameter/ Return parameter	<NR2> 0.3 ~ 999.9 seconds
Example	MANU:IR:TTIM 1 Sets the IR test time to 1 second.



**MANU:IR:WAITtime**

Description	Sets or returns the IR wait time in seconds. The test must first be in IR mode before this command can be used.
Syntax	MANU:IR:WAITtime <NR2>
Query Syntax	MANU:IR:WAITtime?
Parameter/ Return parameter	<NR2> 0 ~ 999.9 seconds
Example	MANU:IR:WAIT 10.1 Sets the IR wait time to 10.1 s.



**MANU:IR:RAMPdown**

Description	Sets or returns the IR Ramp Down Time in seconds. The test must first be in IR mode before this command can be used.
Syntax	MANU:IR:RAMPdown <NR2>
Query Syntax	MANU:IR:RAMPdown?
Parameter/ Return parameter	<NR2> 0 ~ 999.9 seconds
Example	MANU:IR:RAMP 999.9 Sets the IR ramp down time to 999.9 seconds.

**MANU:IR:GROUNDMODE**

Set →

→ Query

**Description**      Sets or returns the IR Ground Mode. The test must first be in IR mode before this command can be used.

**Syntax**            MANU:IR:GROUNDMODE {ON|OFF}

**Query Syntax**    MANU:IR:GROUNDMODE?

**Parameter/**      ON                  IR Ground Mode ON

**Return parameter** OFF                IR Ground Mode OFF

**Example**            MANU:IR:GROUNDMODE OFF

                         Sets the IR Ground Mode off.

Set →

→ Query

**MANU:IR:MAXHold**

**Description**      Sets or returns the IR MAX Hold. The test must first be in IR mode before this command can be used.

**Syntax**            MANU:IR:MAXHold {ON|OFF}

**Query Syntax**    MANU:IR:MAXHold?

**Parameter/**      ON                  IR MAX Hold ON

**Return parameter** OFF                IR MAX Hold OFF

**Example**            MANU:IR:MAXH OFF

                         Sets the IR MAX Hold off.

**MANU:IR:PASShold**

Set →

→ Query

**Description** Sets or returns the duration of IR PASS Hold. The test must first be in IR mode before this command can be used.

**Syntax** MANU:IR:PASShold {<NR2>|ON}

**Query Syntax** MANU:IR:PASShold?

**Parameter/** <NR2> 0 ~ 999.9 seconds

**Return parameter** ON Indefinite duration

**Example** MANU:IR:PASS 999.9

Sets the IR PASS Hold time to 999.9 seconds.

Set →

→ Query

**MANU:IR:REF**

**Description** Sets or returns the IR reference value in MΩ or GΩ. The test must first be in IR mode before this command can be used.

**Syntax** MANU:IR:REF <NR2>

**Query Syntax** MANU:IR:REF?

**Parameter/** <NR2> 000.0M ~ 999.9M (Ω)

**Return parameter** 1.000G ~ 9.999G (Ω)

10.00G ~ 50.00G (Ω)

**Example** MANU:IR:REF 900M

Sets the IR reference to 900 MΩ.



**MANU:IR:MODE**

Set →

→ Query

**Description** Sets or returns the IR Mode in IR. The test must first be in IR mode before this command can be used.

**Syntax** MANU:IR:MODE  
**Query Syntax** {STOP\_ON\_FAIL|STOP\_ON\_PASS|TIMER}  
 MANU:IR:MODE?

<b>Parameter/</b>	STOP_ON_FAIL	IR Mode in Stop On FAIL
<b>Return parameter</b>	STOP_ON_PASS	IR Mode in Stop On PASS
	TIMER	IR Mode in Timer

**Example** MANU:IR:MODE TIMER  
 Sets the IR Mode in Timer setting.

Set →

→ Query

**MANU:IR:CONTACT**

**Description** Sets or returns the CONTACT CHK function on or off.  
 Note: An “Err” message will be shown on display if the learned reference value is less than 30uA. An “LEARNING < 30uA” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

**Syntax** MANU:IR:CONTACT {ON|OFF}  
**Query Syntax** MANU:IR:CONTACT?

<b>Parameter/</b>	ON	CONTACT CHK in IR test ON
<b>Return parameter</b>	OFF	CONTACT CHK in IR test OFF

**Example** MANU:IR:CONTACT OFF  
 Sets the CONTACT CHK off in IR test.

Set →

**MANU:IR:FILTer**

→ Query

Description	Sets or returns the FILTER function for IR test.	
Syntax	MANU:IR:FILT {OFF   LEVEL1   LEVEL2}	
Query Syntax	MANU:IR:FILT?	
Parameter/ Return parameter	OFF	FILTER in IR test Off
	LEVEL 1	FILTER in IR test Level 1
	LEVEL 2	FILTER in IR test Level 2
Example	MANU:IR:FILT OFF Sets the FILTER off in IR test.	

Set →

**MANU:IR:GNDOFFSET**

→ Query

Description	Sets or returns the GND Offset function for IR test.	
Syntax	MANU:IR:GNDOFFSET {ON   OFF}	
Query Syntax	MANU:IR:GNDOFFSET?	
Parameter/ Return parameter	ON	GDN Offest in IR test On
	OFF	GDN Offest in IR test Off
Example	MANU:IR:GNDOFFSET OFF Sets the GND Offest off in IR test.	

Set →

**MANU:GB:CURRent**

→ Query

Description	Sets or returns the GB current in A. The test must first be in GB mode before this command can be used.	
Syntax	MANU:GB:CURRent <NR2>	
Query Syntax	MANU:GB:CURRent?	
Parameter/ Return parameter	<NR2>	3.00~33.00
Example	MANU:GB:CURR 3.00 Sets the GB current to 3.00A.	

## MANU:GB:RHISet

Set →

→ Query

Description	Sets or returns the GB HI SET resistance value in mΩ. The test must first be in GB mode before this command can be used.
Syntax	MANU:GB:RHISet <NR2>
Query Syntax	MANU:GB:RHISet?
Parameter/ Return parameter	<NR2> 000.1 ~ 650.0 (mΩ)
Example	MANU:GB:RHIS 100.0 Sets the GB HI SET value to 100mΩ.



## Note

If the GB current x (HI SET resistance + REF) > 7.2V, an “Err” message will be shown on display. And an “GBV > 7.2V” message will be returned after using the query command “SYSTem:ERRor ?” in remote control.

Set →

**MANU:GB:RLOSet**

→ Query

Description	Sets or returns the GB LOW SET resistance value in mΩ. The LOW SET value must be less than the HI SET value. The test must first be in GB mode before this command can be used.
Syntax	MANU:GB:RLOSet<NR2>
Query Syntax	MANU:GB:RLOSet?
Parameter/ Return parameter	<NR2> 0.000 ~ 649.9 (mΩ)
Example	MANU:GB:RLOS 50 Sets the GB LO SET resistance to 50mΩ.

Set →

**MANU:GB:TTIME**

→ Query

Description	Sets or returns the GB test time in seconds. The test must first be in GB mode before this command can be used.
Syntax	MANU:GB:TTIME <NR2>
Query Syntax	MANU:GB:TTIME?
Parameter/ Return parameter	<NR2> 0.3 ~ 999.9 seconds
Example	MANU:GB:TTIM 1 Sets the GB test time to 1 second.

Set →

**MANU:GB:FREQuency**

→ Query

Description	Sets or returns the GB test frequency in Hz. The test must first be in GB mode before this command can be used.
Syntax	MANU:GB:FREQuency {50 60}
Query Syntax	MANU:GB:FREQuency?
Parameter/ Return parameter	50 50 Hz

Return parameter 60 60 Hz

Example MANU:GB:FREQ 50  
Sets the GB test frequency to 50Hz.

Set →

**MANU:GB:CONtact**

→ Query

Description Sets or returns the GB Contact Time in seconds. The test must first be in GB mode before this command can be used.

Syntax MANU:GB:CONtact <NR2>

Query Syntax MANU:GB:CONtact?

Parameter/ Return parameter <NR2> 0 ~ 999.9 seconds

Example MANU:GB:CONtact 999.9  
Sets the GB Contact time to 999.9 seconds.

Set →

**MANU:GB:GROUNDMODE**

→ Query

Description Sets or returns the GB Ground Mode. The test must first be in GB mode before this command can be used.

Syntax MANU:GB:GROUNDMODE {ON|OFF}

Query Syntax MANU:GB:GROUNDMODE?

Parameter/ Return parameter ON GB Ground Mode ON  
OFF GB Ground Mode OFF

Example MANU:GB:GROUNDMODE OFF  
Sets the GB Ground Mode off.

Set →

**MANU:GB:MAXHold**

→ Query

Description Sets or returns the GB MAX Hold. The test must first be in GB mode before this command can be used.

Syntax	MANU:GB:MAXHold {ON OFF}	
Query Syntax	MANU:GB:MAXHold?	
Parameter/ Return parameter	ON OFF	GB MAX Hold ON GB MAX Hold OFF
Example	MANU:GB:MAXH OFF Sets the GB MAX Hold off.	

Set →

→ Query

### MANU:GB:PASShold

Description	Sets or returns the duration of GB PASS Hold. The test must first be in GB mode before this command can be used.	
Syntax	MANU:GB:PASShold {<NR2> ON}	
Query Syntax	MANU:GB:PASShold?	
Parameter/ Return parameter	<NR2> ON	0 ~ 999.9 seconds Indefinite duration
Example	MANU:GB:PASS 999.9 Sets the GB PASS Hold time to 999.9 seconds.	

Set →

→ Query

### MANU:GB:REF

Description	Sets or returns the GB reference value in mΩ. The test must first be in GB mode before this command can be used.  Beware that when ISET x (HIEST + REF) is greater than 7.2V, an “Err” message will be shown on display. And an “GBV > 7.2V” message will be returned after using the query command “SYSTEM:ERRor ?” in remote control.	
Syntax	MANU:GB:REF <NR2>	
Query Syntax	MANU:GB:REF?	
Parameter/ Return parameter	<NR2>	0.000 ~ 650.0 (mΩ)

Example            MANU:GB:REF 100  
                      Sets the GB reference to 100 m $\Omega$ .

Set →

**MANU:GB:ZEROCHECK**

→ Query

Description       Performs the zero check function. The test must first be in GB mode and in the Ready Status before this command can be used.

See page 71 for details on the ZERO function.

Syntax             MANU:GB:ZEROCHECK {ON|OFF}

Query Syntax      MANU:GB:ZEROCHECK?

Parameter/ Return parameter	ON	Zero function is active.
	OFF	Zero function is not active.

Example            MANU:GB:ZEROCHECK OFF  
                      Activates the GB ZERO function.

Set →

**MANU:CONTInuity:RHISet**

→ Query

Description       Sets or returns the CONT HI SET resistance value in  $\Omega$ . The test must first be in CONT mode before this command can be used.

Syntax             MANU:CONTInuity:RHISet <NR2>

Query Syntax      MANU:CONTInuity:RHISet?

Parameter/ Return parameter	<NR2>	00.01 ~ 80.00 $\Omega$
--------------------------------	-------	------------------------

Example            MANU:CONT:RHIS 30.0  
                      Sets the CONT HI SET resistance to 30  $\Omega$ .

**MANU:CONTinuity:RLOSet**

Set →

→ Query

**Description** Sets or returns the CONT LOW SET resistance value in  $\Omega$ . The LOW SET value must be less than the HI SET value. The test must first be in CONT mode before this command can be used.

The LOW SET range must use the HI SET range. If all the digits in the LOW SET range are outside the HI SET range, an Err message will be produced. All digits outside the HI SET range are ignored and will not be used.

For example:

HI SET value: 10.00

LOW SET value: 10.01 → error

**Syntax** MANU:CONTinuity:RLOSet <NR2>

**Query Syntax** MANU:CONTinuity:RLOSet?

**Parameter/Return parameter** <NR2> 00.00 ~ 79.99  $\Omega$

**Example** MANU:CONT:RLOS 20.0  
Sets the CONT LO SET resistance to 20  $\Omega$ .

Set →

→ Query

**MANU:CONTinuity:TTIME**

**Description** Sets or returns the CONT test time in seconds. The test must first be in CONT mode before this command can be used.

**Syntax** MANU:CONTinuity:TTIME <NR2>

**Query Syntax** MANU:CONTinuity:TTIME?


**Parameter** <NR2> 0.3 ~ 999.9 seconds

**Return parameter** <NR2> 0.3 ~ 999.9 seconds

**Example** MANU:CONT:TTIM 1  
Sets the CONT test time to 1 second.




**MANU:CONTInuity:PASShold**



Description	Sets or returns the duration of CONT PASS Hold. The test must first be in CONT mode before this command can be used.
Syntax	MANU:CONTInuity:PASShold {<NR2> ON}
Query Syntax	MANU:CONTInuity:PASShold?
Parameter/ Return parameter	<NR2> 0 ~ 999.9 seconds ON Indefinite duration
Example	MANU:CONT:PASS 999.9 Sets the CONT PASS Hold time to 999.9 seconds.

**MANU:CONTInuity:REF**



Description	Sets or returns the CONT reference value in $\Omega$ . The test must first be in CONT mode before this command can be used.  Note: when HI SET+REF VALUE is over 80 $\Omega$ , an "Err" message will be shown on display. And an "CONT Setting Over 8V" message will be returned after using the query command "SYSTem:ERRor ?" in remote control.
Syntax	MANU:CONTInuity:REF <NR2>
Query Syntax	MANU:CONTInuity:REF?
Parameter/ Return parameter	<NR2> 00.00 ~ 79.99 $\Omega$
Example	MANU:CONT:REF 0.01 Sets the CONT reference to 00.01 $\Omega$ .

**MANU:CONTinuity:ZEROCHECK**

Set →

→ Query

**Description**      Performs the zero check function. The test must first be in CONT mode and in the Ready Status before this command can be used.

See page 71 for details on the ZERO function.

**Syntax**              MANU:CONTinuity:ZEROCHECK {ON|OFF}

**Query Syntax**      MANU:CONTinuity:ZEROCHECK?

**Parameter/**        ON            Zero function is active.

**Return parameter** OFF            Zero function is not active.

**Example**            MANU:CONT:ZEROCHECK OFF

Deactivates the CONT ZERO function.

## Auto Commands

AUTO:STEP .....239  
 AUTO:NAME .....240  
 AUTO:EDIT:ADD .....241  
 AUTO<x>:EDIT:HOLD .....242  
 AUTO<x>:EDIT:SKIP .....242  
 AUTO:EDIT:DEL .....243  
 AUTO:TEST:RETURN .....243  
 AUTO:EDIT:SHOW .....244

### AUTO:STEP

Set →

→ Query

Description	Sets or queries the AUTO number (automatic test number).
Syntax	AUTO:STEP <NR1>
Query Syntax	AUTO:STEP?
Parameter/ Return parameter	<NR1> 1~100
Example	AUTO:STEP 100 Sets the current AUTO number to 100

Set →

→ Query

**AUTO:NAME**

**Description** Sets or returns the AUTO name for the selected automatic test. The test must be in AUTO mode before this command can be used.

Note only alphanumeric characters (A-Z, a-z, 0-9) and the “\_” underscore character can be used to set the AUTO test name.


**Syntax** AUTO:NAME <”string”>

**Query Syntax** AUTO:NAME?

**Parameter/Return parameter** <”string”> 10 character string.

**Example** AUTO:NAME “program1”  
Sets the AUTO name to “program1”.

## AUTO:EDIT:ADD




---

Description      Add the selected MANU test to the current AUTO number.

---

Syntax            AUTO:EDIT:ADD {<NR1>|CON}

---

Parameter/      <NR1>    1~100  
                       CON        Continuous step

---

Example            AUTO:EDIT:ADD 7  
                       Adds MANU STEP 007 to the current AUTO number.

---



## Note

An “Err” message will be shown on display when 10 groups have been added into AUTO already and user still sends the command “AUTO:EDIT:ADD”. An “Auto Step Add Full” message will be returned after using the query command SYSTem:ERRor ?.

When “CON” is configured within AUTO and user still sends the command “AUTO:EDIT:ADD”, an “Err” message will be shown on display. An “This Is Last Step” message will be returned after using the query command SYSTem:ERRor ?.

**AUTO<x>:EDIT:HOLD** 


Description	Sets or returns the actions for STEP HOLD of each MANU STEP in AUTO test.	
Syntax	AUTO<x>:EDIT:HOLD {PH_FH PH_FS PH_FC  PC_FH PC_FS PC_FC}	
Query Syntax	AUTO<x>:EDIT:HOLD?	
Parameter/	<x>	MAMU step 1 ~ 10
Return parameter	PH_FH	Sets Pass Hold & Fail Hold action
	PH_FS	Sets Pass Hold & Fail Stop action
	PH_FC	Sets Pass Hold & Fail Continue action
	PC_FH	Sets Pass Continue & Fail Hold action
	PC_FS	Sets Pass Continue & Fail Stop action
	PC_FC	Sets Pass Continue & Fail Continue action
Example	<p>AUTO1:EDIT:HOLD PH_FH</p> <p>Sets the Pass Hold &amp; Fail Hold action for MANU STEP 1 in the current AUTO test.</p>	

**AUTO<x>:EDIT:SKIP** 


Description	Sets or returns the SKIP action for each MANU STEP in AUTO test.	
Syntax	AUTO<x>:EDIT:SKIP {ON OFF}	
Query Syntax	AUTO<x>:EDIT:SKIP?	
Parameter/	<x>	Sets MANU STEP from 1 - 10 for skip
Return parameter	ON	Turns SKIP action for the designated MANU STEP on
	OFF	Turns SKIP action for the designated MANU STEP off
Example	<p>AUTO1:EDIT:SKIP ON</p> <p>Enables SKIP function for MANU STEP 1 in AUTO test.</p>	

## AUTO:EDIT:DEL

Set →

Description	Deletes the designated MANU STEP within the current AUTO test.	
Syntax	AUTO:EDIT:DEL {<NR1> ALL}	
Parameter	<NR1>	Deletes selected MANU STEP from 1 - 10
	ALL	Deletes all the MANU STEPs
Example	AUTO:EDIT:DEL 3 Deletes the MANU STEP 3 from the current AUTO test.	

## AUTO:TEST:RETURN

→ Query

Description	Returns the number of AUTO test and MANU STEP that is being tested currently.	
Query Syntax	AUTO:TEST:RETURN?	
Return parameter	String	The returned string will be in the format of AUTO number followed by MANU STEP number. AUTO-XXX,STEP-XX
Example	AUTO:TEST:RETURN? AUTO-004,STEP-03 The MANU STEP-03 of AUTO-004 is being tested.	

**AUTO:EDIT:SHOW**

→ **Query**

Description	Returns all the information of the current AUTO test page.	
Query Syntax	AUTO:EDIT:SHOW?	
Return parameter	String	The returned strings will be shown in the way almost identical to the contents displayed on an AUTO test page.
Example	<pre> AUTO:EDIT:SHOW? &gt;AUTO-001 AUTO_NAME &gt;STEP,MODE,V/I SET,HI SET ,LOW SET,STEP HOLD &gt;_____ &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C &gt;001 ,ACW ,0.100kV,1.000mA,000 uA,P.C/F.C                 </pre>	



## Sweep Commands

SWEEP:DATA:STATus .....245  
 SWEEP:DATA:SHOW .....245  
 SWEEP:GRAPh:SHOW .....246

### SWEEP:DATA:STATus → Query

Description	Returns the basic status of get data.
Query Syntax	SWEEP:DATA:STA?
Return parameter	<String> The returned string will be in the format below: STEP, TEST MODE, V SET, HI SET, TOTAL DATA
Example	SWEEP:DATA:STA? > STEP, MODE, V SET , HI SET , TOTAL DATA 000 , DCW , 0.450kV, 1.700mA, 00076

### SWEEP:DATA:SHOW → Query

Description	Returns the full measured readings of get data.
Query Syntax	SWEEP:DATA:SHOW<NR1>
Return parameter	<NR1> 0~10000 0 stands for the full steps. 1~10000 indicates the designated step.
Example	SWEEP:DATA:SHOW 0 > TIMER , READ V, READ I 0000.1s , 0.003kV, 007uA 0000.2s , 0.008kV, 026uA 0000.3s , 0.019kV, 064uA 0000.4s , 0.028kV, 095uA 0000.5s , 0.037kV, 126uA 0000.6s , 0.045kV, 153uA

**SWEEP:GRAPh:SHOW**

Set →

→ Query

Description	Displays or turns off Sweep graph on LCD screen. Also Returns if Sweep graph is shown on LCD.	
Syntax	SWEEP:GRAPh:SHOW {ON OFF}	
Query Syntax	SWEEP:GRAPh:SHOW?	
Parameter/	ON	To enable Sweep graph on LCD
Return parameter	OFF	To disable Sweep graph on LCD
	?	Returns if Sweep graph is shown on LCD
Example	SWEEP:GRAP:SHOW? > OFF Sweep graph is Not displayed on LCD screen.	

## Common Commands

*CLS.....	247
*IDN .....	247
*SRE.....	248

\*CLS (Set) →

Description	The *CLS command clears the internal registers and error message, if any.
-------------	---

Syntax	*CLS
--------	------

\*IDN → (Query)

Description	Queries the model number, serial number, and firmware version of the tester.
-------------	--

Query Syntax	*IDN?
--------------	-------

Return parameter	<string>	Returns the instrument identification as a string in the following format: >GPT-12004 ,GPT12000 ,V1.00 Model number : GPT-12004 Serial number :8 characters serial number Firmware version : V1.00
------------------	----------	--

**\*SRE** → Query

Description	AUTO MODE only. Use this command to get measurement step number at the current point in time during AUTO MODE testing.
Query Syntax	*SRE?
Return parameter	<NR1> 00~50
Example	<p>*SRE?</p> <p>&gt;5</p> <p>The current test step is number 5. This indicates that steps 1~4 have already been completed and the results for those steps can now be retrieved.</p>

**Remote Commands**

\*RMTOFF .....248

**\*RMTOFF** Set →

Description	This command can be used to terminate a remote session. When this command is used “RMT” will no longer be displayed on the front panel, indicating that remote mode has been terminated.
Syntax	*RMTOFF

## Error Messages

Background The possible error messages returned from SYST:ERR? query are well listed below.

Error	Error Code
No Error	0
Command Error	20
Value Setting Error	21
String Setting Error	22
Query Error	23
MODE Error	24
TIME Error	25
DC Over 50W (GPT-12XXX)	26
DC Over 100W (GPT-15XXX)	26
GBV > 7.2V	27
ARC <= HI Set	28
HI Set => ARC	29
Voltage Setting Error	30
Current Setting Error	31
Current HI Set Error	32
Current LO Set Error	33
Resistance HI Set Error	34
Resistance LO Set Error	35
REF Setting Error	36
Frequency Setting Error	37
ARC Setting Error	38
RAMP Time Setting Error	39
TEST Time Setting Error	40
WAIT Time Setting Error	41
RAMP Down Setting Error	42
PASS Hold Setting Error	43
GB Contact Setting Error	44
Setting Over 200W	45
CONT Setting Over 8V	46
Auto Step Add Full	47
This Is The Last Step	48
Learning less than 30uA	49
USB DISK BUSY	50

Read Buffer Error	70
Send Buffer Error	71

---

# F FAQ

- 
- The tester will not turn on.
  - The panel keys are not working.
  - The measured value of IR, GB or Continuity test does not match the specification.
  - When I press the START button the tester will not start testing?

## The tester will not turn on?

---

Ensure the power cord is connected. Check and make sure the fuse is not blown and properly installed. See page 254.

## The panel keys are not working?

---

Ensure the tester is not in the SIGNAL I/O or Remote Control mode (page 135). If it is, refer to page 184 for how to return to front panel control. Also, if Key Lock is enabled, all panel keys except START and STOP are disabled. Refer to page 136 for details.

## The measured value of IR test does not match the specification?

---

Make sure the tester is powered on for warm-up of at least 30 minutes, within +15°C~+35°C. This is necessary to stabilize the tester to match the specification. After warm-up, please proceed to Contact Check procedure.

## The measured value of GB test does not match the specification?

---

Make sure the tester is powered on for warm-up of at least 30 minutes, within +15°C~+35°C. This is necessary to stabilize the

tester to match the specification. After warm-up, please proceed to Zero Check procedure. Refer to page 71 for details.

The measured value of Continuity test does not match the specification?

---

Make sure the tester is powered on for warm-up of at least 30 minutes, within +15°C~+35°C. This is necessary to stabilize the tester to match the specification. After warm-up, please proceed to Zero Check procedure. Refer to page 71 for details.



When I press the START button the tester will not start testing?

---

The tester must first be in the READY status before a test can be started. Ensure the tester displays READY before pressing the START button, page 85 (manual test), 113 (automatic test).

If Double Action is enabled, the START button must be pressed within 0.5 seconds after the STOP button is pressed, otherwise the tester will not start testing.

If Interlock is enabled, the interlock key must be inserted into the signal I/O port on the rear before a test starts. See page 178.

Lastly, if Start Click For 1 Second is enabled, it is required to press and hold the START button for 1 second above to initiate a test. Pressing the START button below 1 second will not start a test.

For more information, contact your local dealer or GWInstek at [www.gwinstek.com](http://www.gwinstek.com) / [marketing@goodwill.com.tw](mailto:marketing@goodwill.com.tw).


# APPENDIX

## Fuse Replacement


---

Steps


1. Turn the instrument off.




2. Remove the power cord.



3. Remove the fuse socket using a flat screwdriver.



4. Replace the fuse in the fuse holder.



Fuse Rating

**GPT-12000**

T 4A, 250V

**GPT-15000**

T 10A, 250V

## Tester Errors

The following test error messages highlighted in red may appear on the GPT-10000 display when completing a running test.

Test Error	Description
HI FAIL	Test result is beyond the HI SET value
LOW FAIL	Test result is below the LOW SET value
V OVER	Measured voltage is beyond the set value by 1.1 times
V LOW	Measured voltage is below the set value by 0.9 time
SHORT	Voltage short-circuit detected
GBI OVER	Measured current is beyond the set value by 1.1 times
GBI LOW	Measured current is below the set value by 0.9 time
GBV OVER	Measured GB voltage is beyond 7.2V
CONT V ERR	Measured CONT voltage is beyond 8.0V
ARC ERR	ARC abnormality detected
GFCI ERR	Ground current abnormality detected
SHORT (CONTACT CHK)	CONTACT CHK greater than HI Limit detected
OPEN (CONTACT CHK)	CONTACT CHK lower than LOW Limit detected

The following setup error messages highlighted in red may appear on the GPT-10000 display when abnormality occurs in the settings of MANU steps.

Setup Error	Description
TEST MODE ERROR	Setting error in ACW/DCW
VOLTAGE SET ERROR	Setting error in voltage
CURRENT SET ERROR	Setting error in current
MANU STEP ERROR	Setting error in MANU STEP value
MANU NAME ERROR	Setting error in MANU NAME
HI SET ERROR	Setting error in HI SET value
HISSET <= LOWSET	Set value of HI SET is less than or equal to LOW SET value

HISET >= ARC	Set value of HI SET is greater than or equal to ARC SET value
LOW SET ERROR	Setting error in LOW SET
TEST TIME ERROR	Setting error in TEST TIME
RAMP TIME ERROR	Setting error in RAMP TIME
ARC FUNC ERROR	Setting error in ARC FUNC
ARC SET ERROR	Setting error in ARC SET
ARC SPEED ERROR	Setting error in ARC SPEED
FREQ SET ERROR	Setting error in FREQ of ACW/GB
WAIT > TEST+RAMP	Setting error in WAIT TIME
GB CONTACT ERROR	Setting error in GB CONTACT
RAMP DOWN ERROR	Setting error in RAMP DOWN
GROUND ERROR	Setting error in GROUND MODE
MAX HOLD ERROR	Setting error in MAX HOLD
PASS HOLD ERROR	Setting error in PASS HOLD
REF SET ERROR	Setting error in REF VALUE
GBV OVER	Setting Error in ISET x (HI SET + REF) > 7.2V of GB Mode
INIT VSET ERROR	Setting error in INIT VOLTAGE
IR MODE ERROR	Setting error in IR MODE
DCW OVER 50W (GPT-12XXX)	Setting error in $V * I > 50W$ of DCW Mode
DCW OVER 100W (GPT-15XXX)	Setting error in $V * I > 100W$ of DCW Mode
GB OVER 200W	Setting error in $V * I > 200W$ of GB Mode
ZERO SET ERROR	Setting Error in ZERO CHECK
CONT. TEST V OVER	Setting Error in ISET(100mA) x (HI SET + REF) > 8V of CONT Mode
TIME OVER 240s (GPT-12XXX)	TIME OVER 240s is displayed when, under ACW test mode, HI SET is greater than 30mA and the RAMP TIME plus the TEST TIME setting is > 240 seconds.
TIME OVER 240s (GPT-15XXX)	TIME OVER 240s is displayed when, under ACW test mode, HI SET is greater than 80mA and the RAMP TIME plus the TEST TIME setting is > 240 seconds.

---

TEST TIME<0.5s	TEST TIME<0.5s is displayed when test time, under IR test mode with Ground mode ON, is below 0.5 second.
CONTACT ERROR	Setting error in CONTACT of ACW, DCW or IR.
LEARNING < 30uA	The learned reference value of CONTACT CHK is less than 30uA and thus CONTACT CHK function will be invalid.

---

## Factory Default Parameters

### DISPLAY SET

Brightness	5
Language	ENGLISH

### BUZZER

Volume	3
Key Sound	ON

### INTERFACE

Interface	RS-232
Baud Rate	9600

### CONTROL

Control By	Front Panel	
	SIGNAL IO -->	OUT1:READY
		OUT2:TEST
		OUT3:PASS
		OUT4:FAIL
		OUT5:FAIL_H
Double Action	OFF	
Key Lock	OFF	
Interlock	OFF	
Start Click For 1 Second	OFF	
Power GND Check	OFF	
Barcode Function Setting	Delete set data of 100 groups	

**STATISTICS**

TOTAL AMOUNT =	0
PASS AMOUNT =	0
FAIL AMOUNT =	0
ACW PASS DATA	0
ACW FAIL DATA	0
DCW PASS DATA	0
DCW FAIL DATA	0
IR PASS DATA	0
IR FAIL DATA	0
GB PASS DATA	0
GB FAIL DATA	0
CONT PASS DATA	0
CONT FAIL DATA	0

**USB DISK**

USB Disk Auto Data Save	OFF
File Name	Logfile_
Internal Memory Save	OFF

**CONTACT CHK**

Hi Limit	200%
Low Limit	50%
Learning	000 $\mu$ A

## GPT-10000 Specifications

The specifications apply when the GPT-10000 is powered on for at least 30 minutes at 15°C~35°C.

### Specifications

#### General

DISPLAY	7" color LCD	
MEMORY	AUTO/MANU mode 100 memory blocks total	
POWER SOURCE	AC 100V~240V ± 10%, 50Hz/60Hz	
POWER CONSUMPTION	GPT-15XXX	1000VA Max.
	GPT-12XXX	400VA Max.
ACCESSORIES	GPT-15XXX	Power cord x1 Quick Start Guide x1 User Manual x1 (CD) GHT-115 x1 for GPT-15001/2/3 GHT-115 x1, GTL-215 x1 for GPT-15004
	GPT-12XXX	Power cord x1 Quick Start Guide x1 User Manual x1 (CD) GHT-115 x1 for GPT-12001/2/3 GHT-115 x1, GTL-215 x1 for GPT-12004
DIMENSIONS & WEIGHT	GPT-15001	380(W) x 148(H) x 492(D), 17kg (Approx)
	GPT-15002	
	GPT-15003	
	GPT-15004	380(W) x 148(H) x 546(D), 21kg (Approx)
	GPT-12001	
	GPT-12002	380(W) x 148(H) x 436(D), 11kg (Approx)
GPT-12003		
GPT-12004	380(W) x 148(H) x 454(D), 15kg (Approx)	



**Environment**

Range	Temperature	Humidity
Warranty	15°C ~ 35°C	≤70% (No condensation)
Operation	0°C ~ 40°C	≤70% (No condensation)
Storage	-10°C ~ 70°C	≤85% (No condensation)
Installation Location	Indoors at an amplitude of up to 2000m.	

## AC Withstanding Voltage

Output Voltage Range	0.050kV~ 5.000kV <sup>1</sup>	
Output Voltage Resolution	1V	
Output Voltage Accuracy	± (1% of setting +5V) with no load	
Maximum Rated Load(Table1)	GPT-15XXX	500VA (5kV/100mA)
	GPT-12XXX	200VA (5kV/40mA)
Maximum Rated Current	GPT-15XXX	100mA
		0.001mA~10mA(0.05kV≤V≤0.5kV) 0.001mA~100mA(0.5kV<V≤5kV)
	GPT-12XXX	40mA
		0.001mA~10mA(0.05kV≤V≤0.5kV) 0.001mA~40mA(0.5kV<V≤5kV)
Output Voltage Waveform	Sine wave	
Frequency	50 Hz / 60 Hz	
Voltage Regulation	± (1% +5V)[Maximum rated load →no load]	
Voltmeter Accuracy	± (1% of reading+ 5 V)	
Current Measurement Range	GPT-15XXX	0.001mA~100.0mA
	GPT-12XXX	0.001mA~40.00mA
Current Best Resolution	GPT-15XXX	1uA
		1uA (1uA~9.999mA) 10uA(10.00mA~99.99mA) 100uA(100.0mA)
	GPT-12XXX	1uA
		1uA (1uA~9.999mA) 10uA(10.00mA~40.00mA)
Current Measurement Accuracy	± (1.5% of reading+30uA)	
Current Offset	60uA Maximum	
Judgment Accuracy	± (3% of setting+30uA)	
Window Comparator Method	Yes	
ARC DETECT	Yes	
Rise-time Control Function	Yes	
RAMP TIME (Rise Time)	0.1~999.9s	
Fall-time Control Function	Yes	
RAMP DOWN Time	0.0~999.9s	
TIMER (Test Time) <sup>2</sup>	OFF, 0.3s~999.9s	
TIMER Accuracy	+/- (100ppm+20ms)	
GND	ON/OFF	
WAIT TIME	0.0~999.9s	

<sup>1</sup> At least ramp 0.3 seconds is needed to reach a set voltage of 50V/10mA.

<sup>2</sup> Timer can only be turned off when the upper current is set below 30mA. (GPT-12XXX)

<sup>3</sup> Timer can only be turned off when the upper current is set below 80mA. (GPT-15XXX)

## DC Withstanding Voltage

Output Voltage Range	0.050kV~ 6.000kV <sup>1</sup>	
Output Voltage Resolution	1V	
Output Voltage Accuracy	±(1% of setting +5V) With no load	
Maximum Rated Load	GPT-15XXX	100W(5kV/20mA)
	GPT-12XXX	50W(5kV/10mA)
Maximum Rated Current	GPT-15XXX	20mA
		0.001mA~2mA(0.05kV≤V≤0.5kV) 0.001mA~20mA(0.5kV≤V≤6kV)
	GPT-12XXX	10mA
		0.001mA~2mA(0.05kV≤V≤0.5kV) 0.001mA~10mA(0.5kV<V≤6kV)
Voltmeter Accuracy	± (1% of reading+ 5 V)	
Voltage Regulation	± (1% +5V)[Maximum rated load ->no load]	
Current Measurement Range	GPT-15XXX	0.001mA- 20.00mA
	GPT-12XXX	0.001mA-10.00mA
Current Measurement Best Resolution	GPT-15XXX	0.1uA
		0.1uA (0.1uA~999.9uA)
		1uA (1uA~9.999mA)
	GPT-12XXX	10uA (20.00mA)
		0.1uA
		0.1uA (0.1uA~999.9uA) 1uA(1uA~9.999mA) 10uA(10.00mA)
Current Measurement Accuracy	±(1.5% of reading+3uA) when I<1mA ±(1.5% of reading+30uA) when I≥1mA	
Current Offset	5uA Maximum	
Judgment Accuracy	± (3% of setting+30uA)	
Window Comparator Method	Yes	
ARC DETECT	Yes	
Rise-time Control Function	Yes	
RAMP TIME (Rise Time)	0.1~999.9s	
Fall-time Control Function	Yes	
RAMP DOWN Time	0.0~999.9s	
TIMER (Test Time)	OFF, 0.3s~999.9s	
TIMER Accuracy	+/- (100ppm+20ms)	
GND	ON/OFF	
WAIT TIME	0.0~999.9s	
Maximum Capacitive Load DC Mode	1uF	

<sup>1</sup> At least ramp 0.3 seconds is needed to reach a set voltage of 50V/2mA.

**Insulation Resistance Test**

Output Voltage	50V-1200V	
Output Voltage Resolution	50V	
Output Voltage Accuracy	±(1% of setting +5V) with no load	
Resistance Measurement Range	0.1MΩ~50GΩ	
Test Voltage	Measurement Range	Accuracy
50V≤V≤450V	0.1MΩ~1MΩ	5% of reading + 3 count
	1MΩ~50MΩ	5% of reading + 1 count
	51MΩ~2GΩ	10% of reading + 1 count
500V≤V≤1200V	0.1MΩ~1MΩ	5% of reading + 3 count
	1MΩ~500MΩ	5% of reading + 1 count
	501MΩ~9.999GΩ	10% of reading + 1 count
	10G~50GΩ	20% of reading + 1 count <sup>1</sup>
Test Voltage	Display Range	
50V≤V≤100V	000.1MΩ~10.00GΩ	
150V≤V≤450V	000.1MΩ~20.00GΩ	
500V≤V≤1200V	000.1MΩ~50.00GΩ	
Voltage regulation	± (1% +5V) [Maximum rated load ->no load	
Voltmeter Accuracy	±(1% of reading +5V)	
Resistance Judgment Range	0.1MΩ~50GΩ	
Test Voltage	Judgment Range	Accuracy
50V≤V≤450V	0.1MΩ~1MΩ	5% of setting + 3 count
	1MΩ~50MΩ	5% of setting + 1 count
	51MΩ~2GΩ	10% of setting + 1 count
500V≤V≤1200V	0.1MΩ~1MΩ	5% of setting + 3 count
	1MΩ~500MΩ	5% of setting + 1 count
	501MΩ~9.999GΩ	10% of setting + 1 count
	10G~50GΩ	20% of setting + 1 count <sup>1</sup>
Short-Circuit Current	10mA max.	
Output Impedance	2kΩ	
Window Comparator Method	Yes	
Rise-time Control Function	Yes	
RAMP TIME (Rise Time)	0.1~999.9s	
Fall-time Control Function	Yes	
RAMP DOWN Time	0.0~999.9s	
WAIT TIME	0.0~999.9s	
TIMER (Test Time)	0.3s~999.9s <sup>2</sup>	
TIMER Accuracy	+/- (100ppm+20ms)	
GND	ON/OFF	


NOTE: It is required to implement GND OFFSET action when IR Ground Mode is On.

<sup>1</sup> When IR Ground Mode is On, the maximum 30Gohm measurement range is guaranteed.

<sup>2</sup> When IR Ground Mode is On, test time starts from 0.5 second.

**Ground Bond Test**

Output Current Range	3.00A~32.00A
Output Current Accuracy	±(1% of setting+0.2A) when 3A≤I ≤8A ±(1% of setting+0.05A) 8A < I ≤ 32A
Output Current Resolution	0.01A
Test Voltage	Approximately max. 8VAC (open-circuit)
Frequency	50Hz/60Hz selectable
Ohmmeter Measurement Range	1mΩ ~ 650mΩ



Ohmmeter Measurement Resolution	0.1mΩ
Ohmmeter Measurement Accuracy	±(1% of reading+2mΩ)
Ohmmeter Judgment Accuracy	±(1% of setting+2mΩ)
Window Comparator Method	Yes
TIMER (Test Time)	0.3s~999.9s
TIMER Accuracy	+/(100ppm+20ms)
GND	ON/OFF

**Continuity Test**

Output Current	100mA(DC)
Ohmmeter Measurement Range	0.10Ω~70.00Ω
Ohmmeter Measurement Resolution	0.01Ω
Ohmmeter Measurement Accuracy	±(10% of reading+2Ω)
Ohmmeter Judgment Accuracy	±(10% of setting+2Ω)
Window Comparator Method	Yes
TIMER (Test Time)	0.3s~999.9s
TIMER Accuracy	+/(100ppm+20ms)

**Interface**

REMOTE (Remote terminal)	Yes
SIGNAL IO	Yes
RS232	Yes
USB (Device)	Yes (USB 2.0)
Rear Output	Yes
USB (Host) for data output port	Yes (USB 2.0)
GPIB	Yes (Optional)
LAN	Yes (Optional)
Barcode Reader USB port	Yes (USB-VCP)

**Table 1: Output Limitation in Withstanding Voltage Testing**




Function	Upper Current	Pause	Output Time
AC	GPT- 80mA ≤ I ≤ 15XXX	At least as long as the output time	Maximum 240 seconds
	0.001mA ≤ I < 80mA	Not necessary	Continuous output possible
	GPT- 30mA ≤ I ≤ 12XXX	At least as long as the output time	Maximum 240 seconds
DC	0.001mA ≤ I < 30mA	Not necessary	Continuous output possible
	GPT- 0.001mA ≤ I ≤ 15XXX	Not necessary	Continuous output possible
	GPT- 0.001mA ≤ I ≤ 12XXX	Not necessary	Continuous output possible
GB	15A < I ≤ 32A	At least as long as the output time	999.9 seconds
	3A ≤ I ≤ 15A	Not necessary	999.9 seconds

NOTE: Output Time = Ramp Time + Test Time.

Table 2: GPT-10000 capacitive load table

	Test Condition			Maximum Capacitive Load
	Test Voltage DCW	HI-SET Current	RAMP Time ↗	
1	1.000kV	$I \geq 10.00\text{mA}$	$T \geq 1.0\text{s}$	4.7 $\mu\text{F}$
2	2.000kV	$I \geq 7.00\text{mA}$	$T \geq 1.0\text{s}$	1.65 $\mu\text{F}$
3	3.000kV	$I \geq 8.00\text{mA}$	$T \geq 1.0\text{s}$	1.32 $\mu\text{F}$
4	4.000kV	$I \geq 11.00\text{mA}$	$T \geq 1.0\text{s}$	1.32 $\mu\text{F}$
5	5.000kV	$I \geq 7.00\text{mA}$	$T \geq 1.0\text{s}$	0.66 $\mu\text{F}$
6	6.000kV	$I \geq 8.00\text{mA}$	$T \geq 1.0\text{s}$	0.66 $\mu\text{F}$




## GPT-15001/15002/15003 Dimensions






# GPT-15004 Dimensions

---




# GPT-12001/12002/12003 Dimensions

---



# GPT-12004 Dimensions

---



## Declaration of Conformity

We

**GOOD WILL INSTRUMENT CO., LTD.**

declare that the below mentioned product

Type of Product: Electrical Safety Analyzer

Model Number: **GPT-12001 / GPT-12002/ GPT-12003 / GPT-12004**

satisfies all the technical relations application to the product within the scope of council:

**Directive:** 2014/30/EU; 2014/35/EU; 2011/65/EU; 2012/19/EU

The above product is in conformity with the following standards or other normative documents:

© **EMC**

<b>EN 61326-1:</b> <b>EN 61326-2-1:</b> <b>EN 61326-2-2:</b>	Electrical equipment for measurement, control and laboratory use -- EMC requirements (2013)	
Conducted & Radiated Emission EN 55011: 2016+A1:2017 Class A	Electrical Fast Transients EN 61000-4-4: 2012	
Current Harmonics EN 61000-3-2: 2014	Surge Immunity EN 61000-4-5: 2014+A1:2017	
Voltage Fluctuations EN 61000-3-3: 2013	Conducted Susceptibility EN 61000-4-6: 2014	
Electrostatic Discharge EN 61000-4-2: 2009	Power Frequency Magnetic Field EN 61000-4-8: 2010	
Radiated Immunity EN 61000-4-3: 2006+A2:2010	Voltage Dip/ Interruption EN 61000-4-11: 2004+A1:2017	

© **Safety**

<b>Low Voltage Equipment Directive 2014/35/EU</b>	
Safety Requirements	EN 61010-1: 2010 EN 61010-2-030: 2010 IEC 61010-2-034: 2017

GOOD WILL INSTRUMENT CO., LTD.

No. 7-1, Jhongsing Road, Tucheng Dist., New Taipei City 236, Taiwan

Tel: +886-2-2268-0389

Fax: +866-2-2268-0639

Web: [www.gwinstek.com](http://www.gwinstek.com)

Email: [marketing@goodwill.com.tw](mailto:marketing@goodwill.com.tw)

GOOD WILL INSTRUMENT (SUZHOU) CO., LTD.

No. 521, Zhujiang Road, Snd, Suzhou Jiangsu 215011, China

Tel: +86-512-6661-7177

Fax: +86-512-6661-7277

Web: [www.instek.com.cn](http://www.instek.com.cn)

Email: [marketing@instek.com.cn](mailto:marketing@instek.com.cn)

GOOD WILL INSTRUMENT EURO B.V.

De Run 5427A, 5504DG Veldhoven, The Netherlands

Tel: +31(0)40-2557790

Fax: +31(0)40-2541194

Email: [sales@gw-instek.eu](mailto:sales@gw-instek.eu)

## Declaration of Conformity

We

**GOOD WILL INSTRUMENT CO., LTD.**

declare that the below mentioned product

Type of Product: Electrical Safety Analyzer

Model Number: **GPT-15001 / GPT-15002/ GPT-15003 / GPT-15004**

satisfies all the technical relations application to the product within the scope of council:

**Directive:** 2014/30/EU; 2014/35/EU; 2011/65/EU; 2012/19/EU

The above product is in conformity with the following standards or other normative documents:

© EMC

EN 61326-1: EN 61326-2-1: EN 61326-2-2	Electrical equipment for measurement, control and laboratory use -- EMC requirements (2013)
Conducted & Radiated Emission EN 55011: 2016+A1:2017 Class A EN 55032:2015 Class A	Electrical Fast Transients EN 61000-4-4: 2012
Current Harmonics EN 61000-3-2: 2019	Surge Immunity EN 61000-4-5: 2014+A1:2017
Voltage Fluctuations EN 61000-3-3: 2013+A1:2019	Conducted Susceptibility EN 61000-4-6: 2014
Electrostatic Discharge EN 61000-4-2: 2009	Power Frequency Magnetic Field EN 61000-4-8: 2010
Radiated Immunity EN 61000-4-3: 2006+A2:2010	Voltage Dip/ Interruption EN 61000-4-11: 2004+A1:2017

© Safety

<b>Low Voltage Equipment Directive 2014/35/EU</b>	
Safety Requirements	EN 61010-1: 2010 EN 61010-2-030: 2010 IEC 61010-2-034: 2017

GOOD WILL INSTRUMENT CO., LTD.

No. 7-1, Jhongsing Road, Tucheng Dist., New Taipei City 236, Taiwan

Tel: +886-2-2268-0389

Fax: +866-2-2268-0639

Web: [www.gwinstek.com](http://www.gwinstek.com)

Email: [marketing@goodwill.com.tw](mailto:marketing@goodwill.com.tw)

GOOD WILL INSTRUMENT (SUZHOU) CO., LTD.

No. 521, Zhujiang Road, Snd, Suzhou Jiangsu 215011, China

Tel: +86-512-6661-7177

Fax: +86-512-6661-7277

Web: [www.instek.com.cn](http://www.instek.com.cn)

Email: [marketing@instek.com.cn](mailto:marketing@instek.com.cn)

GOOD WILL INSTRUMENT EURO B.V.

De Run 5427A, 5504DG Veldhoven, The Netherlands

Tel: +31(0)40-2557790

Fax: +31(0)40-2541194

Email: [sales@gw-instek.eu](mailto:sales@gw-instek.eu)

# INDEX

- Accessories ..... 12
- Automatic test
  - add test ..... 103
  - load ..... 101
  - page view ..... 105, 107
  - results ..... 119
  - running a test ..... 113
  - test file name ..... 102
- Caution symbol ..... 5
- Cleaning the instrument ..... 7
- Declaration of conformity 272, 273
- Dimensions ..... 268, 269, 270, 271
- Disposal instructions ..... 8
- EN61010
  - measurement category ..... 7
  - pollution degree ..... 8
- Environment
  - safety instruction ..... 7
- External control ..... 172
  - Interlock key ..... 178
  - overview ..... 173
  - remote operation ..... 174
  - remote terminal ..... 173
  - signal I/O operation ..... 177
  - signal I/O overview ..... 175
- FAQ ..... 251
- Front panel diagram ..... 15
- GPIB installation ..... 24
- Ground
  - symbol ..... 5
- Interlock key ..... 178
- Line voltage selection ..... 23
- List of features ..... 11
- Manual tests
  - ARC mode ..... 60
  - fail mode ..... 56, 65
  - ground mode ..... 74
  - max hold ..... 63
  - overview ..... 39
  - pass hold ..... 64
  - ramp up time ..... 48, 50, 58
  - results ..... 90
  - running a test ..... 85
  - special mode ..... 95, 97
  - test filename ..... 43
  - test frequency ..... 54
  - test function ..... 41
  - test limits ..... 44
  - test reference ..... 55
  - test selection ..... 42
  - test time ..... 46
  - test voltage ..... 52
  - timing diagrams ..... 91
- Marketing
  - contact ..... 253
- Menu tree ..... 31
- Operating precautions ..... 26
- Overview ..... 10
- Package contents ..... 14
- Power on/off
  - safety instruction ..... 7
- Rear panel diagram ..... 19
- Remote control ..... 179
  - Command list ..... 188
  - Command syntax ..... 185
  - function check ..... 183
  - interface configuration ..... 180
- Service operation
  - about disassembly ..... 6
  - contact ..... 253
- Specifications ..... 260
- Test errors ..... 255
- Tilt stand ..... 22
- Utility settings
  - buzzer ..... 128
  - Control settings 136, 150, 155, 158, 159, 161
  - double action 136, 150, 155, 158, 159, 161
  - GPIB ..... 130
  - interface ..... 130
  - key lock 136, 150, 155, 158, 159, 161
  - LCD ..... 126
  - RS232 ..... 130

start control	136, 150, 155, 158, 159, 161	Workplace precautions	.....25
USB	.....130	Zeroing	.. 67, 69, 71, 79, 81, 83, 169
Warning symbol	..... 5		